

# CROWN

## Maintenance Manual



**GPC2000** Series

---

**CROWN**

***TABLE OF CONTENT***

---

Page intentionally left blank

## Table of Content

<b>MA – SAFETY</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Safety Symbols used in the Manual</b> .....	<b>3</b>		Rev.1 04/00
<b>General Maintenance and Repair Safety Notes</b> .....	<b>3</b>		
Maintenance and Repair .....	3		Rev.1 04/00
Before Leaving the Truck .....	4		
Before Carrying out Work on the Truck .....	4		
Before Operating the Truck .....	4		
Warnings and Labels on the Truck .....	4		
<b>ITD – INTRODUCTION</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>General</b> .....	<b>7</b>		
Operating Instructions .....	7		
Service Training .....	7		
Ordering Spare Parts .....	7		
Using the Manual .....	7		
Model-Number .....	8		
<b>M1 – LUBRICATION AND ADJUSTMENT</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Jacking up the Truck</b> .....	<b>11</b>		
<b>Lifting the Truck with a Crane</b> .....	<b>11</b>		
<b>Towing the Truck</b> .....	<b>13</b>		
<b>De-commissioning</b> .....	<b>14</b>		
<b>Re-commissioning</b> .....	<b>14</b>		
<b>Component Access</b> .....	<b>15</b>		
<b>Models</b> .....	<b>17</b>		
<b>Maintenance</b> .....	<b>18</b>		
Check and Maintenance Schedule .....	18		
Recommended Lubricants and Oils .....	27		
Lubricants .....	27		
Cold Store Trucks .....	27		
Grease items and grease intervals .....	28		
Torques .....	30		
<b>M2 – HYDRAULICS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Hydraulic Symbols</b> .....	<b>35</b>		
<b>Hydraulic System</b> .....	<b>39</b>		
Operation .....	39		
GPC2020/2040/2040S .....	39		
Platform Lift .....	40		
Fork High Lift .....	41		
Platform Lift and Fork High Lift .....	42		
Hydraulic Unit Removal .....	43		
Replacing the Hydraulic Pump .....	44		
Removal .....	44		
Installation .....	44		
Replacing the Hydraulic Filter .....	44		
Replacing the Suction Filter .....	44		
Replacing the Oil .....	44		
Start-Up .....	44		
Checking the Valve Settings .....	46		
Checking the Non-Return Valve .....	46		
Checking the Safety Valve .....	46		
Adjusting the Safety Valve .....	46		

<b>M3 – DRIVE UNIT</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Drive Unit</b> .....	<b>51</b>		
General .....	51		
Environmental Protection .....	51		
Drive Wheel .....	51		
Removal .....	51		
Assembly .....	51		
Drive Unit Removal .....	52		
Drive Unit Assembly .....	52		
<b>Transmission</b> .....	<b>52</b>		
Transmission Removal .....	52		
Transmission Assembly .....	52		
<b>Transmission Repairs</b> .....	<b>53</b>		
Disassembly .....	53		
Assembly .....	53		
Bevel Wheel Set Adjustment .....	54		
<b>Oil Change</b> .....	<b>56</b>		
<b>Live Ring Bearing</b> .....	<b>56</b>		
Removal .....	56		
Assembly .....	56		
<b>M4 – ELECTRICS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Electrics - General</b> .....	<b>61</b>		
Wire Colour Codes .....	61		
Abbreviations .....	62		
Electrical Symbols .....	64		
<b>Electrical Components</b> .....	<b>65</b>		
Transmitter (POT, FS, RS) .....	65		
Brake Switch (BRS) .....	65		
Lift/Lower switches (RAS, LOS) .....	65		
Lift limiting switch (LMS) .....	65		
Horn Switch (HNS) .....	65		
Key Switch (KYS) .....	65		
Emergency Disconnect (EDS) .....	65		
Fuses (FU) .....	65		
Walk along switch (WAS) .....	66		
GPC2020 .....	66		
GPC2040 .....	67		
<b>Programmer</b> .....	<b>68</b>		
General .....	68		
Connection .....	68		
Key Description .....	68		
Display .....	68		
SCROLL DISPLAY .....	68		
CHANGE SETTING .....	68		
MORE INFO .....	69		
PROGRAM .....	70		
TEST .....	70		
DIAGNOSTIC .....	70		
Key Combinations .....	70		
SPECIAL DIAGNOSTIC mode .....	70		
SPECIAL PROGRAM mode .....	71		
Deleting the Error History .....	71		
Copying (Cloning) Controller Settings .....	71		
Resetting to Original Settings .....	71		
Programmer Self-Test .....	71		
Traction Controller Removal / Installation .....	72		
Removal .....	72		
Installation .....	72		

<b>M4 – ELECTRICS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
Controller Test .....	73		
Traction Controller 1207 and 1214 Settings .....	74		
Fault Recovery (including recovery from disable) .....	78		
<b>Test Procedure .....</b>	<b>79</b>		
Pulse Monitor Trip - Test (PMT) .....	79		
Equipment .....	79		
Test Procedure .....	79		
PMT- Test Wiring Diagram .....	80		
<b>1207 and 1214 Traction Controllers .....</b>	<b>81</b>		
General .....	81		
Operating Features .....	81		
Functions .....	82		
Key Switch .....	82		
Autotest (Watchdog, internal and external) .....	82		
Current Limit .....	82		
Overvoltage .....	82		
Overtemperature .....	82		
Performance Reduction at Low Voltage .....	82		
Error Detection .....	82		
Error Listing .....	83		
Error Reset .....	83		
Maintenance .....	84		
1207 Control Line Connections .....	85		
Power Line Connections .....	85		
1214 Control Line Connections .....	86		
Power Line Connections .....	86		
1207 Control Panel .....	87		
Setting Potentiometers .....	87		
Programmer Connection .....	87		
Status LED .....	87		
Diagnostics with Status LED .....	87		
Connection side of			
Controller 1214 .....	88		
Programmer connector .....	88		
Status LED .....	88		
LED Diagnostics .....	88		
Status LED .....	89		
Status LED .....	90		
<b>DACI-EL Steering Control System .....</b>	<b>92</b>		
Electrical Connections .....	92		
Performance Connections .....	92		
Control Section Connections .....	92		
Steering Control System Error Codes .....	92		
Steering Control System Error Codes .....	93		
Steering Control System Error Codes .....	94		
Steering Control System Error Codes .....	95		
Steering Control System Error Codes .....	96		
Steering Control System Removal / Installation .....	96		
Removal .....	96		
Installation .....	96		
<b>Distributor Boards .....</b>	<b>98</b>		
General .....	98		
Board 804247-001 .....	99		
Board 804247-002 .....	99		
Board 804247-003 .....	99		
Jumper Arrangement and Usage .....	100		
Platform Lift and Combination .....	101		

<b>M4 – ELECTRICS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
Electrical Steering Option .....	102		
Board 808 191 Contact Arrangement .....	102		
Board 808 191 Contact Arrangement .....	103		
Board 808 197 .....	104		
<b>Contactors .....</b>	<b>105</b>		
Inspection .....	105		
Contacts .....	105		
Coils .....	105		
Springs .....	105		
GPC2020 Travel Contactor Repairs .....	105		
Disassembly .....	105		
Assembly .....	106		
GPC2040 and GPC2040S Travel Contactor Repairs .....	107		
Disassembly .....	107		
Assembly .....	107		
<b>M-5 – BRAKE</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Brake .....</b>	<b>111</b>		
Operational Description .....	111		
GPC 2020 Brake System .....	111		
GPC 2040 Brake System .....	112		
Removal .....	113		
Preparation .....	113		
Maintenance and Repairs .....	113		
Installation .....	114		
Air Gap Setting .....	114		
Brake Moment Setting .....	115		
GPC 2020, Single Stage Brake .....	115		
GPC 2040, Twin Stage Brake .....	115		
GPC 2020 1.6 t, Brake Default Setting .....	115		
GPC 2040 Standard 2.0 t, Brake Default Setting .....	115		
GPC 2040 High Lift and Twin Lift 1.0 t, Brake Default Setting .....	115	115	
<b>Brake Test .....</b>	<b>116</b>		
Braking Distance Setting .....	116		
GPC 2020 Standard 1.6 t .....	116		
Braking Distance with Max. Load .....	116		
Braking Distance with Truck Unladen .....	116		
GPC 2040 Standard 2.0 t .....	116		
Braking Distance with Max. Load .....	116		
Braking Distance with Truck Unladen .....	116		
GPC 2040 High Lift and Twin Lift 1.0 t .....	116		
Braking Distance with Max. Load .....	116		
Braking Distance with Truck Unladen .....	116		
<b>Testing the Load-Dependent Pressure Switch (GPC 2040 only) .....</b>	<b>117</b>		
<b>M6 – STEERING</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Steering Drive System .....</b>	<b>121</b>		
Steering Drive Removal .....	121		
Repairing the Steering Drive .....	121		
Removing the Motor from the Transmission .....	121		
Replacing the Motor Bearings .....	121		
Repairing the Steering Transmission .....	123		
<b>Steering .....</b>	<b>126</b>		
Tiller .....	126		
Tiller and Recuperating Spring Removal (All Models) .....	126		
Tiller Adjustment .....	128		
Forward Travel Setting for Mechanical Steering .....	128		

<b>M6 – STEERING</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
Forward Travel Setting for Electrical Steering .....	129		
<b>Steering Chain .....</b>	<b>130</b>		
Chain Tension Adjustment .....	130		
<b>M7 – LIFTING MECHANISM</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Lifting Mechanism .....</b>	<b>133</b>		
Lifting mechanism adjustment .....	133		
Lift Stop Setting .....	134		
Lift Chains .....	135		
General .....	135		
Inspection .....	135		
Cleaning .....	135		
Wear .....	135		
Freedom of Movement .....	136		
Chain Tension .....	136		
Chain Anchor and Pulleys .....	136		
Worn or Missing Plates .....	136		
Protruding or Turned Chain Pins .....	136		
Corrosion .....	137		
Chain Lateral Wear .....	137		
Uneven Chain Tension .....	137		
Misalignment of Lift Components .....	137		
Lift Chain Lubrication .....	138		
Fork Tine Test .....	139		
General .....	139		
Fork Identification .....	139		
Repairs .....	139		
Crack Inspection .....	139		
Fork Blade Warping .....	140		
Verticality Test .....	140		
Measuring the Fork Tip Width .....	141		
Fork Tine Height Difference .....	141		
Fork Stop .....	141		
Wear .....	142		
<b>M8 – CYLINDERS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Cylinders .....</b>	<b>145</b>		
General .....	145		
Plunger Cylinders (single-acting) .....	145		
Piston Cylinder (Double-Acting Cylinder) .....	146		
Single-Acting Cylinder .....	147		
Double-Acting Cylinder .....	147		
<b>Cylinder .....</b>	<b>148</b>		
General .....	148		
Cylinder Removal .....	148		
Replacing the Rod Seal .....	148		
Platform Lift Cylinder .....	149		
Free Lift Cylinder .....	150		
Free Lift Cylinder for Platform Lift and Combination .....	151		
<b>DIA – ELECTRICAL DIAGRAMS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
Control Circuit 2020 .....	155		
Driver Board 2020 .....	156		
Traction Controller 2020 .....	157		
Brake and BDI 2020 .....	158		
Tiller and Pedestrian Function 2020 .....	159		
Power Lead 2020 .....	160		
Overview 2040 .....	161		



<b>DIA – ELECTRICAL DIAGRAMS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
Driver Board 2040 .....	162		
Driver Board 2040/Platform Lift .....	163		
Traction Controller 2040 .....	164		
Brake and Brake Switch 2040 .....	165		
Lift/Lower and Limit Switch 2040 .....	166		
Tiller: BDI and Pedestrian Function 2040 .....	167		
Power Lead 2040 .....	168		
Overview 2040S .....	169		
Steering Motor Controller 2040S .....	170		
Steering Sensor Encoder 2040S .....	171		
PCB Connection Lead 2040S .....	172		
Steering Feedback POT 2040S .....	173		
Backrest Control Cable 2040S .....	174		
Tiller Lead 2040S .....	175		
Tiller Head Cable 2040S .....	176		
Power Lead 2040S .....	177		
Power Lead 2040S .....	178		
<b>HYD – HYDRAULIC SCHEMATIC</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
2020/2040/2040S .....	181		
Platform Lift .....	182		
Fork Lift .....	183		
Platform/ Fork Lift .....	184		

---

# CROWN

***SAFETY***

---

Page intentionally left blank

## Safety Symbols used in the Manual

To help guide you through the manual and to highlight particular danger areas, we have used graphic illustrations:

### **DANGER**



**This symbol indicates life-threatening risks**

- Failure to comply with this notice may result in severe or fatal injuries to yourself or other people.

### **WARNING**



**This symbol indicates the risk of serious injury and/or serious material damage.**

- Failure to comply with this notice may result in severe injuries to yourself or other people and/or serious material damage.

### **CAUTION**



**This symbol indicates the risk of minor injury and/or minor material damage.**

- Failure to comply with this notice may result in minor injuries to yourself or other people and/or minor material damage.

### **INFORMATION**



**Contains additional information with supplementary notes and hints.**

### **OPTION**



**These items relate to optional features not supplied with the standard version.**

## General Maintenance and Repair Safety Notes

### **DANGER**



**Read the safety notices in the truck Maintenance and Operator's Manuals.**

- Failure to do so could result in severe or fatal injuries to maintenance personnel and/or other persons.

Motorised vehicles can be dangerous if maintenance and service are neglected. For this reason maintenance and inspections must be carried out at regular short intervals by trained personnel working to approved company guidelines.

### **DANGER**



**Follow all national/local safety regulations applicable for maintenance work, e.g. for work on higher levels.**

- Failure to do so could result in severe or fatal injuries to maintenance personnel and/or other persons.

## Maintenance and Repair

1. Maintenance work must only be carried out in accordance with the test and maintenance program contained in the present Maintenance Manual and any applicable service notices.
2. Only qualified and authorised personnel may carry out work on the truck.
3. Always keep fire extinguishers in good working condition. Do not approach fluid levels or leaks with a naked flame.
4. To clean, use a non flammable, non combustible cleaning solution which is groundwater-neutral. Only carry out cleaning with an oil separator. Protect the electrical system from dampness.
5. Keep the service area clean, dry and well-ventilated.
6. Do not allow oil to penetrate the ground or enter the draining system. Used oil must be recycled. Oil filters and desiccants must be treated as special waste products. Relevant applicable regulations must be followed.
7. Neutralise and thoroughly rinse any spilled battery fluid immediately.

8. Keep the truck clean. This will facilitate the location of loose or faulty components.
9. Make sure that capacity and data plates, warnings and labels are legible at all times.
10. Alterations or modifications by the owner or operator are not permitted without the express written authorisation from Crown.
11. Only use original Crown spare parts to ensure the reliability, safety and suitability of the Crown truck.

## Warnings and Labels on the Truck

During regular maintenance check that the warnings and labels on the truck are complete and legible.

- Clean any illegible labels.
- Replace any faulty or missing labels.

The order and meaning of the warnings and labels on the truck are described in section 10.9 of the parts manual.

## Before Leaving the Truck

- Stop the truck.
- Lower the fork carriage fully.
- Apply the parking brake.
- Turn off the travel switch and remove the key.
- Block all wheels when parking on an uneven surface.

## Before Carrying out Work on the Truck

- Raise the truck to free the drive wheel. Press the emergency Stop button and disconnect the battery.
- Prevent the truck from rolling away.
- Before carrying out work on the hoist frame, the lift mast or on the fork carriage: Block these parts according to maintenance instructions in order to prevent them from dropping.
- Only carry out operational testing when there is sufficient room to manoeuvre, to avoid the risk of injury to yourself and others.

## Before Operating the Truck

- Check the safety devices.
- Get into the driver's seat.
- Check the operation of the lifting device, travel direction switch, speed control, steering, warning devices and brakes.

---

**CROWN**

***INTRODUCTION***

---

Page intentionally left blank

**General**

The present manual is designed for Customer Service engineers who wish to familiarise themselves with the maintenance work required for the various truck components.

It also contains troubleshooting sections which can be used to identify and remedy truck faults.

**INFORMATION**



***This book is not an operating manual. It is designed solely for specialist personnel who have been trained and authorised to carry out the work described in the manual.***

This manual therefore contains fewer and less detailed warnings than the Operator's Manual, as the latter is aimed at persons who have very little or no prior experience at all.

**Operating Instructions**

This manual contains no operating instructions. An operating instructions manual is supplied with the vehicle. Additional copies can be ordered as required.

With the help of this manual you and your personnel will be able to ensure the long service life, operational safety and error free functioning of your CROWN vehicle.

**Service Training**

CROWN offers the appropriate vehicle related training for service personnel. Details on this training can be obtained from CROWN on request.

**Ordering Spare Parts**

The maintenance manual does not cover spare parts. These are listed in a separate manual.

Spare parts can be ordered by quoting:

- The truck specification number
- The truck model number
- The truck serial number

This information can be found on the truck's data plate. Only if this information is provided can the order be processed quickly, correctly and reliably.

Please refer to the Technical Specifications Sheet for the utilisable loads, technical data and dimensions for this

series. Brochures can be obtained from your CROWN dealer or from the following address:

**CROWN Gabelstapler GmbH**  
**Moosacher Str. 52**  
**80809 Munich**  
**GERMANY**  
**Tel.: +49 (0)89 / 93 002 -0**  
**Fax: +49 (0)89 / 93 002 -175 oder 133**

**Using the Manual**

The manual is divided into sections. The following table shows how the manual is structured.

<b>Sections Maintenance</b>	
<b>Section</b>	<b>Description</b>
IDX	Table of Content
MA	Safety
MS-ITD	Introduction
MS-1	Lubrication and Adjustment
MS-2	Hydraulics
MS-3	Drive Unit
MS-4	Electrical
MS-5	Brake
MS-6	Steering
MS-7	Mast /Lifting Mechanism
MS-8	Cylinder
DIA	Electrical Diagrams
HYD	Hydraulic Schematic

A01M-gb



## Model-Number

This manual describes the maintenance and repairs for the following truck versions:

### GPC2020

**Modeldescription**

Low Level Order Picker, 1.600 kg capacity

### GPC2040

**Modeldescription**

Low Level Order Picker, 2.000 kg capacity

### GPC2040S

**Modeldescription**

Rider Pallet Truck with Steering Wheel, 2.000 kg capacity

---

**CROWN**

***LUBRICATION AND ADJUSTMENT***

---

Page intentionally left blank

**BUY NOW**

**Then Instant Download  
the Complete Manual  
Thank you very much!**