




Service Manual

Detector™/Sentinel™ Controls GENERATOR SETS

Models Begin
Spec

DGBB	E
DGBC	D
DGCA	M
DGCB	M
DGCC	A
DGDA	L
DGDB	L
DGEA	K
DGFA	K
DGFB	K
DGFC	A



Supplement 960–1056

Date: 11-09-00

Insert with –

Title: Service

Numbers: See Supplement Use

PURPOSE

This supplement contains information for the revised Engine Control Monitor (ECM) board. The revised ECM board contains LED's and terminal board TB3 to aid in genset control troubleshooting. A selection jumper has also been added, which controls how the SWITCH OFF indicator operates.

Both ECM boards are identical in function and how they connect electrically. The present ECM board description in Section 3 of the Service manual has not changed, other than the additional information describing the new components and a figure showing the location of the new components.

SUPPLEMENT USE

Refer to the corresponding pages/headings of your manual and write "IMPORTANT: REFER TO SUPPLEMENT".

Please keep this supplement with the following Service manuals:

928-0502B

928-0506

960-0504A

960-0505

960-0510B

ENGINE CONTROL MONITOR (A11)

The heart of the engine control system is the engine control monitor (ECM) (Figure 3-5). It is a printed circuit board assembly mounted on the back wall of the control box. It starts and stops the engine in response to the control panel switches, engine sensors and remote control signals.

Note that there are two versions of the ECM board and that they both perform the same functions. They only differ in that one version contains additional components, which are, LED's (**DS1 – DS9**), terminal board (**TB3**) and function selection jumper **W10**. Figure 3-5 illustrates the ECM version which contains the additional components.

LED's DS1 through DS9

The ECM LED's are provided as an aid in

troubleshooting the control circuitry. The LED's indicate the following conditions:

LED	STATUS WHEN ILLUMINATED
DS1	B+ is connected to ECM and fuse F4 is good.
DS2	RUN relay is energized.
DS3	Start Command signal enabled.
DS4	Crank signal enabled.
DS5	DC Starter Disconnect signal enabled.
DS6	AC Starter Disconnect signal enabled.
DS7	LOP/HET signal active (time delay circuit has timed-out).
DS8	Reverse battery voltage.
DS9	Remote Shutdown signal active (grnd at TB2-16)

Terminals and Connectors

See Pages 9-5 through 9-9 for the appropriate connection and schematic drawings for the DC control system. See Page 9-10 for typical customer connections at terminal boards **TB1** and **TB2** on the ECM and page 9-11 if the set is also equipped with the auxiliary relay board.

TB3 provides an alternative direct connection to the ECM for the RUN/STOP/REMOTE switch for troubleshooting or if desired, customer connection.

TB3-1 = REMOTE

TB3-2 = RUN

TB3-3 = STOP

Fuses

The ECM has five replaceable fuses to protect it from overloads and ground faults. They are:

F1 Starter solenoid circuit, 20 amps.

F2 Fuel solenoid (switched B+) circuits, 20 amps.

F3 Continuous B+ out to remote circuits, 15 amps.

F4 ECM circuits, 5 amps.

F5 Engine gauge circuits, 5 amps.

Function Selection Jumpers

ECM board has six selection jumpers that can be repositioned to provide the following timed or non-timed warnings or timed or non-timed shutdowns with warnings and control of the SWITCH OFF indicator:

W1 Jumper Position (jumper **W8** must be in the **B** position):

A Non-timed warning under **FLT 2** conditions.

B Non-timed shutdown under **FLT 2** conditions.

C Timed warning under **FLT 2** conditions.

D Timed shutdown under **FLT 2** conditions.

W2 Jumper Position (jumper **W9** must be in the **B** position):

A Non-timed warning under **FLT 1** conditions.

B Non-timed shutdown under **FLT 1** conditions.

C Timed warning under **FLT 1** conditions.

D Timed shutdown under **FLT 1** conditions.

W6 Jumper Position:

A Warning under **Pre-High Engine Temperature** conditions.

B Shutdown under **Pre-High Engine Temperature** conditions.

W7 Jumper Position:

A Warning under **Pre-Low Oil Pressure** conditions.

B Shutdown under **Pre-Low Oil Pressure** conditions.

W8 Jumper Position:

A Warning while running or during standby under **FLT 2** conditions.

B Allows selection of functions with **W1** jumper.

W9 Jumper Position:

A Warning while running or during standby under **FLT 1** conditions.

B Allows selection of functions with **W2** jumper.

W10 Jumper Position (**SWITCH OFF** Indicator):

A Flashing

B Constant ON

C OFF




FIGURE 3-5. ENGINE CONTROL MONITOR FUSES AND FUNCTION SELECTION JUMPERS

Table of Contents

SECTION	TITLE	PAGE
	SAFETY PRECAUTIONS	iii
1	INTRODUCTION	
	About This Manual	1-1
	Test Equipment	1-1
	How To Obtain Service	1-1
2	AC CONTROL	
	General	2-1
	AC Control Panel Components (Detector Control)	2-1
	AC Control Panel Components (Sentinel Control)	2-2
	Automatic Voltage Regulator (AVR) Adjustments	2-3
	Principle Of Generator Operation	2-9
3	ENGINE CONTROL (DETECTOR CONTROL)	
	General	3-1
	Standard Control Panel Components	3-1
	Optional Control Panel Components	3-3
	Control Box Interior	3-4
	Engine Control Monitor (A11)	3-4
	Engine Sensors	3-6
	Auxiliary Control Components	3-9
	Sequence Of Operation	3-14
4	ENGINE CONTROL (SENTINEL CONTROL)	
	General	4-1
	Control Panel Components	4-1
	Control Box Interior	4-2
	Control Relays	4-2
	Terminal Block TB1	4-2
	Dry Contact Module (Optional)	4-3
	Engine Sensors	4-4
	Auxiliary Control Components	4-6
	Sequence Of Operation	4-8

5	TROUBLESHOOTING (DETECTOR CONTROL)	
	The Engine Does Not Crank In Run Mode	5-1
	The Engine Does Not Crank In Remote Mode	5-4
	The Engine Cranks But Does Not Start	5-5
	The Engine Runs Until Fault Shutdown	5-6
	The Engine Lacks Power Or Is Unstable	5-8
	An Amber Warning Lamp Is On	5-10
	The Green Run Lamp Stays Off But The Set Runs Normally	5-11
	No Output Voltage	5-12
	Output Voltage Is Too High Or Too Low	5-15
	Output Voltage Is Unstable	5-16
	The Field Circuit Breaker Keeps Tripping	5-17
	The Phase Currents Are Unbalanced	5-18
6	TROUBLESHOOTING (SENTINEL CONTROL)	
	The Engine Does Not Crank In Run Mode	6-1
	The Engine Does Not Crank In Remote Mode	6-3
	The Engine Cranks But Does Not Start	6-4
	The Engine Runs Until Fault Shutdown	6-5
	The Engine Lacks Power Or Is Unstable	6-7
	No Output Voltage	6-9
	Output Voltage Is Too High Or Too Low	6-12
	Output Voltage Is Unstable	6-13
	The Field Circuit Breaker Keeps Tripping	6-14
	The Phase Currents Are Unbalanced	6-15
7	SERVICING THE GENERATOR	
	Testing The Generator	7-1
	Removing And Disassembling The Generator	7-9
	Reassembling The Generator	7-11
	Servicing The PMG	7-11
8	GOVERNORS	
	Mechanical Governor	8-1
	Electric Governor	8-2
	Electric Governor (Type A) Throttle Lever/Linkage Adjustment	8-5
	Magnetic Speed Pickup Unit Installation	8-7
9	FUEL TRANSFER PUMP AND CONTROL	
	General	9-1
	Operation	9-2
	Wiring Connections	9-4
	Fuel Transfer Pump Motor Connections	9-5
	Testing The Float Switch Assembly	9-6
10	WIRING DIAGRAMS	10-1

Safety Precautions

Before operating the generator set, read the Operator's Manual and become familiar with it and the equipment. **Safe and efficient operation can be achieved only if the equipment is properly operated and maintained.** Many accidents are caused by failure to follow fundamental rules and precautions.

The following symbols, found throughout this manual, alert you to potentially dangerous conditions to the operator, service personnel, or the equipment.

⚠ DANGER *This symbol warns of immediate hazards which will result in severe personal injury or death.*

⚠ WARNING *This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.*

⚠ CAUTION *This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.*

FUEL AND FUMES ARE FLAMMABLE

Fire, explosion, and personal injury or death can result from improper practices.

- DO NOT fill fuel tanks while engine is running, unless tanks are outside the engine compartment. Fuel contact with hot engine or exhaust is a potential fire hazard.
- DO NOT permit any flame, cigarette, pilot light, spark, arcing equipment, or other ignition source near the generator set or fuel tank.
- Fuel lines must be adequately secured and free of leaks. Fuel connection at the engine should be made with an approved flexible line. Do not use copper piping on flexible lines as copper will become brittle if continuously vibrated or repeatedly bent.
- Be sure all fuel supplies have a positive shutoff valve.
- Be sure battery area has been well-ventilated prior to servicing near it. Lead-acid batteries emit a highly explosive hydrogen gas that can be ignited by arcing, sparking, smoking, etc.

EXHAUST GASES ARE DEADLY

- Provide an adequate exhaust system to properly expel discharged gases away from enclosed or sheltered areas and areas where individuals are likely to congregate. Visually and audibly inspect the exhaust daily for leaks per the maintenance schedule. Make sure that exhaust manifolds are secured and not warped. Do not use exhaust gases to heat a compartment.
- Be sure the unit is well ventilated.
- Engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects, and other reproductive harm.

MOVING PARTS CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Keep your hands, clothing, and jewelry away from moving parts.
- Before starting work on the generator set, disconnect battery charger from its AC source, then disconnect starting batteries, negative (-) cable first. This will prevent accidental starting.
- Make sure that fasteners on the generator set are secure. Tighten supports and clamps, keep guards in position over fans, drive belts, etc.
- Do not wear loose clothing or jewelry in the vicinity of moving parts, or while working on electrical equipment. Loose clothing and jewelry can become caught in moving parts. Jewelry can short out electrical contacts and cause shock or burning.
- If adjustment must be made while the unit is running, use extreme caution around hot manifolds, moving parts, etc.

DO NOT OPERATE IN FLAMMABLE AND EXPLOSIVE ENVIRONMENTS

Flammable vapor can cause a diesel engine to overspeed and become difficult to stop, resulting in possible fire, explosion, severe personal injury and death. Do not operate a diesel-powered genset where a flammable vapor environment can be created by fuel spill, leak, etc., unless the genset is equipped with an automatic safety device to block the air intake and stop the engine. The owners and operators of the genset are solely responsible for operating the genset safely. Contact your authorized Onan/Cummins dealer or distributor for more information.

ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Remove electric power before removing protective shields or touching electrical equipment. Use rubber insulative mats placed on dry wood platforms over floors that are metal or concrete when around electrical equipment. Do not wear damp clothing (particularly wet shoes) or allow skin surface to be damp when handling electrical equipment.
- Use extreme caution when working on electrical components. High voltages can cause injury or death. DO NOT tamper with interlocks.
- Follow all applicable state and local electrical codes. Have all electrical installations performed by a qualified licensed electrician. Tag and lock open switches to avoid accidental closure.
- DO NOT CONNECT GENERATOR SET DIRECTLY TO ANY BUILDING ELECTRICAL SYSTEM. Hazardous voltages can flow from the generator set into the utility line. This creates a potential for electrocution or property damage. Connect only through an approved isolation switch or an approved paralleling device.

MEDIUM VOLTAGE GENERATOR SETS (601V to 15kV)

- Medium voltage acts differently than low voltage. Special equipment and training is required to work on or around medium voltage equipment. Operation and maintenance must be done only by persons trained and qualified to work on such devices. Improper use or procedures will result in severe personal injury or death.
- Do not work on energized equipment. Unauthorized personnel must not be permitted near energized equipment. Due to the nature of medium voltage electrical equipment, induced voltage remains even after the equipment is disconnected from the power source. Plan the time for maintenance with authorized personnel so that the equipment can be de-energized and safely grounded.

GENERAL SAFETY PRECAUTIONS

- Coolants under pressure have a higher boiling point than water. DO NOT open a radiator or heat exchanger pressure cap while the engine is running. Allow the generator set to cool and bleed the system pressure first.
- Benzene and lead, found in some gasoline, have been identified by some state and federal agencies as causing cancer or reproductive toxicity. When checking, draining or adding gasoline, take care not to ingest, breathe the fumes, or contact gasoline.
- Used engine oils have been identified by some state or federal agencies as causing cancer or reproductive toxicity. When checking or changing engine oil, take care not to ingest, breathe the fumes, or contact used oil.
- Provide appropriate fire extinguishers and install them in convenient locations. Consult the local fire department for the correct type of extinguisher to use. Do not use foam on electrical fires. Use extinguishers rated ABC by NFPA.
- Make sure that rags are not left on or near the engine.
- Remove all unnecessary grease and oil from the unit. Accumulated grease and oil can cause overheating and engine damage which present a potential fire hazard.
- Keep the generator set and the surrounding area clean and free from obstructions. Remove any debris from the set and keep the floor clean and dry.
- Do not work on this equipment when mentally or physically fatigued, or after consuming any alcohol or drug that makes the operation of equipment unsafe.
- Substances in exhaust gases have been identified by some state or federal agencies as causing cancer or reproductive toxicity. Take care not to breathe or ingest or come into contact with exhaust gases.

KEEP THIS MANUAL NEAR THE GENSET FOR EASY REFERENCE

1. Introduction

ABOUT THIS MANUAL

This service manual is for generator sets with the Cummins® B and C Series diesel engines. It includes engine and generator troubleshooting guides. Engine service instructions are in the applicable engine service manual. Operating and maintenance instructions are in the applicable Operator's Manual.

This manual does not have instructions for servicing printed circuit board assemblies. Always replace a faulty printed circuit board assembly. Attempts to repair a printed circuit board can lead to costly damage to the equipment.

This manual contains basic (generic) wiring diagrams and schematics that are included to help in troubleshooting. Service personnel must use the actual wiring diagram and schematic shipped with each unit. The wiring diagrams and schematics that are maintained with the unit should be updated when modifications are made to the unit.

Read **Safety Precautions** and carefully observe all instructions and precautions in this manual.

TEST EQUIPMENT

Most of the tests in this manual can be done with an AC-DC multimeter, frequency meter, Wheatstone bridge (0.001 ohm precision is necessary for measuring stator winding resistance) and load test panel.

HOW TO OBTAIN SERVICE

Always give the complete Model, Specification and Serial number of the generator set as shown on the nameplate when seeking additional service information or replacement parts. The nameplate is located on the side of the generator output box.

⚠ WARNING *Incorrect service or replacement of parts can result in severe personal injury or death, and/or equipment damage. Service personnel must be qualified to perform electrical and mechanical service. Read and follow Safety Precautions, on pages iii and iv.*

There are separate *Engine Control* and *Troubleshooting* sections for gensets using the Sentinel control or the Detector control (Figure 1-1). Refer to the *Table of Contents* for specific information relating to your genset. The remaining sections apply to both versions.




FIGURE 1-1. CONTROL PANEL CONFIGURATIONS

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**