

EX550-3, EX550-3C Workshop Manual

SECTION 01 GENERAL INFORMATION



CONTENTS

Group 01- Precautions for Disassembling and Assembling


Precautions for Disassembling and
Assembling W01-01-01

Group 02- Tightening

Torque Specifications W01-02-01

Standard Torque Specifications . W01-02-03

Piping Joint W01-02-06



GENERAL INFORMATION / Precautions for Disassembling and Assembling

PRECAUTIONS FOR DISASSEMBLING AND ASSEMBLING

Preparations for Disassembling

- Clean the Machine

Thoroughly wash the machine before bringing it into the shop. Bringing a dirty machine into the shop may cause machine components to be contaminated during disassembling/assembling, resulting in damage to machine components, as well as decreased efficiency in service work.

- Inspect the Machine

Be sure to thoroughly understand disassembling procedures beforehand, to help avoid incorrect disassembling of components as well as the purchase of unnecessary service parts.

Check and record the items listed below to help prevent problems from occurring in the future.

- The machine model, machine serial number, and hour meter reading,
- Reason for disassembly (symptoms, failed parts, and causes).
- Clogging of filters and oil or air leakages, if any,
- Capacities and dirtiness of lubricants,
- Loose or damaged parts.

- Prepare and Clean Tools and Disassembly Area

Prepare tools to be used and areas for disassembling as well as for disassembled parts. Clean the tools and areas.

Precautions for Disassembling and Assembling

- Precautions for Disassembling

- Be sure to provide appropriate containers for draining fluids.
- Plug all disconnected ends of hoses, lines and ports.
- Use matching marks for easier reassembling.
- Be sure to use specified special tools, when so instructed.
- If a part or component cannot be removed after removing its securing nuts and bolts, do not attempt to remove it forcibly. Find the cause(s), then take appropriate measures to remove it.
- Orderly arrange disassembled parts. Put marks and tags on them as necessary.
- Store common parts, such as nuts and bolts with reference to where they are to be used and in a manner that will prevent loss.
- Inspect contact or sliding surfaces of disassembled parts for abnormal wear, sticking, or other damage.
- Measure and record degrees of wear and clearances.

- Precautions for Assembling

- Be sure to clean all parts and inspect them for any damage. If any damage is found on a part, repair or replace it with a new one.
- Dirt or debris on contact or sliding surfaces may shorten the service life of the machine. Take care not to contaminate any contact or sliding surfaces of the parts to be assembled.
- Be sure that liquid-gasket-applied surfaces are clean and dry.
- If an anti-corrosive agent has been used on a new part, be sure to thoroughly clean the part so as to remove the agent.
- Utilize matching marks when assembling.
- Be sure to use designated tools to assemble bearings, bushings and oil seals.
- Keep a record of the number of tools used for disassembling/assembling. After assembling is complete, count the number of tools, so as to make sure that no tools are left in the assembled components.

GENERAL INFORMATION / Precautions for Disassembling and Assembling

GENERAL INFORMATION / Tightening

TORQUE SPECIFICATIONS

No.	Descriptions		Bolt Dia	Q'ty	Wrench Size	Torque			
			mm		(mm)	N·m	kgf·m	lbf·ft	
1	Engine cushion rubber mounting bolt	Front	Engine Cushion rubber	16	2	24	205	21	152
			Cushion Rubber-Machine	16	2	24	205	21	152
		Rear	Engine Cushion rubber	22	2	32	540	55	400
			Cushion Rubber-Machine	16	4	24	205	21	152
2	Radiator mounting bolt		16	4	24	205	21	152	
3	Hydraulic oil tank mounting bolt		16	8	24	205	21	152	
4	Fuel tank mounting bolt		16	8	24	205	21	152	
5	ORS fittings for hydraulic hoses and piping		1-3/16-12UNF		36	175	18	130	
			1-7/16-12UNF		41	205	21	152	
6	Pump transmission mounting bolt		U 7/16-14	14	16	69	7	51	
7	Pump device mounting bolt		20	8	30	390	40	290	
8	Control valve mounting bolt		20	4	30	390	40	290	
9	Swing device mounting bolt		22	26	32	740	75	540	
	Ring gear housing mounting bolt (hexagonal wrench)		18	24	14	295	30	215	
10	Swing motor mounting bolt (hexagonal wrench)		12	16	10	88	9	65	
11	Battery mounting nut		12	2	19	34	3.5	25.5	
12	Cab mounting bolt		STD, LC	16	4	24	205	21	152
			H, LCH	16	6	24	205	21	152
13	Swing bearing mounting bolt to upperstructure		30	36	46	1 910	195	1 410	
	Swing bearing mounting bolt to undercarriage		30	36	46	1 720	175	1 270	

Continued on next page

GENERAL INFORMATION / Tightening

Torque Specifications (continued)

No.	Descriptions	Bolt Dia	Q'ty	Wrench Size	Torque			
		mm		mm	N·m	kgf·m	lbf·ft	
14	Travel device mounting bolt	22	40	32	740	75	540	
	Travel motor mounting bolt	18	8	27	295	30	215	
	Sprocket mounting bolt	22	48	32	740	75	540	
15	Upper roller mounting	20	24	30	540	55	400	
16	Lower roller mounting bolt	STD, H	24	64	36	930	95	690
		LC, LCH	24	72	36	930	95	690
17	Track shoe bolt	STD, H	24	392	32	1 370	140	1 010
		LC, LCH	24	416	32	1 370	140	1 010
18	Track guard mounting bolt	STD, H	24	16	36	930	95	690
		LC, LCH	24	24	36	930	95	690
19	Track mounting bolt	33	36	50	2 160	225	1 590	
20	Coupling and clamp of low pressure piping	Coupling	8		13	10.5 to 12.5	1.05 to 1.26	7.6 to 9.1
		Clamp	U 1/4		11	5.9	0.6	4.3
21	Counterweight mounting bolt	45	2	65	2 750	280	2 030	
	Counterweight retaining bolt	24	4	36	440	45	330	
22	Front Pin-Retaining bolt	20		30	390	40	290	
	Front Pin-Retaining Nut	20		30	390	40	290	

NOTE: (1) Apply lubricant (e.g. white zinc B solved into spindle oil) to bolts and nuts to stabilize friction coefficient of them.
 (2) Make sure bolt and nut threads are clean before installing.

GENERAL INFORMATION / Tightening

STANDARD TORQUE SPECIFICATIONS

⚠ CAUTION: Use tools appropriate for the work to be done. Makeshift tools and procedures can create safety hazards. For loosening and tightening nuts and bolts, use correct size tools. Otherwise, tightening tools may slip, potentially causing personal injury.




Bolt Types

Tighten nuts or bolts correctly to torque specifications. Four different types and grades of bolt are employed. Make sure to employ correct bolts and tighten them correctly when assembling the machine or components.

SA-040

Hexagon T Bolt



Hexagon H Bolt



Hexagon M Bolt



Socket Bolt



W105-01-01-007

Specified Tightening Torque Chart

Bolt Dia.	Wrench Size	Hexagon Wrench Size	T Bolt, Socket-Head bolt			H Bolt			M Bolt		
			N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M 8	13	6	29.5	3	22	19.5	2	14.5	9.8	1	7.2
M 10	17	8	64	6.5	47	49	5	36	19.5	2	14.5
M 12	19	10	108	11	80	88	9	65	34	3.5	25.5
M 14	22	12	175	18	130	137	14	101	54	5.5	40
M 16	24	14	265	27	195	205	21	152	78	8	58
M 18	27	14	390	40	290	295	30	220	118	12	87
M 20	30	17	540	55	400	390	40	290	167	17	123
M 22	32	17	740	75	540	540	55	400	215	22	159
M 24	36	19	930	95	690	690	70	505	275	28	205
M 27	41	19	1 370	140	1 010	1 030	105	760	390	40	290
M 30	46	22	1 910	195	1 410	1 420	145	1 050	540	55	400
M 33	50	24	2 550	260	1 880	1 910	195	1 410	740	75	540
M 36	55	27	3 140	320	2 310	2 400	245	1 770	930	95	690


GENERAL INFORMATION/Tightening

- IMPORTANT:**
- (1) Apply lubricant (i. e. white zinc B dissolved into spindle oil) to nuts and bolts to stabilize their friction coefficients.
 - (2) Torque tolerance is $\pm 10\%$.
 - (3) Be sure to use bolts of correct length. Bolts that are too long cannot be tightened, as the bolt tip comes into contact with the bottom of the bolt hole. Bolts that are too short cannot develop sufficient tightening force.
 - (4) The torques given in the chart are for general use only. Do not use these torques if a different torque is given for a specific application.
 - (5) Make sure that nut and bolt threads are clean before installing. Remove dirt or corrosion, if any.


Bolt Tightening Order

When tightening two or more bolts, tighten them alternately, as shown, to ensure even tightening.


Equally tighten upper and lower alternately



Tighten diagonally



Tighten from center and diagonally




W105-01-01-003

GENERAL INFORMATION/Tightening


Service Recommendations for Split Flange

- IMPORTANT:** (1) Be sure to clean and inspect sealing surfaces. Scratches / roughness cause leaks and seal wear. Unevenness causes seal extrusion. If defects cannot be polished out, replace the component.
- (2) Be sure to use only specified O-rings. Inspect O-rings for any damage. Take care not to file O-ring surfaces. When installing an O-ring into a groove, use grease to hold it in place.
- (3) Loosely assemble split flange halves. Make sure that split is centrally located and perpendicular to the port. Hand-tighten bolts to hold parts in place. Take care not to pinch the O-ring.
- (4) Tighten bolts alternately and diagonally, as shown, to ensure even tightening.
- (5) Do not use air wrenches. Using an air wrench often causes tightening of one bolt fully before tightening of the others, resulting in damage to O-rings or uneven tightening of bolts.




W105-01-01-015

WRONG




W105-01-01-016



W105-01-01-008

RIGHT

WRONG



RIGHT

RIGHT

WRONG



Bend along edge sharply

W105-01-01-009

RIGHT



RIGHT

WRONG



RIGHT

WRONG



Tighten

Loosen

Nut and Bolt Lockings

- Lock Plate

IMPORTANT: Do not reuse lock plates. Do not try to bend the same point twice.

- Split Pin

IMPORTANT: Do not reuse split pins. Match the holes in the bolt and nut while tightening, not while loosening.

- Lock Wire

IMPORTANT: Apply wire to bolts in the bolt-tightening direction, not in the bolt-loosening direction.

W105-01-01-010

GENERAL INFORMATION/Tightening

PIPING JOINT

Pipe Thread Connection / Union Joint Tightening Torque Specifications

Union Joint

Metal sealing faces (4) and (5) of adaptor (1) and hose (2) fit together to seal pressure oil. Union joints are used to join small-diameter lines.

IMPORTANT: (1) Do not over-tighten nut (3). Excessive force will be applied to metal sealing surfaces (4) and (5), possibly cracking adaptor (1). Be sure to tighten nut (3) to specifications.

(2) Scratches or other damage to sealing surfaces (4) or (5) will cause oil leakage at the joint. Take care not to damage them when connecting /disconnecting.

O-ring Seal Joint


O-ring (6) seats against the end face of adaptor (7) to seal pressure oil.

IMPORTANT: (1) Be sure to replace O-ring (6) with a new one when reconnecting.


(2) Before tightening nut (9), confirm that O-ring (6) is seated correctly in O-ring groove (8). Tightening nut (9) with O-ring (6) displaced will damage O-ring (6), resulting in oil leakage.

(3) Take care not to damage O-ring groove (8) or sealing face (10). Damage to O-ring (6) will cause oil leakage.

(4) If loose nut (9) is found to be loose, causing oil leakage, do not tighten it to stop leakage. Instead, replace O-ring (6) with a new one, then tighten nut (9) after confirming that O-ring (6) is securely seated in place.




M202-07-051



W105-01-01-017

Wrench Size mm	Tightening Torque N·m (kgf·m, lbf·ft)
19	29 (3.0, 22)
22	39 (4.0, 29)
27	93 (9.5, 69)
32	137 (14, 101)
36	175 (18, 130)
41	205 (21, 152)
50	255 (26, 188)



M104-07-033

Wrench Size mm	Tightening Torque N·m (kgf·m, lbf·ft)
27	93 (9.5, 69)
32	137 (14, 101)
36	175 (18, 130)
41, 46	205 (21, 152)

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**