

# EX5500

## Workshop Manual

---

---

# SECTION 1 GENERAL INFORMATION



## —CONTENTS—

### **Group 1 Precautions for Disassembling and Assembling**

Precautions for Disassembling and Assembling.....	W1-1-1
--	--------

### **Group 2 Tightening**

Torque Specification.....	W1-2-1
Torque Chart .....	W1-2-2
Piping joint .....	W1-2-5

---

---

(Blank)

# **GENERAL INFORMATION / Precautions for Disassembling and Assembling**

---

## **PRECAUTIONS FOR DISASSEMBLING AND ASSEMBLING**

### **Preparations for Disassembling**

- Clean the Machine

Thoroughly wash the machine before bringing it into the shop. Bringing a dirty machine into the shop may cause machine components to be contaminated during disassembling/assembly, resulting in damage to machine components, as well as decreased efficiency in service work.

- Inspect the Machine

Be sure to thoroughly understand all disassembling/assembly procedures beforehand, to help avoid incorrect disassembling of components as well as personal injury.

Check and record the items listed below to prevent problems from occurring in the future.

- The machine model, machine serial number, and hour meter reading.
- Reason for disassembly (symptoms, failed parts, and causes).
- Clogging of filters and oil, water or air leaks, if any.
- Capacities and condition of lubricants.
- Loose or damaged parts.

- Prepare and Clean Tools and Disassembly Area

Prepare the necessary tools to be used and the area for disassembling work.

### **Precautions for Disassembling and Assembling**

- Precautions for Disassembling

- To prevent dirt from entering, cap or plug the removed pipes.
- Before disassembling, clean the exterior of the components and place it on a work bench.
- Before disassembling, drain gear oil from the reduction gear.
- Be sure to provide appropriate containers for draining fluids.
- Use matching marks for easier reassembly.
- Be sure to use the specified special tools, when instructed.
- If a part or component cannot be removed after removing its securing nuts and bolts, do not attempt to remove it forcibly. Find the cause(s), then take the appropriate measures to remove it.
- Orderly arrange disassembled parts. Mark and tag them as necessary.
- Store common parts, such as bolts and nuts with reference to where they are to be used and in a manner that will prevent loss.
- Inspect the contact or sliding surfaces of disassembled parts for abnormal wear, sticking, or other damage.
- Measure and record the degree of wear and clearances.

- Precautions for Assembling

- Be sure to clean all parts and inspect them for any damage. If any damage is found, repair or replace it.
- Dirt or debris on the contact or sliding surfaces may shorten the service life of the machine. Take care not to contaminate any contact or sliding surfaces.
- Be sure to replace O-rings, backup rings, and oil seals with new ones once they are disassembled. Apply a film of grease before installing.
- Be sure that liquid-gasket-applied surfaces are clean and dry.
- If an anti-corrosive agent has been used on a new part, be sure to thoroughly clean the part to remove the agent.
- Utilize matching marks when assembling.
- Be sure to use the designated tools to assemble bearings, bushings and oil seals.
- Keep a record of the number of tools used for disassembly/assembly. After assembly is complete, count the number of tools, so as to make sure that no tools are missing.

# GENERAL INFORMATION / Precautions for Disassembling and Assembling

---


## Bleeding Air from Hydraulic System

When hydraulic oil is drained, the suction filter or the suction lines are replaced, or the removal and installation of the pump, swing motor, travel motor or cylinder is done, bleed air from the hydraulic system in the following procedures:

- Bleeding Air from Hydraulic Pump

**IMPORTANT: If the engine is started with air trapped in the hydraulic pump housing, damage to the pump may result. Be sure to bleed air before starting the engine.**

- Remove the air bleeding plug from the top of the pump and fill the pump housing with hydraulic oil.
  - After the pump housing is filled with hydraulic oil, temporarily tighten the plug. Then, start the engine and run at slow idle speed.
  - Slightly loosen the plug to bleed air from the pump housing until hydraulic oil oozes out.
  - After bleeding all the air, securely tighten the plug.
- Bleeding Air from Travel Motor / Swing Motor
    - With the drain plug / hose on travel motor / swing motor removed, fill the motor case with hydraulic oil.
  - Bleeding Air from Hydraulic Circuit
    - After refilling hydraulic oil, start the engine. While operating each cylinder, swing motor and travel motor evenly, operate the machine under light loads for 10 to 15 minutes. Slowly start each operation (never fully stroke the cylinders during initial operation stage). As the pilot oil circuit has an air bleed device, air trapped in the pilot oil circuit will be bled while performing the above operation for approx. 5 minutes.
    - Reposition the front attachment to check hydraulic oil level.
    - Stop the engine. Recheck hydraulic oil level. Replenish oil as necessary.



M104-07-021


# GENERAL INFORMATION / Precautions for Disassembling and Assembling

## Floating Seal Precautions

1. In general, replace the floating seal with a new one.

If the floating is to be reused, follow these procedures:


- (1) Keep seal rings together as a matched set with seal ring faces together. Insert a piece of cardboard to protect surfaces.
- (2) Check the seal ring face (A) for scuffing, scoring, corrosion, deformation or uneven wear.
- (3) Check O-ring (B) for tears, breaks, deformation or hardening.



W105-03-05-019

2. If incorrectly assembled, oil leakage or damage will occur. Be sure to do the following, to prevent trouble.

- (1) Clean the floating seal and seal mounting bores with cleaning solvent. Use a wire brush to remove mud, rust or dirt. After cleaning, thoroughly dry parts with compressed air.
- (2) Clean the floating seal and seal mounting bores, as dust on them tends to enter the floating seal when installing it.
- (3) Check that the O-ring is not twisted, and that it is installed correctly on the seal ring.
- (4) After installing the floating seal, check that seal ring surface (A) is parallel with idler face (C) by measuring the distances seal ring surface (A) and idler face (C) at point (a) and (b), as illustrated. If these distances differ, correct the O-ring seating.




Correct

Incorrect

Correct Incorrect

W105-03-05-020




W110-03-05-004


## GENERAL INFORMATION / Precautions for Disassembling and Assembling

### Precautions for Using Nylon Sling

1. Follow the precautions below to use nylon slings safely.
  - Attach protectors (soft material) on the corners of the load so that the nylon sling does not directly contact the corners. This will prevent the nylon sling from damage and the lifted load from slipping.
  - Lower the temperature of the lifted load to lower than 100 °C (212 °F). If unavoidably lifting a load with a temperature of 100 °C (212 °F) or more, reduce the load weight.
  - Do not lift acid or alkali chemicals.
  - Take care not to allow the sling to become wet. The load may slip.
  - When required to use more than one sling, use slings with the same width and length to keep the lifted load balanced.
  - When lifting a load using an eyehole, be sure to eliminate any gaps between the sling and load. (Refer to the right illustration.) Reduce the load weight so that it is less than 80 % of the sling breaking force.
  - Avoid using twisted, bound, connected, or hitched slings.
  - Do not place any object on twisted or bent slings. (Refer to the right illustration.)
  - When removing the slings from under the load, take care not to damage the nylon slings. Avoid contact with protrusions.
  - Avoid dragging slings on the ground, throwing slings or pushing slings with a metal piece.
  - When using with other types of slings (wire rope) or accessories (shackle), protect the joint so that the nylon sling is not damaged.
  - Store the nylon slings indoors so they won't deteriorate with heat, sun light, or chemicals.



W102-04-02-016




W105-04-01-008

W162-01-01-009

## GENERAL INFORMATION / Precautions for Disassembling and Assembling

**!** **CAUTION:** If a load is lifted with a damaged nylon sling, serious personal injury may result. Be sure to visually check the nylon sling for any damage before using.

2. Before using a nylon sling, visually check the nylon sling for any damage corresponding to examples shown to the right. If any damage is found, cut and discard the sling. Even if no damage is found, do not use slings older than 7-years.





## **GENERAL INFORMATION / Precautions for Disassembling and Assembling**

---

### **Maintenance Standard Terminology**

#### **“Standard”**

1. Dimension for parts on a new machine.
2. Dimension of components or assemblies adjusted to specification. Tolerances are indicated as necessary.


#### **“Allowable Limit”**

1. Machine cannot operate normally with the parts exceeding this dimension installed.
2. Repair or adjustment is impossible if this dimension is exceeded.
3. To maintain high machine availability and to save the repair expense, the machine parts should be repaired or replaced before reaching the “Allowable Limit.”

## GENERAL INFORMATION / Tightening Torque

### TIGHTENING TORQUE SPECIFICATIONS

	Descriptions	Bolt Dia (mm)	Qty	Wrench Size (mm)	Torque		
					N·m	kgf·m	lbf·ft
1	Engine cushion rubber mounting bolt	36	12	55	3140	320	2310
2	Engine bracket mounting bolt	30	24	46	1420	145	1050
		22	8	36	740	75	540
		UNC 3/4	32	28.6	440	45	330
3	Hydraulic oil tank mounting bolt	36	10	55	2400	245	1770
4	Fuel tank mounting bolt	36	22	55	2400	245	1770
5	Pump transmission mounting bolt	UNC 1/2	32	19	118	12	87
6	Pump device mounting bolt	24	24	36	690	70	510
7	Fan drive pump mounting bolt	20	8	30	390	40	290
8	Gear pump mounting bolt	12	8	19	88	9	65
9	Control valve mounting nut	20	24	30	390	40	290
10	Swing device mounting bolt	36	56	55	3140	320	2310
11	Swing motor mounting bolt	20	16	30	390	40	290
12	Battery mounting bolt	10	24	17	49	5	36
13	Cab mounting bolt	18	8	27	295	30	215
14	Cab bed mounting bolt	12	50	19	88	9	65
15	Swing bearing mounting bolt	56	142	85	9800	1000	7230
16	Counterweight mounting nut	56	14	85	6860	700	5060
17	Engine bed mounting bolt	36	84	55	3140	320	2310
18	Oil cooler mounting bolt	27	8	41	1370	140	1010
19	Radiator mounting nut	27	8	41	1370	140	1010
20	Fan motor housing mounting bolt	16	8	24	205	21	152
21	Fan motor bracket mounting bolt	12	12	19	88	9	65
22	Travel device mounting bolt	36	24	55	3140	320	2310
		56	56	85	9800	1000	7230
		24	40	36	690	70	510
		20	46	30	390	40	290
23	Travel motor mounting bolt	22	16	32	740	75	540
24	Upper roller mounting bolt	30	24	46	1910	195	1410
25	Lower roller mounting bolt	56	56	85	9800	1000	7230
26	Track pin-retaining bolt	30	156	46	1910	195	1410
27	Side frame mounting bolt	64	80	95	14700	1500	10850
28	Track guard mounting bolt	45	22	70	4710	480	3470
		24	48	36	690	70	510
29	Travel motor cover mounting bolt (backhoe)	36	30	55	3140	320	2310
30	Front pin lock bolt (loading shovel)	24	36	36	930	95	690
		20	8	30	390	40	290
		27	10	19	1030	105	760
31	Front pin lock bolt (backhoe)	24	20	36	930	95	690
		20	22	30	390	40	290

 NOTE: 1. Apply lubricant (e.g. white zinc B dissolved into spindle oil) to bolts and nuts to stabilize friction coefficient of them.

2. Make sure bolt and nut threads are clean before installing.

3. Apply loctite to threads of engine cushion rubber mounting bolts, and lower roller mounting bolts before installing.

# GENERAL INFORMATION / Tightening Torque

## TORQUE CHART

**CAUTION:** Use tools appropriate for the work to be done. Makeshift tools and procedures can create safety hazards. For loosening and tightening nuts and bolts, use correct size tools. Otherwise, tightening tools may slip, potentially causing personal injury.




SA-040


### Bolt Types

Tighten nuts or bolts correctly to torque specifications. Four different types and grades of bolt are employed. Make sure to employ correct bolts and tighten them correctly when assembling the machine or components.

Hexagon T Bolt




Hexagon H Bolt



Hexagon M Bolt



Socket Bolt



W162-01-01-001

### Specified Tightening Torque Chart

Bolt Dia.	Wrench Size	Hexagon Wrench Size	T Bolt, Socket Bolt			H Bolt			M Bolt		
			N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M 8	13	6	29.5	3	22	19.5	2	14.5	9.8	1	7.2
M 10	17	8	64	6.5	47	49	5	36	19.5	2	14.5
M 12	19	10	108	11	80	88	9	65	34	3.5	25.5
M 14	22	12	175	18	130	137	14	101	54	5.5	40
M 16	24	14	265	27	195	205	21	152	78	8	58
M 18	27	14	390	40	290	295	30	220	118	12	87
M 20	30	17	540	55	400	390	40	290	167	17	123
M 22	32	17	740	75	540	540	55	400	215	22	159
M 24	36	19	930	95	690	690	70	505	275	28	205
M 27	41	19	1370	140	1010	1030	105	760	390	40	290
M 30	46	22	1910	195	1410	1420	145	1050	540	55	400
M 33	50	24	2550	260	1880	1910	195	1410	740	75	540
M 36	55	27	3140	320	2310	2400	245	1770	930	95	690

## GENERAL INFORMATION / Tightening Torque


**IMPORTANT:** The following items are applied to both fine and coarse pitch threads.

1. Apply lubricant (i. e. white zinc B dissolved into Spindle oil) to nuts and bolts to reduce their friction coefficients.  
The plated bolts require no lubricant.
2. Torque tolerance is  $\pm 10\%$ .
3. Be sure to use bolts of correct length. Bolts that are too long cannot be tightened, as the bolt tip comes into contact with the bottom of the bolt hole. Bolts that are too short cannot develop sufficient tightening force.
4. The torques given in the chart are for general use only. Do not use these torques if a different torque is given for a specific application.
5. Make sure that nut and bolt threads are clean before installing.  
Remove dirt or corrosion, if any.


### Bolt Tightening Order

When tightening two or more bolts, tighten them alternately, as shown, to ensure even tightening.


Equally tighten upper and lower alternately



Tighten diagonally



Tighten from center and diagonally




W105-01-01-003


# GENERAL INFORMATION / Tightening

## Service Recommendations for Split Flange

- IMPORTANT:** (1) Be sure to clean and inspect sealing surfaces. Scratches / roughness cause leaks and seal wear. Unevenness causes seal extrusion. If defects cannot be polished out, replace the component.
- (2) Be sure to use only specified O-rings. Inspect O-rings for any damage. Take care not to file O-ring surfaces. When installing an O-ring into a groove, use grease to hold it in place.
- (3) Loosely assemble split flange halves. Make sure that the split is centrally located and perpendicular to the port. Hand-tighten the bolts to hold the parts in place. Take care not to pinch the O-ring.
- (4) Tighten bolts alternately and diagonally, as shown, to ensure even tightening.
- (5) Do not use air wrenches. Using an air wrench often causes tightening of one bolt fully before tighten the others, resulting in damage to O-rings or uneven tightening of bolts.




**WRONG**




W105-01-01-015

W105-01-01-016




**RIGHT**



Bend along edge sharply

**WRONG**



Do not bend it round



W105-01-01-008

## Nut and Bolt Lockings

### • Lock Plate


**IMPORTANT:** Do not reuse lock plates. Do not try to bend the same point twice.

**RIGHT**



Bend along edge sharply

**RIGHT**



**WRONG**




W105-01-01-009

### • Cotter Pin

**IMPORTANT:** Do not reuse cotter pins. Match the holes in the bolt and nut while tightening, not while loosening.


**RIGHT**



**RIGHT**




**WRONG**




**RIGHT**

Tighten



Loosen

**WRONG**




W105-01-01-010

## GENERAL INFORMATION / Tightening

### PIPING JOINT

**IMPORTANT:** The torques given in the chart are for general use only. Do not use these torques if a different torque is given for a specific application.




M202-07-051

### Pipe Thread Connection / Union Joint Tightening Torque Specifications

#### Union Joint

Metal sealing faces (4) and (5) of adaptor (1) and hose (2) fit together to seal pressure oil. Union joints are used to join small-diameter lines.



W105-01-01-017

**IMPORTANT:** (1) Do not over-tighten union nut (3). Excessive force will be applied to metal sealing surfaces (4) and (5), possibly cracking adaptor (1). Be sure to tighten union nut (3) to specifications.

(2) Scratches or other damage to sealing surfaces (4) or (5) will cause oil leakage at the joint. Take care not to damage them when connecting /disconnecting.

Type	Wrench Size		Tightening Torque	
	Union Nut	Joint Body	N·m (kgf·m)	lbf·ft
30° Male Union Joint	19	19	59 (6)	43
	22	22	98 (10)	72
	27	27	118 (12)	87
	36	36	235 (24)	134
	41	41	295 (30)	215
	50	50	490 (50)	360
	60	60	670 (68)	490
	70	70	980 (100)	720
37° Female Union Joint	19	17	44 (4.5)	32.5
	22	19	59 (6)	43
	27	22	118 (12)	87
	36	30, 32	235 (24)	134
	41	36	295 (30)	215
	50	46	490 (50)	360

**NOTE:** Tightening torque for the non-union type 37° male joint is the same as the 37° female union joint.

## GENERAL INFORMATION / Tightening

### O-Ring Seal Joint


O-ring (6) seats against the end face of adaptor (7) to seal pressure oil.

**IMPORTANT:** (1) Be sure to replace O-ring (6) with a new one when reconnecting.

(2) Before tightening union nut (9), confirm that O-ring (6) is seated correctly in O-ring groove (8). Tightening union nut (9) with O-ring (6) displaced will damage O-ring (6), resulting in oil leakage.

(3) Take care not to damage O-ring groove (8) or sealing face (10). Damage to O-ring (6) will cause oil leakage.

(4) If union nut (9) is found to be loose, causing oil leakage, do not tighten it to stop the leak. Instead, replace O-ring (6) with a new one, then tighten union nut (9) after confirming that O-ring (6) is securely seated in place.




M104-07-033

Wrench Size		Tightening Torque	
Union Nut	Joint Body	N·m (kgf·m)	lbf·ft
19	17	59 (6)	43
22	19	98 (10)	72
27	22	118 (12)	87
36	30, 32	235 (24)	134
41	36	295 (30)	215
50	46	490 (50)	360

# GENERAL INFORMATION / Tightening

### Screwed-In Connection

**IMPORTANT:** Many types of screwed-in connections are used for hose connections. Be sure to confirm that the thread pitch and thread type (tapered or straight) are the correct type before using any screw-in connection.



W105-01-01-018


Male Tapered Thread		
Wrench Joint Body	Tightening Torque	
	N·m (kgf·m)	lbf·ft
17, 19	59 (6)	43
19, 22	98 (10)	72
27, 22	118 (12)	87
36, 32	235 (24)	134
41	295 (30)	215
50	490 (50)	360
60	670 (68)	490
70	980 (100)	720

### Seal Tape Application

Seal tape is used to seal clearances between male and female threads, so as to prevent any leakage between threads. Be sure to apply just enough seal tape to fill up thread clearances. Do not overwrap.


- Application Procedure

Confirm that the thread surface is clean, free of dirt or damage.  
Apply seal tape around threads as shown. Wrap seal tape in the same direction as the threads.



W105-01-01-019

Leave one to two pitch threads uncovered



M114-07-041

### Low-Pressure-Hose Clamp Tightening Torque

Low-pressure-hose clamp tightening torque differs depending on the type of clamp. See below for correct tightening torque of each type of low-pressure-hose clamp.


T-Bolt Type Band Clamp:

4.4 N·m (0.45 kgf·m, 3.25 lbf·ft )

Worm Gear Type Band Clamp:


5.9 to 6.9 N·m (0.6 to 0.7 kgf·m, 4.3 to 5.1 lbf·ft )

T-Bolt Type



M114-07-042

Worm Gear Type



M114-07-043



## GENERAL INFORMATION / Tightening


### Connecting Hose




#### CAUTION:

- (1) When replacing hoses, be sure to use only genuine Hitachi service parts. Using hoses other than genuine Hitachi hoses may cause oil leakage, hose rupture or separation of fitting, possibly resulting in a fire on the machine.
- (2) Do not install hoses kinked. Application of high oil pressure, vibration, or an impact to a kinked hose may result in oil leakage, hose rupture or separation of fitting. Utilize print marks on hoses when installing hoses to prevent hose from being installed kinked.
- (3) If hoses rub against each other, wear to the hoses will result, leading to hose rupture. Take necessary measures to protect hoses from rubbing against each other. Take care that hoses do not come into contact with moving parts or sharp objects.

#### WRONG




#### RIGHT




W105-01-01-011

#### WRONG




#### RIGHT




W105-01-01-012

#### WRONG




#### RIGHT




W105-01-01-013

#### WRONG



#### RIGHT



W105-01-01-014

## GENERAL INFORMATION / Tightening

---

**\*REFEREVCE: Major Parts to Be Replaced at Regular Intervals.**

The parts listed below deteriorate as the machine ages and are worn out or fatigued by repeated loads, resulting in possible severe personal injury and/or machine trouble. The service life of these parts can not be detected through machine operation or visual inspection.

Therefore, these parts should be replaced at regular intervals even if no abnormalities are noticed. In case any abnormalities are found on a part at any time regardless of its specified replacement interval, immediately replace the part.

Periodic Replacement Parts		Replacement Intervals	
Engine	Fuel hose (Fuel tank to filter)	Every 2 years	
	Fuel hose (Fuel tank to injection pump)	Every 2 years	
	Heater hose (Heater to engine)	Every 2 years	
Hydraulic System	Basic Machine	Pump suction hose	Every 2 years
		Pump delivery hose	Every 2 years
	Front-End Attachment	Motor line hose	Every 2 years
		Cylinder line hose	Every 2 years
		Pilot hose	Every 2 years

**IMPORTANT:** Be sure to replace seals, such as O-rings and hose clamp along with replacing hoses. Each hose has an individual service life. If any abnormalities are found during the regular interval check and/or maintenance service, be sure to replace with a new one.

## GENERAL INFORMATION / Tightening

---

(Blank)

**BUY NOW**

**Then Instant Download  
the Complete Manual  
Thank you very much!**