

Workshop Manual

ZAXIS

650LC-3

670LCH-3


Hydraulic Excavator

Service Manual consists of the following separate Part No;
Technical Manual (Operational Principle) : Vol. No.TO1J7-E
Technical Manual (Troubleshooting) : Vol. No.TT1J7-E
Workshop Manual : Vol. No.W1J7-E

SAFETY

RECOGNIZE SAFETY INFORMATION

- These are the **SAFETY ALERT SYMBOLS**.
- When you see these symbols on your machine or in this manual, be alert to the potential for personal injury.
- Follow recommended precautions and safe operating practices.



001-E01A-0001

SA-688

UNDERSTAND SIGNAL WORDS

- On machine safety signs, signal words designating the degree or level of hazard - **DANGER**, **WARNING**, or **CAUTION** - are used with the safety alert symbol.
 - **DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
 - **WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
 - **CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
 - **DANGER** or **WARNING** safety signs are located near specific hazards. General precautions are listed on **CAUTION** safety signs.
 - Some safety signs don't use any of the designated signal words above after the safety alert symbol are occasionally used on this machine.
- To avoid confusing machine protection with personal safety messages, a signal word **IMPORTANT** indicates a situation which, if not avoided, could result in damage to the machine.
-  **NOTE** indicates an additional explanation for an element of information.

002-E01A-1223




SA-1223

SAFETY

FOLLOW SAFETY INSTRUCTIONS

- Carefully read and follow all safety signs on the machine and all safety messages in this manual.
- Safety signs should be installed, maintained and replaced when necessary.
 - If a safety sign or this manual is damaged or missing, order a replacement from your authorized dealer in the same way you order other replacement parts (be sure to state machine model and serial number when ordering).
- Learn how to operate the machine and its controls correctly and safely.
- Allow only trained, qualified, authorized personnel to operate the machine.
- Keep your machine in proper working condition.
 - Unauthorized modifications of the machine may impair its function and/or safety and affect machine life.
 - Do not modify any machine parts without authorization. Failure to do so may deteriorate the part safety, function, and/or service life. In addition, personal accident, machine trouble, and/or damage to material caused by unauthorized modifications will void Hitachi Warranty Policy.
 - Do not use attachments and/or optional parts or equipment not authorized by Hitachi. Failure to do so may deteriorate the safety, function, and/or service life of the machine. In addition, personal accident, machine trouble, and/or damage to material caused by using unauthorized attachments and/or optional parts or equipment will void Hitachi Warranty Policy.
- The safety messages in this SAFETY chapter are intended to illustrate basic safety procedures of machines. However it is impossible for these safety messages to cover every hazardous situation you may encounter. If you have any questions, you should first consult your supervisor and/or your authorized dealer before operating or performing maintenance work on the machine.



SA-003

003-E01B-0003

SAFETY

PREPARE FOR EMERGENCIES

- Be prepared if a fire starts or if an accident occurs.
 - Keep a first aid kit and fire extinguisher on hand.
 - Thoroughly read and understand the label attached on the fire extinguisher to use it properly.
 - To ensure that a fire-extinguisher can be always used when necessary, check and service the fire-extinguisher at the recommended intervals as specified in the fire-extinguisher manual.
 - Establish emergency procedure guidelines to cope with fires and accidents.
 - Keep emergency numbers for doctors, ambulance service, hospital, and fire department posted near your telephone.



SA-437

004-E01A-0437


WEAR PROTECTIVE CLOTHING

- Wear close fitting clothing and safety equipment appropriate to the job.

You may need:

- A hard hat
- Safety shoes
- Safety glasses, goggles, or face shield
- Heavy gloves
- Hearing protection
- Reflective clothing
- Wet weather gear
- Respirator or filter mask.

Be sure to wear the correct equipment and clothing for the job. Do not take any chances.



SA-428

- Avoid wearing loose clothing, jewelry, or other items that can catch on control levers or other parts of the machine.
- Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating the machine.

005-E01A-0438

SAFETY

PROTECT AGAINST NOISE

- Prolonged exposure to loud noise can cause impairment or loss of hearing.
- Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortably loud noises.



006-E01A-0434

SA-434

INSPECT MACHINE

- Inspect your machine carefully each day or shift by walking around it before you start it to avoid personal injury.
- In the walk-around inspection be sure to cover all points described in the "RE-START INSPECTION" chapter in the operator's manual.



007-E01A-0435

SA-435

SAFETY

GENERAL PRECAUTIONS FOR CAB

- Before entering the cab, thoroughly remove all dirt and/or oil from the soles of your work boots. If any controls such as a pedal is operated while with dirt and/or oil on the soles of the operator's work boots the operator's foot may slip off the pedal, possibly resulting in a personal accident.
- Do not leave parts and/or tools lying around the operator's seat. Store them in their specified locations.
- Avoid storing transparent bottles in the cab. Do not attach any transparent type window decorations on the windowpanes as they may focus sunlight, possibly starting a fire.
- Refrain from listening to the radio, or using music headphones or mobile telephones in the cab while operating the machine.
- Keep all flammable objects and/or explosives away from the machine.
- After using the ashtray, always cover it to extinguish the match and/or tobacco.
- Do not leave cigarette lighters in the cab. When the temperature in the cab increases, the lighter may explode.

524-E01A-0000

**SECTION AND GROUP
CONTENTS**

SECTION 1 GENERAL INFORMATION

Group 1 Precautions for disassembling and Assembling	
Group 2 Tightening Torque	
Group 3 Painting	
Group 4 Bleeding Air from Hydraulic Oil Tank	

WORKSHOP MANUAL

SECTION 2 UPPERSTRUCTURE

Group 1 Cab	
Group 2 Counterweight	
Group 3 Main Frame	
Group 4 Pump Device	
Group 5 Control Valve	
Group 6 Swing Device	
Group 7 Pilot Valve	
Group 8 Pilot Shut-Off Solenoid Valve	
Group 9 Solenoid Valve	
Group 10 Signal Control Valve	
Group 11 Shockless Valve	
Group 12 Fan Valve	
Group 13 Fan Motor	
Group 14 Engine	

SECTION 3 UNDERCARRIAGE

Group 1 Swing Bearing	
Group 2 Travel Device	
Group 3 Center Joint	
Group 4 Track Adjuster	
Group 5 Front Idler	
Group 6 Upper and Lower Roller	
Group 7 Track	

SECTION 4 FRONT ATTACHMENT

Group 1 Front Attachment	
Group 2 Cylinder	

TECHNICAL MANUAL (Operational Principle)

SECTION 1 GENERAL

- Group 1 Specification
- Group 2 Component Layout
- Group 3 Component Specifications

SECTION 2 SYSTEM

- Group 1 Controller
- Group 2 Control System
- Group 3 ECM System
- Group 4 Hydraulic System
- Group 5 Electrical System

SECTION 3 COMPONENT OPERATION

- Group 1 Pump Device
- Group 2 Swing Device
- Group 3 Control Valve
- Group 4 Pilot Valve
- Group 5 Travel Device
- Group 6 Signal Control Valve
- Group 7 Others (Upperstructure)
- Group 8 Others (Undercarriage)

TECHNICAL MANUAL (Troubleshooting)

SECTION 4 OPERATIONAL PERFORMANCE TEST

- Group 1 Introduction
- Group 2 Standard
- Group 3 Engine Test
- Group 4 Excavator Test
- Group 5 Component Test
- Group 6 Adjustment

SECTION 5 TROUBLESHOOTING

- Group 1 Diagnosing Procedure
 - Group 2 Monitor Unit
 - Group 3 Dr. ZX
 - Group 4 ICF
 - Group 5 Component Layout
 - Group 6 Troubleshooting A
 - Group 7 Troubleshooting B
 - Group 8 Electrical System Inspection
-

SECTION 1 GENERAL



— CONTENTS —

Group 1 Precautions for Disassembling and Assembling

Precautions for Disassembling and Assembling.....T1-1-1

Group 2 Tightening Torque

Tightening Torque Specification W1-2-1
Torque Chart W1-2-2
Piping Joint W1-2-5
Periodic Replacement of Parts W1-2-9

Group 3 Painting

Painting..... W1-3-1

Group 4 Bleeding Air from Hydraulic Oil Tank

Bleeding Air from Hydraulic Oil Tank..... W1-4-1

GENERAL / Precautions for Disassembling and Assembling

PRECAUTIONS FOR DISASSEMBLING AND ASSEMBLING

Precautions for Disassembling and Assembling

- Clean the Machine

Thoroughly wash the machine before bringing it into the shop. Bringing a dirty machine into the shop may cause machine components to be contaminated during disassembling/assembly, resulting in damage to machine components, as well as decreased efficiency in service work.

- Inspect the Machine

Be sure to thoroughly understand all disassembling / assembling procedures beforehand, to help avoid incorrect disassembling of components as well as personal injury.

Be sure to and record the items listed below to prevent problems from occurring in the future.

- The machine model, machine serial number, and hour meter reading.
- Reason for disassembly (symptoms, failed parts, and causes).
- Clogging of filters and oil, water or air leaks, if any.
- Capacities and condition of lubricants.
- Loose or damaged parts.

- Prepare and Clean Tools and Disassembly Area

Prepare the necessary tools to be used and the area for disassembling work.

- Precautions for Disassembling

- To prevent dirt from entering, cap or plug the removed pipes.
- Before disassembling, clean the exterior of the components and place on a work bench.
- Before disassembling, drain gear oil from the reduction gear.
- Be sure to provide appropriate containers for draining fluids.
- Use matching marks for easier reassembling.
- Be sure to use the specified special tools, when instructed.
- If a part or component cannot be removed after removing its securing nuts and bolts, do not attempt to remove it forcibly. Find the cause(s), then take the appropriate measures to remove it.
- Orderly arrange disassembled parts. Mark and tag them as necessary.
- Store common parts, such as bolts and nuts with reference to where they are to be used and in a manner that will prevent loss.
- Inspect the contact or sliding surfaces of disassembled parts for abnormal wear, sticking, or other damage.
- Measure and record the degree of wear and clearances.

GENERAL / Precautions for Disassembling and Assembling

• Precautions for Assembling

- Be sure to clean all parts and inspect them for any damage. If any damage is found, repair or replace part.
- Dirt or debris on the contact or sliding surfaces may shorten the service life of the machine. Take care not to contaminate any contact or sliding surfaces.
- Before assembling, coat all inner parts with clean hydraulic oil or gear oil. Especially coat the sliding surfaces with clean hydraulic oil or gear oil.
- Be sure to replace O-rings, backup rings, and oil seals with new ones once they are disassembled. Apply a film of grease before installing.
- Check that liquid-gasket-applied surfaces are clean and dry.
- If an anti-corrosive agent has been used on a new part, be sure to thoroughly clean the part to remove the agent.
- Utilize matching marks when assembling.
- Be sure to use the designated tools to assemble bearings, bushings and oil seals.
- Keep a record of the number of tools used for disassembly / assembly. After assembling is complete, count the number of tools, so as to make sure that no forgotten tools remain in the assembled machine.

Bleeding Air from Hydraulic System

When hydraulic oil is drained, the suction filter or the suction lines are replaced, or the removal and installation of the pump, swing motor, travel motor or cylinder is done, bleed air from the hydraulic system in the following procedures:

IMPORTANT: If the engine is started with air trapped in the hydraulic pump housing, damage to the pump may result. If the hydraulic motor is operated with air trapped in the hydraulic motor housing, damage to the motor may result. If the cylinder is operated with air trapped in the cylinder tube, damage to the cylinder may result. Be sure to bleed air before starting the engine.

• Bleeding Air from Hydraulic Pump

- Remove the air bleeding plug from the top of the pump and fill the pump housing with hydraulic oil.
- After the pump housing is filled with hydraulic oil, temporarily tighten the plug. Then, start the engine and run at slow idle speed.
- Slightly loosen the plug to bleed air from the pump housing until hydraulic oil oozes out.
- After bleeding all the air, securely tighten the plug.


• Bleeding Air from Travel Motor / Swing Motor

- With the drain plug / hose on travel motor / swing motor removed, fill the motor case with hydraulic oil.

GENERAL / Precautions for Disassembling and Assembling

- Bleeding Air from Hydraulic Circuit

- After refilling hydraulic oil, start the engine. While operating each cylinder, swing motor and travel motor evenly, operate the machine under light loads for 10 to 15 minutes. Slowly start each operation (never fully stroke the cylinders during initial operation stage). As the pilot oil circuit has an air bleed device, air trapped in the pilot oil circuit will be bled while performing the above operation for approx. 5 minutes.
- Reposition the front attachment to check hydraulic oil level.
- Stop the engine. Recheck hydraulic oil level. Replenish oil as necessary.




M104-07-021

GENERAL / Precautions for Disassembling and Assembling

Floating Seal Precautions

1. In general, replace the floating seal with a new one after disassembling. If the floating seal is to be reused, follow these procedures:




- (1) Keep seal rings together as a matched set with seal ring faces together. Insert a piece of cardboard to protect surfaces.
- (2) Check the slide surface on seal ring (A) for scuffing, scoring, corrosion, deformation or uneven wear.
- (3) Check O-ring (B) for tears, breaks, deformation or hardening.




W105-03-05-019

2. If incorrectly assembled, oil leakage or damage will occur. Be sure to do the following, to prevent trouble.

- (1) Clean the floating seal and seal mounting bores with cleaning solvent. Use a wire brush to remove mud, rust or dirt. After cleaning, thoroughly dry parts with compressed air.
- (2) Clean the floating seal and seal mounting bores. Check the bore surface for scuffing or scoring by touching the surface with touch.
- (3) Check that the O-ring is not twisted, and that it is installed correctly on the seal ring.



- (4) After installing the floating seal, check that seal ring surface (A) is parallel with seal mating face (C) by measuring the distances (A) and (C) at point (a) and (b), as illustrated. If these distances differ, correct the O-ring seating.




W105-03-05-020

W110-03-05-004


GENERAL / Precautions for Disassembling and Assembling

Precautions for Using Nylon Sling


1. Follow the precautions below to use nylon slings safely.
 - Attach protectors (soft material) on the corners of the load so that the nylon sling does not directly contact the corners. This will prevent the nylon sling from being damaged and the lifted load from slipping.
 - Lower the temperature of the lifted load to lower than 100 °C (212 °F). If unavoidably lifting a load with a temperature of 100 °C (212 °F) or more, reduce the load weight.
 - Do not lift acid or alkali chemicals.
 - Take care not to allow the sling to become wet. The load may slip.
 - When required to use more than one sling, use slings with the same width and length to keep the lifted load balanced.
 - When lifting a load using an eyehole, be sure to eliminate any gaps between the sling and load. (Refer to the right illustration.) Reduce the load weight so that it is less than 80 % of the sling breaking force.
 - Avoid using twisted, bound, connected, or hitched slings.
 - Do not place any object on twisted or bent slings. (Refer to the right illustration.)
 - When removing the slings from under the load, take care not to damage the nylon slings. Avoid contact with protrusions.
 - Avoid dragging slings on the ground, throwing slings or pushing slings with a metal object.
 - When using with other types of slings (wire rope) or accessories (shackle), protect the joint so that the nylon sling is not damaged.
 - Store the nylon slings indoors so they won't deteriorate with heat, sun light, or chemicals.



W102-04-02-016



W105-04-01-008



W162-01-01-009


GENERAL / Precautions for Disassembling and Assembling



CAUTION: If a load is lifted with a damaged nylon sling, serious personal injury may result. Be sure to visually check the nylon sling for any damage before using.

2. Before using a nylon sling, visually check the nylon sling for any damage corresponding to examples shown to the right. If any damage is found, cut and discard the sling. Even if no damage is found, do not use slings older than 7-years.

Damaged Appearance Broken Sewing Thread



W162-01-01-002

Scuffing



W162-01-01-003


Fuzz

Broken Sewing Thread



W162-01-01-004

Broken Sewing Thread



W162-01-01-005

Broken Sewing Thread



W162-01-01-006

Scoring

Separation of Belt



W162-01-01-007

Fuzz

Scuffing

Broken Warp



W162-01-01-008

GENERAL / Precautions for Disassembling and Assembling

MAINTENANCE STANDARD TERMINOLOGY

“Standard”

1. Dimension for parts on a new machine.
2. Dimension of new components or assemblies adjusted to specification.


“Allowable Limit”

1. Normal machine performance cannot be accomplished after exceeding this limit.
2. Repair or adjustment is impossible after exceeding this limit.
3. Therefore, in consideration of operation efficiency and maintenance expense, proper maintenance shall be carried out before reaching the “Allowable Limit”.

GENERAL / Tightening

TIGHTENING TORQUE SPECIFICATION

No.	Descriptions		Bolt Dia	Q'ty	Wrench Size (mm)	Torque		
			mm			N·m	(kgf·m)	(lbf·ft)
1	Engine cushion rubber mounting bolt	Front (Cushion rubber-machine)	27	2	41	1050	(105)	(775)
		Rear (Cushion rubber-machine)	33	2	50	1950	(195)	(1440)
2	Engine bracket mounting bolt		14	8	22	210	(21)	(155)
3	Radiator mounting bolt		24	4	36	950	(95)	(700)
4	Hydraulic oil tank mounting bolt		18	8	27	300	(30)	(220)
5	Fuel tank mounting bolt		18	8	27	300	(30)	(220)
6	ORS fittings for hydraulic hoses and piping		1 - $\frac{3}{16}$ -12UNF		36	180	(18.0)	(135)
			1 - $\frac{7}{16}$ -12UNF		41	210	(21.0)	(155)
7	Pump transmission mounting bolt		12	14	19	110	(11)	(80)
8	Pump device mounting bolt		20	8	17 Holes	400	(40)	(295)
9	Fan pump mounting bolt		16	4	14 Holes	210	(21)	(155)
10	Fan motor mounting nut		12	4	19	110	(11)	(81.0)
11	Control valve mounting bolt		20	4	30	400	(41.0)	(295)
12	Control valve bracket mounting bolt		20	8	30	400	(41.0)	(295)
13	Swing device mounting bolt		22	26	32	750	(76.5)	(550)
			18	24	14 Holes	300	(30)	(220)
14	Swing motor mounting bolt		12	16	10 Holes	90	(9)	(66)
15	Battery mounting bolt		12	2	19	35	(3.5)	(26)
16	Cab mounting nut		16	6	24	210	(21.5)	(155)
17	Swing bearing mounting bolt to upperstructure		30	40	46	1750	(175)	(1290)
	Swing bearing mounting bolt to undercarriage		30	40	46	1750	(175)	(1290)
18	Travel device mounting bolt		27	48	41	1400	(140)	(1030)
	Travel motor mounting bolt		18	8	27	300	(30.5)	(220)
	Sprocket mounting bolt		27	48	41	1400	(140)	(1030)
19	Upper roller mounting bolt		20	24	30	550	(55)	(405)
20	Lower roller mounting bolt		24	64	36	950	(95)	(700)
21	Track shoe bolt		27	376	32	2000	(200)	(1475)
22	Track guard mounting bolt	LC	27	16	41	1400	(140)	(1030)
		LCH	27	30	41	1400	(140)	(1030)
23	Track mounting bolt		36	44	55	2800	(280)	(2065)
24	Low-pressure piping	Flex master coupling	8		13	10.5 to 12.5	(1.05 to 1.26)	(7.7 to 9.2)
		T bolt clamp	1/4-28 UNF		11	10	(1.0)	(7.4)
25	Counterweight mounting bolt		45	2	65	2800	(280)	(2065)
			24	4	36	700	(70)	(515)
26	Signal control valve mounting bolt		10	4	8 Holes	50	(5.1)	(37)
27	Front pin-retaining bolt		20	24	30	400	(41.0)	(295)
	Front pin-retaining nut		20	7	30	400	(41.0)	(295)

-  **NOTE:** 1. Apply lubricant (e.g. white zinc B dissolved into spindle oil) to bolts and nuts to reduce friction coefficient of them.
2. Make sure bolt and nut threads are clean before installing.

GENERAL / Tightening

TORQUE CHART


CAUTION: Use tools appropriate for the work to be done. Makeshift tools and procedures can create safety hazards. For loosening and tightening nuts and bolts, use correct size tools. Otherwise, tightening tools may slip, potentially causing personal injury.



Bolt Types

Tighten nuts or bolts correctly to torque specifications. Make sure to employ correct bolts and tighten them correctly when assembling the machine or components.

SA-040



W162-01-01-001

Specified Tightening Torque Chart

Bolt Dia.	Wrench Size	Hexagon Wrench Size	10.9			8.8			Socket Bolt		
			N-m	(kgf.m)	(lbf.ft)	N-m	(kgf.m)	(lbf.ft)	N-m	(kgf.m)	(lbf.ft)
M6	10	5							3.3 to 4.2	(0.3 to 0.4)	(2.4 to 3.0)
M8	13	6	30	(3.0)	(21.5)	20	(2.0)	(14.5)	10	(1.0)	(7.2)
M10	17	8	65	(6.5)	(47)	50	(5.0)	(36)	20	(2.0)	(14.5)
M12	19	10	110	(11)	(80)	90	(9.0)	(65)	35	(3.5)	(25.5)
M14	22	12	180	(18)	(130)	140	(14)	(101)	55	(5.5)	(40)
M16	24	14	270	(27)	(195)	210	(21)	(152)	80	(8.0)	(58)
M18	27	14	400	(40)	(290)	300	(30)	(215)	120	(12)	(87)
M20	30	17	550	(55)	(400)	400	(40)	(290)	170	(17)	(123)
M22	32		750	(75)	(540)	550	(55)	(400)	220	(22)	(159)
M24	36		950	(95)	(690)	700	(70)	(510)	280	(28)	(205)
M27	41		1400	(140)	(1010)	1050	(105)	(760)	400	(40)	(290)
M30	46		1950	(195)	(1410)	1450	(145)	(1050)	550	(55)	(400)
M33	50		2600	(260)	(1880)	1950	(195)	(1410)	750	(75)	(540)
M36	55		3200	(320)	(2310)	2450	(245)	(1770)	950	(95)	(690)

GENERAL / Tightening


IMPORTANT: The following items are applied to both fine and coarse pitch threads.

1. Apply lubricant (i. e. white zinc B dissolved into Spindle oil) to nuts and bolts to reduce their friction coefficients.
The plated bolts require no lubricant.
2. Torque tolerance is $\pm 10\%$.
3. Be sure to use bolts of correct length. Bolts that are too long cannot be tightened, as the bolt tip comes into contact with the bottom of the bolt hole. Bolts that are too short cannot develop sufficient tightening force.
4. The torques given in the chart are for general use only. Do not use these torques if a different torque is given for a specific application.
5. Make sure that nut and bolt threads are clean before installing.
Remove dirt or corrosion, if any.


Bolt Tightening Order

When tightening two or more bolts, tighten them alternately, as shown, to ensure even tightening.


Equally tighten upper and lower alternately



Tighten diagonally



Tighten from center and diagonally




W105-01-01-003

GENERAL / Tightening


Service Recommendations for Split Flange

- IMPORTANT:**
1. Be sure to clean and inspect sealing surfaces. Scratches / roughness cause leaks and seal wear. Unevenness causes seal extrusion. If defects cannot be polished out, replace the component.
 2. Be sure to use only specified O-rings. Inspect O-rings for any damage. Take care not to file O-ring surfaces. When installing an O-ring into a groove, use grease to hold it in place.
 3. While lightly tightening split flange halves, check that split is centered and perpendicular to the port. Hand-tighten bolts to hold parts in place. Take care not to pinch the O-ring.
 4. Tighten bolts alternately and diagonally, as shown, to ensure even tightening.
 5. Do not use air wrenches. Using an air wrench often causes tightening of one bolt fully before tightening of the others, resulting in damage to O-rings or uneven tightening of bolts.




W105-01-01-015

WRONG




W105-01-01-016




W105-01-01-008

RIGHT



Bend along edge sharply

WRONG



Do not bend it round

Nut and Bolt Locking

- Lock Plate

IMPORTANT: Do not reuse lock plates. Do not try to bend the same point twice.


- Cotter Pin

IMPORTANT: Do not reuse cotter pins. Match the holes in the bolt and nut while tightening, not while loosening.


- Lock Wire

IMPORTANT: Apply wire to bolts in the bolt-tightening direction, not in the bolt-loosening direction. Do not reuse lock wires.


RIGHT




RIGHT



WRONG




Bend along edge sharply



W105-01-01-009


RIGHT




RIGHT



WRONG




RIGHT



Tighten

Loosen

WRONG



W105-01-01-010


GENERAL / Tightening

PIPING JOINT


IMPORTANT: The torques given in the chart are for general use only. Do not use these torques if a different torque is given for a specific application.

Union Joint

Metal sealing surfaces (4) and (5) of adapter (1) and hose (2) fit together to seal pressure oil. Union joints are used to join small-diameter lines.



- IMPORTANT:**
1. Do not over-tighten union nut (3). Excessive force will be applied to metal sealing surfaces (4) and (5), possibly cracking adapter (1). Be sure to tighten union nut (3) to specifications.
 2. Scratches or other damage to sealing surfaces (4) or (5) will cause oil leakage at the joint. Take care not to damage them when connecting/disconnecting.



Description	Wrench Size mm	Wrench Size mm	Tightening Torque N-m (kgf-m, lbf-ft)
	Union Nut	Joint Body	
30° male	17	17	24.5 (2.5,18)
	19	19	29.5 (3.0, 21.5)
	22	22	39 (4.0, 28.5)
	27	27	78 (8.0, 58)
	32	32	137 (14.0,101)
	36	36	175 (18.0,129)
37° female	17	14	24.5 (2.5,18)
	19	17	29.5 (3.0, 21.5)
	22	19	39 (4.0, 28.5)
	27	22	78 (8.0, 58)
	32	27	137 (14.0,101)
	36	32	175 (18.0,129)
	41	36	205 (21.0,151)


NOTE: Tightening torque of 37° male coupling without union is similar to tightening torque of 37° female.

GENERAL / Tightening

O-ring Seal Joint

O-ring (6) seats against the end surface of adapter (7) to seal pressure oil.

- IMPORTANT:**
1. Be sure to replace O-ring (6) with a new one when reconnecting.
 2. Before tightening union nut (9), confirm that O-ring (6) is seated correctly in O-ring groove (8). Tightening union nut (9) with O-ring (6) displaced will damage O-ring (6), resulting in oil leakage.
 3. Take care not to damage O-ring groove (8) or sealing surface (10).
Damage to O-ring (6) will cause oil leakage.
 4. If union nut (9) is loose and oil is leaking, do not re-tighten union nut (9). Replace O-ring (6) with a new one and check that O-ring (6) is correctly seated in place, tighten union nut (9).




Wrench Size mm	Wrench Size mm	Tightening Torque
Union Nut	Joint Body	N·m (kgf·m, lbf·ft)
19	17	29.5 (3.0, 21.5)
22	19	69 (7.0, 51)
27	22	93 (9.5, 69)
32	27	137 (14.0, 101)
36	30,32	175 (18.0, 129)
41	36	205 (21.0, 151)
46	41	205 (21.0, 151)

GENERAL / Tightening

Screw-In Connection

Depending on types of screw and sealing, different types of screw fittings are used.

IMPORTANT: Be sure to confirm that the thread pitch and thread type (tapered or straight) are the correct type before using any screw-in connection.



W105-01-01-018

Male Tapered Thread		
Wrench Size mm	Tightening Torque N·m (kgf·m, lbf·ft)	
Joint Body	FC material	SS material
19	14.5 (1.5, 10.5)	34 (3.5, 25)
22	29.5 (3.0, 21.5)	49 (5.0, 36)
27	49 (5.0, 36)	93 (9.5, 69)
36	69 (7.0, 51)	157 (16, 116)
41	108 (11, 80)	205 (21, 151)
50	157 (16, 116)	320 (33, 235)
60	195 (20, 144)	

Seal Tape Application

Seal tape is used to seal clearances between male and female threads, so as to prevent any leaks between threads.

Be sure to apply just enough seal tape to fill up thread clearances. Do not overwrap.

- Application Procedure

Confirm that the thread surface is clean and, free of dirt or damage.


Apply seal tape around threads as shown. Wrap seal tape in the same direction as the threads.

Low-Pressure-Hose Clamp Tightening Torque

Low-pressure-hose clamp tightening torque differs depending on the type of clamp.


T-Bolt Type Band Clamp:
4.4 N·m (0.45 kgf·m, 3.25 lbf·ft)

Worm Gear Type Band Clamp:
5.9 to 6.9 N·m (0.6 to 0.7 kg·m, 4.3 to 5.1 lbf·ft)




W105-01-01-019

Leave one to two pitch threads uncovered



M114-07-041



M114-07-043

M114-07-042

GENERAL / Tightening

Connecting Hose




CAUTION: When replacing hoses, be sure to use only genuine Hitachi service parts. Using hoses other than genuine Hitachi hoses may cause oil leaks, hose rupture or Separation of fitting, possibly resulting in a fire on the machine.

Do not install hoses kinked. Application of high oil pressure, vibration, or an impact to a kinked hose may result in oil leaks, hose rupture or separation of fitting. Utilize Print marks on hoses when installing to prevent hose from being kinked.


If hoses rub against each other, wear to the hoses will result, leading to hose rupture. Take necessary measures to protect hoses from rubbing against each other.

Take care so that hoses do not come into contact with moving parts or sharp objects.

WRONG




RIGHT




W105-01-01-011

WRONG




RIGHT




W105-01-01-012

WRONG




RIGHT




W105-01-01-013

WRONG




RIGHT



W105-01-01-014

SECTION 2 UPPERSTRUCTURE



— CONTENTS —

Group 1 Cab

Remove and Install Cab	W2-1-1
Dimensions of Cab Glass	W2-1-8
Remove and Install Cab Glass	W2-1-12

Group 2 Counterweight

Remove and Install Counterweight	W2-2-1
--	--------

Group 3 Main Frame

Remove and Install Main Frame	W2-3-1
-------------------------------------	--------

Group 4 Pump Device

Remove and Install Pump Device	W2-4-1
Disassemble Pump Transmission	W2-4-14
Assemble Pump Transmission	W2-4-18
Disassemble Main Pump	W2-4-22
Assemble Main Pump	W2-4-26
Disassemble Main Regulator	W2-4-32
Assemble Main Regulator	W2-4-38
Disassemble Fan Pump	W2-4-44
Assemble Fan Pump	W2-4-48
Disassemble Fan Regulator	W2-4-52
Assemble Fan Regulator	W2-4-54
Maintenance Standard	W2-4-58
Structure of Pilot Pump	W2-4-60
Structure of Solenoid Valve	W2-4-62

Group 5 Control Valve

Remove and Install Control Valve	W2-5-1
Disassemble Control Valve (4-Spool Housing Side)	W2-5-4
Assemble Control Valve (4-Spool Housing Side)	W2-5-10
Disassemble Control Valve (5-Spool Housing Side)	W2-5-16
Assemble Control Valve (5-Spool Housing Side)	W2-5-20
Disassemble Control Valve (4-Spool Housing Upper and Lower Surfaces)	W2-5-26
Assemble Control Valve (4-Spool Housing Upper and Lower S Surfaces)	W2-5-32
Disassemble Control Valve (5-Spool Housing Upper and Lower Surfaces)	W2-5-40
Assemble Control Valve (5-Spool Housing Upper and Lower Surfaces)	W2-5-48
Disassemble Control Valve (4-Spool Control Valve)	W2-5-56
Assemble Control Valve (4-Spool Control Valve)	W2-5-60
Disassemble Control Valve (5-Spool Control Valve)	W2-5-62
Assemble Control Valve (5-Spool Control Valve)	W2-5-66
Disassemble Control Valve (Housing Front and Rear Sides)	W2-5-68
Assemble Control Valve (Housing Front and Rear Sides)	W2-5-70
Disassemble Housing	W2-5-72
Assemble Housing	W2-5-74

Group 6 Swing Device

Remove and Install Swing Device.....	W2-6-1
Disassemble Swing Device.....	W2-6-4
Assemble Swing Device.....	W2-6-14
Disassemble Swing Motor	W2-6-24
Assemble Swing Motor	W2-6-28
Maintenance Standard	W2-6-32

Group 7 Pilot Valve

Remove and Install Pilot Valve.....	W2-7-1
Disassemble Right and Left Pilot Valves	W2-7-18
Assemble Right and Left Pilot Valves	W2-7-22
Disassemble Travel Pilot Valve	W2-7-26
Assemble Travel Pilot Valve.....	W2-7-30

Group 8 Pilot Shut-Off Solenoid Valve

Remove and Install Pilot Shut-Off Solenoid Valve	W2-8-1
Structure of Pilot Shut-Off Solenoid Valve	W2-8-3

Group 9 Solenoid Valve

Remove and Install Solenoid Valve.....	W2-9-1
Structure of Solenoid Valve	W2-9-3
Disassemble and Assemble Proportional Solenoid Valve	W2-9-4

Group 10 Signal Control Valve

Remove and Install Signal Control Valve	W2-10-1
Structure of Signal Control Valve.....	W2-10-3

Group 11 Shockless Valve

Remove and Install Shockless Valve ...	W2-11-1
Structure of Shockless Valve.....	W2-11-3

Group 12 Fan Valve

Remove and Install Fan Valve	W2-12-1
Structure of Fan Valve	W2-12-4

Group 13 Fan Motor

Remove and Install Fan Motor.....	W2-13-1
Structure of Fan Motor	W2-13-12

Group 14 Engine

Remove and Install Engine.....	W2-14-1
--------------------------------	---------

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**