

PERIODIC MAINTENANCE

**H40.00-52.00XM-16CH
(H1050HD-CH, 1150HD-CH) [F117];
H40.00-48.00XM-12
(H800-1050HD/HDS) [A917]**

HYSTER

TABLE OF CONTENTS

General	1
Serial Number Data	1
How to Move Disabled Lift Truck	1
How to Tow Lift Truck	2
How to Put Lift Truck on Blocks	2
How to Raise Drive Tires	2
How to Raise Steering Tires	3
Maintenance Schedule	4
Spreader Maintenance	14
Maintenance Procedures Every 8 Hours or Daily	15
How to Make Checks With the Engine Stopped	15
Safety Labels	15
Operator Restraint System	16
Safety Belt and Seat Rails	16
Steering Column Latch	16
Tires and Wheels	16
Forks	17
Adjust	17
Remove	17
Low Mount Forks, Install	17
Forks, Mast, and Lift Chains, Inspect	18
Drive Belt	19
Crankcase Breather Tube	19
Air Intake Piping and Charge Air Piping	19
Cooling Fan	20
Pre-Cleaner for Air Filter	20
Fuel, Oil, or Coolant Leaks	21
Hydraulic Tank Breather	21
Engine Oil	21
Hydraulic System Oil	22
Hydraulic High Pressure Oil Filter	22
Battery	23
Fuel Filter/Water Separator	23
Cooling System	24
How to Add Fuel to Lift Truck	25
How to Make Checks With Engine Running	25
Gauges, Lights, Horn, Fuses, and Relays	25
Sealed Fuses	28
Transmission Oil	28
Engine Air Filter	28
Engine Oil Pressure	29
Electrical System	29
Steering System	29
Service Brakes	29
Parking Brake	29
Control Levers and Pedals	29
Lift System Operation	29
Attachments	30
First Inspection After First 100 Hours of Operation	30
Engine Oil Filter	30
Drive Axle and Differential	30

TABLE OF CONTENTS (Continued)

Lift Chains	30
Transmission Oil Filter	30
Air Conditioning	30
Steer Wheel Hubs	30
Maintenance Procedures Every 250 Hours Or Monthly	31
Transmission Oil Filter	31
Twist Locks (F117 Only).....	31
Gantry Carriage and Container Attachments (F117 Only).....	31
Maintenance Procedures Every 500 Hours or 3 Months	31
Drive Belt	31
Lift Chains	31
Hydraulic Return Line Oil Filter.....	32
Air Conditioning	32
Wheel Nuts.....	32
Heater Air Filter.....	32
Steering Axle Kingpins	32
Steering Axle Tie Rods	33
Drive Shaft.....	33
Steering Axle Pivots	33
Mast and Carriage Load Rollers	33
Mast Pivots, Sliding Surfaces	33
Sideshift Carriage.....	33
Maintenance Procedures Every 500 Hours or 6 Months	34
Fuel Filter	34
Engine Oil and Filter.....	34
Oil Filter for Oil-Cooled Brakes (Brake Filter).....	34
Transmission Oil.....	34
Change	34
Maintenance Procedures Every 1000 Hours or 6 Months	35
Drive Axle and Differential Oil.....	35
Service Brake System.....	35
Brake System Accumulator	35
Hub Bearings, Steer Wheels	35
General Lubrication	35
Maintenance Procedures Every 1500 Hours or 1 Year	35
Engine	35
Water Pump	35
Turbocharger.....	36
Engine Mounting Bolts	36
Air Leaks, Air Intake and Exhaust	37
Valve and Injector Adjustments.....	38
General.....	38
Adjust.....	39
Injector Adjustment	39
Valve Adjustment.....	40
Maintenance Procedures Every 2000 Hours or 1 Year	42
Parking Brake Assembly.....	42
Clean	42
Inspect.....	42
Maintenance Procedures Every 3000 Hours or 18 Months	44
Hydraulic Suction Oil Filters.....	44

TABLE OF CONTENTS (Continued)

Maintenance Procedures Every 5000 Hours	44
Container Attachment (F117)	44
Maintenance Procedures Every 6000 Hours or 2 Years.....	44
Vibration Damper	44
Fan Drive Idler Pulley.....	45
Fan Hub	46
Turbocharger.....	46
Cooling System Fluid	46
Maintenance Procedures Every 10,000 Hours or 5 Years.....	47
High Pressure Hydraulic Oil Filter	47
Safety Procedures When Working Near Mast.....	48
Lift and Tilt System Leaks Check.....	49
Lift System.....	49
Tilt System	49
Pneumatic Tires and Wheels.....	50
Remove Wheels From Lift Truck	50
Remove Tire From Wheel.....	50
Remove Tire From Five-Piece Wheel	51
Install Tire on Wheel.....	52
Install Tire on Five-Piece Wheel	53
Add Air Pressure to Tires.....	54
Install Wheels on Lift Truck	55

This section is for the following models:

H40.00-52.00XM-16CH (H1050HD-CH, 1150HD-CH) [F117];
H40.00-48.00XM-12 (H800-1050HD/HDS) [A917]

(More Content includes: Brake system, Capacities, and specifications, Frame, Hydraulic, System, Industrial battery, Main control, Valve, Mast repair, Fasteners, Schematics diagrams, Steering axle, Steering system, Wire harness repair And more)

Click Here

**Get all the content
after purchase**

**Thank you very
much.**

General

This section contains a Maintenance Schedule and the instructions for maintenance and inspection.

The Maintenance Schedule has time intervals for inspection, lubrication, and maintenance for your lift truck.

The recommendation for the time intervals are for 8 hours of operation per day. The time intervals must be decreased from the recommendations in the Maintenance Schedule for the following conditions:

- If the lift truck is used more than 8 hours per day.
- If the lift truck must work in dirty operating conditions.

Your dealer for Hyster lift trucks has the equipment and trained personnel to do a complete program of inspection, lubrication, and maintenance. A regular program of inspection, lubrication, and maintenance will help your lift truck give more efficient performance and operate for a longer period of time.



WARNING

Do not make repairs or adjustments unless you have both authorization and training. Repairs and adjustments made on a lift truck by people without authorization and training can make a dangerous operating condition.

Do not operate a lift truck that needs repairs. Report the need for repairs immediately. If repair is necessary, put a DO NOT OPERATE tag in the operators area. Remove the key from the key switch.

Some users have service personnel and equipment to do the inspection, lubrication and maintenance shown in the Maintenance Schedule. Service Manuals are available from your dealer for Hyster lift trucks to help users who do their own maintenance.

SERIAL NUMBER DATA

The serial number for the lift truck is on the nameplate and also on the right hand frame rail, near the counterweight. The serial number indicates the design series, manufacturing plant, and the year manufactured.

Example:	F117	E	4369	A
	(1)	(2)	(3)	(4)

(1) The first letter and number of the serial number indicates the design series and the model number of the lift truck.

(2) The second letter identifies the manufacturing plant.

Examples:

D = Danville, IL U.S.A.

E = Nijmegen, The Netherlands

(3) The number series indicates the sequence of manufacture where the lift truck was made.

(4) The letter indicates the year of manufacture starting with A=2003. The letter B=2004 and so on.

HOW TO MOVE DISABLED LIFT TRUCK

The service brake system requires hydraulic pressure to operate. The park brake will automatically apply when hydraulic pressure drops. If there is no hydraulic pressure to release the parking brake, the parking brake caliper must be manually released. Put blocks on both sides (front and back) of the drive tires to prevent movement of the lift truck. The parking brake caliper is installed at the back of the differential housing. To manually release the parking brake, remove cotter pin from bolt in caliper. Tighten nut to compress spring that applies brake.

NOTE: If there is no hydraulic pressure to release the parking brake, the parking brake caliper must be manually released. Put blocks on both sides, front and rear, of the drive tires to prevent movement of the lift truck. To manually release the parking brake, remove the cotter pin and tighten the nut to compress the spring that applies the brake.

How to Tow Lift Truck



WARNING

Use extra caution when moving a lift truck if any of the following conditions exist:

- Brakes do not operate correctly.
- Steering does not operate correctly.
- Tires are damaged.
- Traction conditions are bad.
- The lift truck must be towed on a slope.

If the engine cannot run, there is no power assist available for the steering and service brakes. This can make the control of the lift truck difficult. Poor traction can cause the disabled lift truck or towing vehicle to slide. Steep grades will increase the required brake effort.

Never lift and move a disabled lift truck unless the disabled lift truck **MUST** be moved and cannot be towed. A lift truck used to move a disabled lift truck **MUST** have a capacity rating equal to or greater than the weight of the disabled lift truck. The capacity of the lift truck used to move a disabled lift truck must have a load center equal to half the width of the disabled lift truck. See the nameplate of the disabled lift truck for the approximate total weight. The forks must extend the full width of the disabled lift truck. Put the weight center of the disabled lift truck on load center of the forks. Be careful to not damage the under side of the lift truck.

1. The towed lift truck must have an operator.
2. Tow the lift truck slowly.
3. Using a lift truck or a lifting device that can be attached to the mast (I.E. come-a-long), raise the carriage and forks approximately 30 cm (12 in.) from surface. Install a chain around the mast crossmember and the carriage, to prevent carriage and mast channels from moving.
4. If another lift truck is used to tow the disabled lift truck, that lift truck must have an equal or larger capacity than the disabled lift truck. Install an approximate half-capacity load on the forks of the lift truck that is being used to tow the disabled lift truck. This half-capacity load will increase the traction of the lift truck. Keep the load as low as possible.

5. Use a towing link made of steel that attaches to the tow pins in the counterweights of both lift trucks.

HOW TO PUT LIFT TRUCK ON BLOCKS

How to Raise Drive Tires



WARNING

The lift truck must be put on blocks for some types of maintenance and repair. The removal of the following assemblies will cause large changes in the center of gravity: drive axle, engine and transmission, and the counterweight. When the lift truck is put on blocks, put additional blocks in the following positions to maintain stability:

- a. Before removing the mast and drive axle, put blocks under the counterweight so that the lift truck cannot fall backward.
- b. Before removing the counterweight, put blocks under the mast assembly so that the lift truck cannot fall forward.

The surface must be solid, even, and level when the lift truck is put on blocks. Verify that any blocks used to support the lift truck are solid, one piece units. Put a steel plate on top of the block.


NOTE: Some lift trucks have lifting eyes. These lift points can be used to raise the lift truck so that blocks can be installed.

NOTE: The lifting eyes of the counterweight are for lifting of the counterweight only. Never use the lifting eyes or the counterweight to lift the truck.

1. Put blocks on each side (front and back) of the steering tires to prevent movement of the lift truck. See Figure 1 and Figure 2.
2. Put the mast in a vertical position. Put a block under each outer mast channel.
3. Tilt the mast fully forward until the drive tires are raised from the surface.
4. Put additional blocks under the frame behind the drive tires.
5. If the hydraulic system will not operate, use a hydraulic jack under the side of the frame near the drive axle. Verify that the jack has a capacity of at least half the weight of the lift truck. See the nameplate.

How to Raise Steering Tires

1. Apply the parking brake. Put blocks on both sides (front and back) of the drive tires to prevent movement of the lift truck. See Figure 1 and Figure 2.
2. Use a hydraulic jack to raise the steering tires. Verify that the jack has a capacity of at least $\frac{2}{3}$ of the weight of the lift truck. See the nameplate.
3. Put the jack under the steering axle or frame to raise the lift truck. Put blocks under the frame to support the lift truck.




HM211788

1. STEER AXLE/STEER TIRES

2. DRIVE AXLE/DRIVE TIRES

Figure 1. Put Lift Truck on Blocks (F117)



HM212383

1. STEER AXLE/STEER TIRES

2. DRIVE AXLE/DRIVE TIRES

Figure 2. Put Lift Truck on Blocks (A917)

Maintenance Schedule

NOTE: Portions reproduced by permission of Cummins Inc.




Figure 3. Maintenance Points (F117) (Sheet 1 of 2)






Figure 3. Maintenance Points (F117) (Sheet 2 of 2)



HM212384

Figure 4. Maintenance Points (A917) (Sheet 1 of 2)



HM212385

Figure 4. Maintenance Points (A917) (Sheet 2 of 2)