

## Technical Manual

John Deere JD670 Motor Grader

TM-1134



ı

Group 0422 - Starting System

.... . ....

Group 0433 - Flywheel, Housing and Fasteners Group 0499 - Specifications and Special Tools

#### SECTION AND GROUP CONTENTS OF THIS MANUAL

SECTION I - GENERAL INFORMATION	SECTION 5 - ENGINE AUXILIARY SYSTEMS Group 0505 - Cold Weather Starting Aids
Group I - Contents, Index and Page List	Group 0510 - Engine Cooling Systems
Group II - Introduction and Safety Information	Group 0515 - Speed Controls
Group III - General Specifications	Group 0520 - Intake System
Group IV - Predelivery, Delivery and After-Sale	Group 0560 - External Fuel Supply Systems
Services	Group 0599 - Specifications and Special Tools
Group V - Lubrication	
SECTION 1 - WHEELS AND TIRES	SECTION 8 - TRANSFER DRIVE
Group 0110 - Powered Wheels, Tires and Fas-	Group 0841 - Housings and Covers
tenings	Group 0851 - Gears, Shafts and Bearings
Group 0120 - Non-Powered Wheels, Tires and	Group 0899 - Specifications and Special Tools
Fastenings	SECTION 9 - STEERING SYSTEM
Group 0199 - Specifications and Special Tools	Group 0960 - Power Steering
SECTION 2 - AXLES AND SUSPENSION	Group 0999 - Specifications and Special Tools
SYSTEMS	
Group 0201 - Drive Axle Housings	SECTION 10 - SERVICE BRAKES
Group 0210 - Differential	Group 1011 - Service Brakes Active Elements
Group 0230 - Non-Powered Wheel Axles	Group 1015 - Controls Linkage
Group 0250 - Axle Shaft, Bearings and Reduction	Group 1066 - Brakes Hydraulics
Gears	Group 1099 - Specifications and Special Tools
Group 0299 - Specifications and Special Tools	SECTION 11 - PARKING-EMERGENCY BRAKES
	Group 1111 - Parking Brake Active Elements
SECTION 3 - TRANSMISSION	Group 1115 - Controls Linkage
Group 0315 - Controls	Group 1199 - Specifications and Special Tools
Group 0341 - Housings and Covers	SECTION 15 - EQUIPMENT ATTACHING
Group 0350 - Gears, Shafts, Bearings and Power Shift Clutch	Group 1511 - Drawbar
Group 0360 - Transmission Hydraulics	
Group 0370 - Clutch Disconnect and Controls	SECTION 16 - ELECTRICAL SYSTEMS
Group 0399 - Specifications and Special Tools	Group 1671 - Batteries, Support and Cables
Gloup 6033 - Openingations and openial roots	Group 1672 - Alternator, Regulator and Charging
SECTION 4 - ENGINES	System Wiring
Group 0400 - Removal and Installation	Group 1673 - Vehicle Lighting System
Group 0401 - Crankshaft and Main Bearings	Group 1674 - Wiring Harness and Switches
Group 0402 - Camshafts and Valve Actuating	Group 1675 - Automatic Control Systems and
Means	Controls
Group 0403 - Connecting Rods and Pistons	Group 1676 - Instrument and Indicators Group 1699 - Specifications and Special Tools
Group 0404 - Cylinder Block	
Group 0407 - Engine Oiling System	SECTION 17 - FRAME, CHASSIS OR SUPPORT-
Group 0408 - Ventilating System	ING STRUCTURE
Group 0409 - Cylinder Head and Valves	Group 1740 - Frame Installation
Group 0410 - Exhaust Manifold Group 0413 - Fuel Injection System	Group 1746 - Bottom Guards
Group 0413 - Fuel Injection System  Group 0414 - Intake Manifold	Group 1799 - Specifications and Special Tools
Group 0414 - Intake Manifold Group 0416 - Turbocharger	
Group 0417 - Valer Pump	
Group 0418 - Thermostats, Housings and Piping	
Group 0419 - Engine Oil Cooler	
Group 0420 - Fuel Filter and Primer Pump	
Group 0421 - Fuel Transfer Pump	

#### SECTION AND GROUP CONTENTS OF THIS MANUAL—Continued

**SECTION 18 - OPERATOR'S STATION** 

Group 1806 - Safety Equipment

Group 1808 - Comfort and Convenience Items

Group 1810 - Operator Enclosure

Group 1821 - Seat

Group 1830 - Heating

Group 1899 - Specifications and Special Tools

SECTION 19 - SHEET METAL

Group 1910 - Hood or Engine Enclosure

Group 1921 - Grille and Grille Housing

SECTION 21 - MAIN HYDRAULIC SYSTEM

Group 2160 - Hydraulic System

Group 2199 - Specifications and Special Tools

**SECTION 34 - GRADING DEVICE** 

Group 3401 - Blade

Group 3415 - Controls Linkage

Group 3440 - Grading Device Frames

Group 3450 - Circle Gear Box

Group 3460 - Hydraulic System

Group 3499 - Specifications and Special Tools

SECTION 42 - GROUND CONDITIONING TOOLS

Group 4201 - Teeth and Shanks

Group 4215 - Controls Linkage

Group 4240 - Frames

Group 4260 - Hydraulic System

Group 4299 - Specifications and Special Tools

SECTION 90 - SYSTEM TESTING

Group 9005 - General Information - Seven Basic Steps of Testing and Diagnosis

Group 9010 - Engine

Group 9015 - Electrical System

Group 9020 - Power Train

Group 9025 - Hydraulic System

Group 9030 - Miscellaneous Components

Group 9032 - Automatic Blade Control

Group 9035 - Specifications and Special Tools

## MAINTENANCE WITHOUT ACCIDENT WORK SAFELY




This safety alert symbol identifies important safety messages in this manual and on the motor grader. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

## EVERY EMPLOYER HAS A SAFETY PROGRAM. KNOW WHAT IT IS!



Consult your shop foreman for specific instructions on a job, and the safety equipment required.

For instance, you may need: Hard hat, safety shoes, safety goggles, heavy gloves, reflector vests, ear protectors, respirators.



#### **BE ALERT!**

Plan ahead—work safely—know how to use a first-aid kit and a fire extinguisher—and where to get aid and assistance.



#### Maintenance Area


Make sure the maintenance area is adequately vented.

Keep maintenance area CLEAN AND DRY. Oily and wet floors are slippery; greasy rags are a fire hazard; wet spots are dangerous when working with electrical equipment.

Store starting aids in a cool and well-ventilated place, out of the reach of unauthorized personnel.

#### MAINTENANCE WITHOUT ACCIDENT

## AVOID FIRE HAZARDS—Fuel Is Dangerous!



Don't smoke while refueling.

Don't smoke while handling highly flammable material.

Engine should be shut off when refueling.

Use care in refueling if the engine is hot.

Don't use open pans of gasoline or diesel fuel for cleaning parts. Good commercial, nonflammable solvents are preferred.

#### Battery Gas Is Highly Flammable!

Provide adequate ventilation when charging batteries.



Don't check battery charge by placing metal objects across the posts.

Don't allow sparks or open flame near batteries. Don't smoke near battery.

#### Flame Is Not a Flashlight!

NEVER USE OPEN FLAME AROUND THE MA-CHINE.


KNOW WHERE FIRE EXTINGUISHERS ARE KEPT!

### UNDER ALL MAINTENANCE CONDITIONS—

Do not perform any work on the equipment unless authorized to do so. Then be sure you know the safe and proper procedure.

Follow recommended procedures.

Never service the equipment while it is being operated.



Avoid working on equipment with the engine running.

If it is necessary to make checks with the engine running, **ALWAYS USE TWO** service technicians—one, the operator, at the controls, the other checking within sight of the operator.

#### KEEP HANDS AWAY FROM MOVING PARTS

Support all raised equipment.

Never work under raised blade, ripper, or scarifier.

Lower all equipment to ground.


If the machine is on an incline, block it securely.

Use hoisting equipment for lifting heavy parts.

## TAKE CARE! WATCH OUT FOR OTHER PEOPLE IN THE VICINITY

Wear safety glasses when drilling, grinding, or hammering metal.

#### **SERVICING PRECAUTIONS**



Keep ALL equipment free of dirt and oil.

Be sure to clean any oil, grease, mud, ice, or snow from floor of operator's compartment, stepping points, and grab rails.

When preparing the engine for storage, remember that inhibitor is volatile and therefore dangerous. Seal and tape openings after adding the inhibitor. Keep container tightly closed when not in use

Don't remove the radiator cap until coolant temperature is below the boiling point. Then turn cap slightly to relieve pressure before removing.

Periodically check exhaust system for excessive leakage.

Relieve hydraulic pressure before working on hydraulic system: shut off engine, lower all equipment to ground, and move control levers until no response is felt.

When checking hydraulic pressure, be sure to use the correct test gauge.

#### PRECAUTIONS DURING REPAIR

Before working on hydraulic system relieve hydraulic pressure.


Before repairing the electrical system, or performing a major overhaul, disconnect batteries.

#### KNOW EQUIPMENT IS READY!

Check guards, safety bars—all protective devices installed on the grader. Every one should be in place and secure.

#### **CHECK IT OUT!**

- ☐ GUARDS
- ☐ SHIELDS
- ☐ PROTECTIVE DEVICES
- ☐ SEAT BELTS, ETC.



T38243N

Carefully inspect equipment for visual defects—leaks in fuel, lubrication, and hydraulic systems. Do not search for pressurized fluid leaks with your hands. Use cardboard or wood to search for leaks.


# Group III GENERAL SPECIFICATIONS

(Specifications and design subject to change without notice. Wherever applicable, specifications are in accordance with SAE Standards. Except where otherwise noted, these specifications are based on a unit equipped with 13.00-24, 8 ply rating, tubeless tires, 12 ft. (3.66 m) moldboard and standard equipment.)

Power @ 2300	Travel Speeds (2,300 engi	ne rpm, no tire s	slip):
engine rpm: SAE		•	• •
Gross	Shift Lever Position	mph	km/h
Net125 (93.2 kW*) 126.7 PS	Forward 1	2.3	3.6
	2	3.2	5.1
Net engine flywheel power is for an engine equipped	3	4.8	7.8
with fan, air cleaner, water pump, lubricating-oil pump,	4	6.3	10.1
fuel pump, alternator, and muffler. Gross engine power	5	8.2	13.2
is without fan. Gross and net flywheel power ratings	6 .	10.5	17.0
are under SAE standard conditions of 500 ft. (152 m)	7	14.1	22.8
altitude and 85°F (29°C) temperature and DIN 70 020	8	23.9	38.4
standard conditions (non-corrected). No derating is	Reverse 1	2.8	4.5
required up to 10,000 ft. (3000 m).	2	3.9	6.3
	3	5.9	9.5
*In the international system of units (SI), power is	4	7.6	12.3
expressed in kilowatts (kW).			
	Brakes:		
Engine: John Deere turbocharged diesel, vertical	Service Fo		•
6-cylinder, valve-in-head, 4-stroke cycle.	ac	tuated, wet-disk,	
Bore and stroke 4.19 x 5 in. (106.5 x 127 mm)		on 4 tandem	n wheels
Piston displacement 414 cu. in. (6 784 cm³)	Parking Foot-o		
Compression ratio	disk effec	tive on 4 tandem	wheels
Maximum torque @ 1300 rpm372 lb-ft	- ·		
(504 Nm)	Steering:		
NACC or AMA (U.S. Tax) horsepower 42.1	Front Ful		
Main bearings 7	Range		
Lubrication Pressure system with full-flow filter	Rear Hydr		
Cooling Pressurized with thermostat and fixed		ing (25 deg. left	
bypass	Turning radius	22 ft.	(6.7 m)
Fan Suction	Liveline die Coetens Cleaned		
Air cleaner with restriction indicator Dry	Hydraulic System: Closed-o		155 haw
Electrical system 24 volt (24 V) with alternator	Standby pressure		
Batteries (2) 12 volt Reserve capacity:	Pump Varial		
180 minutes each	Circle: Welded angle, 4 ft.	nin.) @ 2,300 eng	
Transmission Power Shift, 8 forward and 4	Rotation		
reverse selections	Drive Hydrau		
Differential Lock Foot-operated, hydraulically-	Dilve	ne motor and we	ını yedi
actuated Final DrivesInboard planetary	Drawbar W	elded box 3.5x7x	(0.38 in
i mai brives mboard planetary		mm) wall, with	
	(55	*	ket pivot
		000,	p

, , , , , , , , , , , , , , , , , , ,		
Blade:	Rear Drive Axle: Full floating with tapered roller bear-	
Length	ings	
Height	Diameter at bearings 3.35 in. (85 mm)	
Thickness 0.88 in. (22 mm)	Tires 13.00 - 24, 8, 10 and 12 ply-rating	
	8 in. (203 mm) rim	
Blade Lifting Mechanism:	14.00 - 24, 10 and 12 ply-rating	
Control Dual lever, hydraulic	8 or 10 in. (203 or 254 mm) rim	
with float position	17.5 - 25 and 12 ply-rating	
Cylinders (2) 3.25 in. (82.6 mm) dia. bore;	14 in. (356 mm) rim	
44.87 in. (1.14 m) stroke	0	
Blade Range:	Scarifier (Special Equipment): V-type for 4 ft. (1.22	
Lift above ground 1 ft. 4.10 in. (409 mm)	m) cut with 3 manual pitch positions  Number of teeth	
Blade side-shift:	Lift above ground	
Right or left 2 ft. 2.9 in. (683 mm)	Penetration	
2 10 210 110 110 110 110 110 110 110 110	Shank size	
Shoulder reach outside wheels:	Charit 5/20 (120x 110 this (0.7) x 102 thin)	
Right or left	Ripper (Special Equipment): 8 ft. (2.44 m) cut width,	
Pitch	parallelogram linkage, 2 manual shank vertical posi-	
	tions.	
Lift arms:	Number of shank pockets	
Positions	Number of shanks 3	
Control Hydraulic, foot operated	Lift above ground14.5 in. (368 mm)	
France	Penetration	
Frame:	Shank size	
Rear main frame Welded box section from articulation joint to main frame arch	Lift above ground	
Top and bottom plate, width 8.25 in. (210 mm)	(shank in upper position)23.5 in. (597 mm)	
thickness 0.625 in. (15.9 mm)	Capacities: U.S. Liters	
Side plates, minimum height 13.15 in. (334 mm)	Fuel tank	
thickness 0.625 in. (15.9 mm)	Cooling system	
Weight per ft., min	Engine lubrication,	
Minimum vertical-section modulus 104.52 cu. in.	Including filter	
(1 713 cm³)	Transmission-hydraulic	
Front main frame Formed box section from main	system	
frame arch to front hood	Tandem housings (each) 4 gal. 15	
Width	Worm gearbox 3 qt. 2.8	
Height, min		
Thickness	SAE Operating On Front On Rear	
Minimum vertical section modulus 69.44 cu. in.	Weight Wheels Wheels Total	
(1 138 cm³)		
(	Standard 7,653 lb. 18,177 lb. 25,830 lb.	
Tandems: Welded steel box section 27 in. (686 mm) x	equipment . (3 471 kg) (8 245 kg) (11 716 kg)	
7.56 in. (192 mm)	Standard	
Drive2.00 in. (51 mm) pitch roller chain	equipment and 8,687 lb. 18,177 lb. 26,944 lb.	
Axle dia. at bearings 3.63 in. (92.2 mm)	scarifier (3 940 kg) (8 245 kg) (12 221 kg)	
3.35 in. (85.1 mm)	Standard (3 940 kg) (6 245 kg) (12 221 kg)	
ing the second of the second o	equipment,	
Front Axle: Fabricated steel box-frame with steel spin-	scarifier 7,970 lb. 21,474 lb. 29,444 lb.	
dles, tapered roller bearings	and ripper . (3 615 kg) (9 740 kg) (13 356 kg)	
Diameter at bearing seats 3.54 in. (90 mm)		
1.87 in. (48 mm)		
Total oscillation		

Wheel lean (either direction) ............................... 20 deg.



OVER-ALL DIMENSIONS
A. Length
B. Width (13.00 - 24 tires)
(Front and rear)7 ft. 10 in. (2.34 m)
Width (17.5 - 25 tires)
(Front and rear) 8 ft. 6 in. (2.59 m)
Width (14.00 - 24 tires)
(Front and rear)
C. Height (with Cab) 10 ft. 6 in. (3.2 m)
D. Height (without Cab - To
Top of Steering Wheel)88.4 in. (2.24 m)
E. Wheelbase
F. Blade base 8 ft. 4 in. (2.54 m)
G. Tandems (Center Line) 5 ft. 0.71 in. (1.54 m)
H. Height (Top Lift Cylinders) 8 ft. 9.3 in. (2.67 m)
J. Height (Top Pre-Cleaner) 93.75 in. (2.38 m)

#### Additional Standard Equipment:

Transistorized voltage regulator
Lights (2 white front with stop and taillight)
Mechanical hour meter
Cigar lighter
Horn
Deluxe seat
Front windshield wiper
Rear windshield wiper
Work lights (2 front and 2 rear floods)
Turn signals
Cold weather starting aid
Vandal protection

Gauges:
Transmission pressure
Water temperature
Transmission
temperature
Engine oil pressure
Transmission lube
Fuel
Pre-cleaner
ROPS with cab and seat
belt
12 ft. (3.66 m) moldboard
Engine side shields
Air filter indicator
Floor mat

#### OVER-ALL DIMENSIONS

K. Tread

with 14.00 - 24 tires..... 22.5 in. (571 mm)

Special Equipment:
Scarifier
Cab heater
Cab defroster fan
ROPS with canopy and
seat belt
Rear-mounted ripper with
drawbar hitch
Below-cab blade lights (2)
Reverse warning alarm
Tool box
Sound baffles for engine
side shields
Heavy-duty cutting edges

Coolant heater
Bench seat
2 ft. (610 mm)
 moldboard extensions,
 right or left
Engine disconnect
Overlay end bits
Transmission bottom
 guard
Drawbar hitch
3 in. (76 mm) seat belt
13 ft. (3.96 m) and 14 ft.
 (4.27 m) moldboards
Articulation indicator

# **BUY NOW**

Then Instant Download the Complete Manual Thank you very much!