

# 7000 Drawn and Conservation and 7100 Folding and Integral Max-Emerge® Planters



JOHN DEERE

## TECHNICAL MANUAL

7000 Drawn and Conservation and 7100 Folding and  
Integral Max-Emerge® Planters

TM1154 (01APR82) English

John Deere Harvester Works  
TM1154 (01APR82)

LITHO IN U.S.A.  
ENGLISH



# 7000 DRAWN AND CONSERVATION AND 7100 FOLDING AND INTEGRAL MAX-EMERGE® PLANTERS TECHNICAL MANUAL TM-1154 (Apr-82)

## CONTENTS—REPAIR SECTIONS

- |  |   |
|--|---|
| SECTION 10 - GENERAL   | SECTION 110 - PLANTING UNIT REPAIR  |
| Group 00 - Specifications  | Group 05 - Seed Metering Mechanisms   |
| Group 05 - Predelivery, Delivery Service, and<br>After-Sale Services | Group 10 - Seed Openers   |
| Group 10 - Lubrication   | Group 15 - Closing Wheels   |
| SECTION 70 - HYDRAULIC REPAIR  | SECTION 120 - DISK MARKER REPAIR  |
| Group 00 - Specifications  | Group 00 - Specifications   |
| Group 05 - 7000 Planter Systems (Excluding<br>Markers)               | Group 05 - Marker Actuator and Cables<br>(7000 and 7100 Integral Frame<br>Planters) |
| Group 10 - 7100 Planter Systems (Excluding<br>Markers)               | Group 10 - Marker Control (7100 Folding Planter)                                    |
| Group 15 - Marker Cylinders  | Group 15 - Marker Arms  |
| SECTION 100 - DRIVES REPAIR  |   |
| Group 00 - Specifications  |   |
| Group 05 - Drive Wheels  |   |
| Group 10 - Countershaft Drive System                                 |   |
| Group 15 - Seed Drive Transmission                                   |   |
| Group 20 - Dry Fertilizer Drive                                      |   |
| Group 25 - Liquid Fertilizer Drive                                   |   |

## CONTENTS—OPERATION AND TEST SECTIONS

- |   |  |
|---|--|
| SECTION 270 - HYDRAULIC OPERATION AND<br>TEST           | SECTION 320 - DISK MARKER OPERATION<br>AND TESTS                                 |
| Group 00 - Specifications                               | Group 00 - Specifications  |
| Group 05 - Operation                                    | Group 05 - Marker Actuator and Cables (7000 and<br>7100 Integral Frame Planters) |
| Group 10 - Testing                                      | Group 10 - Hydraulic Markers   |
| SECTION 310 - PLANTING UNITS OPERATION<br>AND TESTS     | Group 15 - Marker Disk   |
| Group 05 - Seed Metering Mechanisms                     |  |
| Group 10 - Seed Openers                                 |  |
| Group 15 - Closing Wheels                               |  |
| Group 20 - Checking Row Unit Meters<br>with Run-In Unit |  |
| Group 25 - Checking Population                          |  |

*All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*


*Because John Deere sells its products world-wide, U.S. units of measure are shown with their respective Metric equivalents throughout this technical manual. These equivalents are the SI (International System) Units of Measure.*

*NOTE: Monitor Section 130 and 330 have been removed from this manual. Refer to TM-1270 for ALL planter monitoring system information.*

Copyright © 1982  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
Previous Editions

Copyright © 1981 Deere & Company  
Copyright © 1980 Deere & Company  
Copyright © 1978 Deere & Company

## INTRODUCTION



*Use FOS Manuals for Reference*

This technical manual is part of a twin concept of service:

- **FOS Manuals—for reference**
- **Technical Manuals—for actual service**

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

*Fundamentals of Service (FOS) Manuals* cover basic theory of operation, *fundamentals* of trouble shooting, *general* maintenance, and *basic* types of failures and their causes. FOS Manuals are for training new people and for reference by experienced technicians.

*Technical Manuals* are concise service guides for a specific machine. Technical manuals are on-the-job guides containing only the vital information needed by an experienced technician.

**NOTE:** Whenever the service technician may need to refer to a FOS Manual for additional information, a specific manual, chapter and/or page number is given.




*Use Technical Manuals for Actual Service*

Some features of this technical manual:

- *Table of contents at front of manual*
- *Exploded views showing parts relationship*
- *Photos showing service techniques*
- *Specifications grouped for easy reference*

This technical manual was planned and written for you—an experienced technician. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.


 This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.


## SAFETY AND YOU



T27999N

### INTRODUCTION

 This safety alert symbol identifies important safety messages in this manual and on the planter. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.



T27504N

Be prepared if an accident or fire should occur. Know where the first aid kit and the fire extinguishers are located—know how to use them.

### SERVICE AREA

Keep the service area clean and dry. Wet or oily floors are slippery. Wet spots can be dangerous when working with electrical equipment.

Make sure the service area is adequately vented.

Be sure all electrical outlets and tools are properly grounded.

Use adequate light for the job at hand.

### SERVICE

Always lower the planter to the ground when not in use. Whenever possible, perform service work and adjustments with the planter on the ground.

Never clean, lubricate, or adjust a machine that is in motion.

## TRANSPORTING

Always lock markers in transport position before transporting the planter any considerable distance.

Stand clear of disk blade when raising or securing marker.

When transporting the planter on a smooth surface road, do not exceed maximum tractor transport speed. Reduce speed considerably when traveling over rough ground.

When transporting the planter on a road or highway at night or during the day, use accessory lights and devices for adequate warning to operators of other vehicles. In this regard, check local governmental regulations. Various safety lights and devices are available from your John Deere dealer.

## FLUIDS UNDER PRESSURE

Escaping fluid under pressure can have sufficient force to penetrate the skin, causing serious personal injury. Before disconnecting lines, be sure to relieve all pressure. Before applying pressure to the system, be sure all connections are tight and that lines, pipes and hoses are not damaged. Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than hands, to search for suspected leaks.

If injured by escaping fluid, see a doctor at once. Serious infection or reaction can develop if proper medical treatment is not administered immediately.

Always relieve pressure in the hydraulic system before working with hydraulic system components.

When checking hydraulic pressure, be sure to use the correct test gauge for the pressure in the particular system.

## PERSONAL SAFETY

RIGHT



H23440N

Always avoid loose clothing or any accessory—flopping cuffs, dangling neckties and scarves—that can catch in moving parts and put you out of work. Always wear your safety glasses while on the job.

# Section 10 GENERAL

## CONTENTS OF THIS SECTION

	Page		Page
GROUP 00 - SPECIFICATIONS		GROUP 05 - PREDELIVERY, DELIVERY	
Description .....	00-1	SERVICE, AND AFTER-SALE	
Serial Numbers .....	00-1	SERVICES	
Oil Capacity of Hydraulic Systems .....	00-2	Predelivery Service .....	05-1
Acres per Hour for Various		Delivery Service .....	05-5
Machine Sizes .....	00-3	After-Sale Services .....	05-5
		GROUP 10 - LUBRICATION	

## Group 00 SPECIFICATIONS

### DESCRIPTION

All Max-Emerge Planters have tubular steel frames. The 7000 4-row narrow, 4-row wide, and 6-row narrow machines have 5- x 7-inch (127 mm x 178 mm) frames; the 6-row wide, 8- and 12-row have 7- x 7-inch (178 x 178 mm) frames. The 7000 Conservation Planters and all 7100 Planters have 7- x 7-inch (178 mm x 178 mm) frames.

“Right-hand” and “left-hand” sides are determined by facing in the direction the planter will travel when in use.

### SERIAL NUMBERS




Fig. 1-Serial Number Plate Location

The 7000 or 7100 Max-Emerge Planter (except 22-inch row spacing) has a serial number located on the top right side of the seed drive transmission (Fig. 1).




Fig. 2-Serial Number Plate Location

On 7100 Integral Max-Emerge Planters with 22-inch row spacing, the serial number is located on the right hand side on the end of the frame (Fig. 2).

**OIL CAPACITY OF HYDRAULIC SYSTEMS**

(Quantities given represent volume of oil contained in planters raised to field transport position.)

**7000 Planters**

4-Row Narrow, 4-Row Wide, or 6-Row Narrow	-Includes a 3-1/2- x 8-inch (76.2 mm x 203.2 mm) tractor cylinder, marker cylinders, manifold, and all hoses	4 U.S. Pts.	(1.8 L)
6-Row Wide, 8-Row Narrow, or 8-Row Wide	-Includes master cylinder, slave cylinders, marker cylinders, manifolds, and all hoses	12 U.S. Pts.	(5.7 L)
12-Row Narrow	-Includes master cylinder, slave cylinders, marker cylinders, manifolds, and all hoses	16 U.S. Pts.	(7.6 L)

**7000 Conservation Planters**

4-Row, 30- to 40-inch (76 cm to 101 cm) Rows	-Includes wheel frame cylinders, marker cylinder, manifold and all hoses	6 U.S. Pts.	(2.9 L)
6-Row Narrow	-Includes wheel frame cylinders, marker cylinder, manifold and all hoses	11-1/2 U.S. Pts.	(5.4 L)
6-Row Wide, 8-Row Narrow	-Includes master cylinder, wheel frame cylinders, marker cylinder, manifold and all hoses	12 U.S. Pts.	(5.7 L)

**7100 Planters - Integral Frame**

4-Row Wide	-Equipped with markers	1 U.S. Pt.	(0.4 L)
	-Equipped with markers, single lift assist wheel, and hydraulic mast	5-1/2 U.S. Pts.	(2.7 L)
6-Row Narrow	-Equipped with markers	1 U.S. Pt.	(0.4 L)
	-Equipped with markers and single lift assist wheel	3-1/2 U.S. Pts.	(1.5 L)
	-Equipped with markers, single lift assist wheel, and hydraulic mast	6 U.S. Pts.	(2.9 L)
	-Equipped with markers and dual lift assist wheels	6-1/2 U.S. Pts.	(3.1 L)
6-Row Wide or 8-Row Narrow	-Equipped with markers, dual lift assist wheels, and hydraulic mast	8-1/2 U.S. Pts.	(4.0 L)
	-Equipped with markers	1 U.S. Pt.	(0.4 L)
8-Row Wide or 12-Row Narrow	-Equipped with markers and dual lift assist wheels	6-1/2 U.S. Pts.	(3.1 L)
	-Equipped with markers, dual lift assist wheels, and hydraulic mast	8-1/2 U.S. Pts.	(4.0 L)
	-Equipped with markers	2 U.S. Pts.	(0.9 L)
8-Row Wide or 12-Row Narrow	-Equipped with markers and dual lift assist wheels	7-1/2 U.S. Pts.	(3.5 L)
	-Equipped with markers, dual lift assist wheels, and hydraulic mast	9-1/2 U.S. Pts.	(4.4 L)
	-Equipped with markers	2 U.S. Pts.	(0.9 L)

**7100 Planters - Folding Frame**

8-Row Wide	-Equipped with markers	9-1/2 U.S. Pts.	(4.4 L)
	-Equipped with markers, single lift assist wheels, and hydraulic mast	14-1/2 U.S. Pts.	(6.8 L)
12-Row Narrow	-Equipped with markers	11-1/2 U.S. Pts.	(5.4 L)
	-Equipped with markers and dual lift assist wheels	17 U.S. Pts.	(8.0 L)
	-Equipped with markers, dual lift assist wheels, and hydraulic mast	19 U.S. Pts.	(9.0 L)

ACRES PER HOUR CAPABILITIES\*

Machine Size		Speed in MPH										
		3	3-1/2	4	4-1/2	5	5-1/2	6	6-1/2	7	7-1/2	8
4-Row	30"	3-3/4	4-1/4	5	5-1/2	6-1/4	6-3/4	7-1/2	8-1/4	8-3/4	9-1/4	10
	32"	4	4-1/2	5-1/4	6	6-1/2	7-1/4	8	8-1/2	9-1/4	10	10-1/2
	34"	4-1/4	5	5-1/2	6-1/4	7	7-3/4	8-1/2	9	10	10-1/2	11-1/4
	36"	4-1/2	5-1/4	6	6-3/4	7-1/2	8-1/4	9	9-3/4	10-1/2	11-1/4	12
	38"	4-3/4	5-1/2	6-1/4	7	8	8-1/2	9-1/2	10-1/4	11	11-3/4	12-1/2
	40"	5	5-3/4	6-1/2	7-1/2	8-1/4	9	10	10-3/4	11-1/2	12-1/2	13-1/4
6-Row	30"	5-1/2	6-1/2	7-1/2	8-1/4	9-1/4	10-1/4	11-1/4	12	13	14	15
	36"	6-3/4	7-3/4	9	10	11-1/4	12-1/4	13-1/2	14-1/2	15-3/4	16-3/4	18
	38"	7	8-1/4	9-1/2	10-1/2	11-3/4	13	14-1/4	15-1/4	16-1/2	17-3/4	19
	40"	7-1/2	8-3/4	10	11-1/4	12-1/2	13-3/4	15	16-1/4	17-1/2	18-3/4	20
8-Row	30"	7-1/2	8-3/4	10	11-1/4	12-1/2	13-3/4	15	16-1/4	17-1/2	18-3/4	20
	36"	9	10-1/2	12	13-1/2	15	16-1/2	18	19-1/2	21	22-1/2	24
	38"	9-1/2	11	12-1/2	14-1/4	15-3/4	17-1/4	19	20-1/2	22	23-3/4	25-1/4
	40"	10	11-1/2	13-1/4	15	16-1/2	18-1/4	20	21-1/2	23-1/4	25	26-1/2
12-Row	22"	8-1/4	9-1/2	11	12-1/4	13-3/4	15	16-1/4	17-3/4	19-1/4	20-1/2	22
	30"	11-1/4	13	15	16-3/4	18-3/4	20-1/2	22-1/2	24-1/4	26-1/4	28	30

HECTARES PER HOUR CAPABILITIES\*

Machine Size		Speed in Kilometres per Hour									
		4	5	6	7	8	9	10	11	12	13
4-Row	76 cm	1.3	1.6	1.9	2.2	2.5	2.8	3.2	3.5	3.8	4.1
	81 cm	1.3	1.7	2.0	2.4	2.7	3.0	3.4	3.8	4.0	4.4
	86 cm	1.4	1.8	2.2	2.5	2.9	3.2	3.6	3.9	4.3	4.7
	91 cm	1.5	1.9	2.3	2.7	3.0	3.4	3.8	4.2	4.6	4.9
	97 cm	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4	4.8	5.2
	102 cm	1.7	2.1	2.5	3.0	3.4	3.8	4.2	4.6	5.1	5.5
6-Row	76 cm	1.9	2.4	2.8	3.3	3.8	4.3	4.7	5.2	5.7	6.2
	91 cm	2.3	2.8	3.4	4.0	4.6	5.1	5.7	6.3	6.8	7.4
	97 cm	2.4	3.0	3.6	4.2	4.8	5.4	6.0	6.6	7.2	7.8
	102 cm	2.5	3.2	3.8	4.4	5.1	5.7	6.3	7.0	7.6	8.2
8-Row	76 cm	2.5	3.2	3.8	4.4	5.1	5.7	6.3	7.0	7.6	8.2
	91 cm	3.0	3.8	4.6	5.3	6.1	6.8	7.6	8.3	9.1	9.9
	97 cm	3.2	4.0	4.8	5.6	6.4	7.2	8.0	8.8	9.6	10.4
	102 cm	3.4	4.2	5.1	5.9	6.7	7.6	8.4	9.3	10.1	11.0
12-Row	56 cm	2.8	3.4	4.1	4.8	5.6	6.2	7.0	7.6	8.4	9.0
	76 cm	3.8	4.7	5.7	6.6	7.6	8.5	9.5	10.4	11.4	12.3

\*NOTE: Acres (Hectare) per hour capabilities do not reflect time for turning at field ends or for filling hoppers.





# Group 05 PREDELIVERY, DELIVERY, AND AFTER-SALE SERVICES

## PREDELIVERY SERVICE

The John Deere Delivery Receipt, when properly filled out and signed by the dealer and customer, verifies that the predelivery and delivery services were satisfactorily performed. When delivering this machine, give the customer a copy of the delivery receipt and the operator's manual. Explain their purpose.

Because of the shipping factors involved, plus extra finishing touches that are necessary to promote customer satisfaction, proper predelivery service is of prime importance to the dealer.

After completing the factory-recommended dealer checks and services listed on the predelivery insert page, remove the page from the operator's manual and file it with the shop order for the job. The page will certify that the planter has received the proper predelivery service when that portion of the customer's John Deere Delivery Receipt is completed.

### Planter Main Frame

Check clutch strap for proper assembly (4-Row Narrow, 4-Row Wide, or 6-Row Narrow Drawn Planters).

Check drive wheels to be certain they are assembled properly and that they turn without binding.

Be certain chain guards and shields are properly installed on appropriate sizes and applications.

Be certain that chain idlers pivot freely.

Check all chains for proper tension.

Check all grease fittings to be certain none have been broken off in shipment.

Lubricate the planter as outlined in Section 10, Group 15.

Be certain planter tires are properly inflated.

Check all hardware to be certain it is tight. See torque chart at left.

Paint any parts which may have become scratched or faded during storage or shipment. Replace any damaged decals.

Raise and lower the planter to be certain planter lift system is working properly, and to be sure that there are no interferences.

### Markers


Set proper cable tension.

Raise and lower to check rate of raise and rate of drop.

Be certain markers alternate properly.

Adjust markers to row width desired by customer.

### TORQUE CHART



Bolt Diameter "A"	Bolt Torque in Ft-Lbs (Nm) (kgm)								
	SAE 2			SAE 5			SAE 8		
3/8"	23	(31)	(3.1)	35	(47)	(4.7)	50	(68)	(6.8)
7/16"	35	(47)	(4.7)	55	(75)	(7.5)	80	(108)	(10.8)
1/2"	55	(75)	(7.5)	85	(115)	(11.5)	120	(163)	(16.3)
9/16"	75	(102)	(10.2)	130	(176)	(17.6)	175	(237)	(23.7)
5/8"	105	(142)	(14.2)	170	(231)	(23.1)	240	(325)	(32.5)
3/4"	185	(251)	(25.1)	300	(407)	(40.7)	425	(576)	(57.6)
7/8"	160	(217)	(21.7)	445	(603)	(60.3)	685	(929)	(92.9)
1"	250	(339)	(33.9)	670	(910)	(91.0)	1030	(1396)	(139.6)
1-1/4"	330	(450)	(45.0)	910	(1235)	(123.5)	1460	(1979)	(197.9)

**NOTE:** Bolts having lock nuts should be tightened to approximately 50% of amounts shown in above chart.

Machine bolts and cap screws 7/8-inch and larger are sometimes formed hot rather than cold, which accounts for the lower torque.

**BUY NOW**

**Then Instant Download  
the Complete Manual  
Thank you very much!**