



**Kawasaki**

**TJ27D**



**2-Stroke Air-Cooled Gasoline Engine**  
**Service Manual**

# Quick Reference Guide

<b>General Information</b>	<b>1</b>
<b>Periodic Maintenance</b>	<b>2</b>
<b>Fuel System</b>	<b>3</b>
<b>Engine Top End</b>	<b>4</b>
<b>Crankshaft</b>	<b>5</b>
<b>Electrical System</b>	<b>6</b>
<b>Recoil Starter</b>	<b>7</b>
<b>Troubleshooting</b>	<b>8</b>

This quick reference guide will assist you in locating a desired topic or procedure.

- Bend the pages back to match the black tab of the desired chapter number with the black tab on the edge at each table of contents page.
- Refer to the sectional table of contents for the exact pages to locate the specific topic required.



**TJ27D**

# **2-Stroke Air-Cooled Gasoline Engine Service Manual**

---

All rights reserved. No parts of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic mechanical photocopying, recording or otherwise, without the prior written permission of Quality Assurance Department/Consumer Products & Machinery Company/Kawasaki Heavy Industries, Ltd., Japan.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

The right is reserved to make changes at any time without prior notice and without incurring an obligation to make such changes to products manufactured previously.

All information contained in this publication is based on the latest product information available at the time of publication. Illustrations and photographs in this publication are intended for reference use only and may not depict actual model component parts.

## LIST OF ABBREVIATIONS

A	ampere(s)	lb	pounds(s)
ABDC	after bottom dead center	m	meter(s)
AC	alternating current	min	minute(s)
ATDC	after top dead center	N	newton(s)
BBDC	before bottom dead center	Pa	pascal(s)
BDC	bottom dead center	PS	horsepower
BTDC	before top dead center	psi	pound(s) per square inch
°C	degree(s) Celsius	r	revolution
DC	direct current	rpm	revolution(s) per minute
F	farad(s)	TDC	top dead center
°F	degree(s) Fahrenheit	TIR	total indicator reading
ft	foot, feet	V	volt(s)
g	gram(s)	W	watt(s)
h	hour(s)	Ω	ohm(s)
L	liter(s)		

**Read OWNER'S MANUAL before operating.**

## **EMISSION CONTROL INFORMATION**

To protect the environment in which we all live, Kawasaki has incorporated exhaust emission control systems (EM) in compliance with applicable regulations of the United States Environmental Protection Agency and California Air Resources Board.

### **Exhaust Emission Control System**

The exhaust emission control system applied to this engine consists of a carburetor and an ignition system having optimum ignition timing characteristics.

The carburetor has been calibrated to provide lean air/fuel mixture characteristics and optimum fuel economy with a suitable air cleaner and exhaust system.

## **TAMPERING WITH EMISSION CONTROL SYSTEM PROHIBITED**

Federal law and California State law prohibits the following acts or the causing thereof: (1) the removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new engine for the purpose of emission control prior to its sale or delivery to the ultimate purchaser or while it is in use, or (2) the use of the engine after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:  
Do not tamper with the original emission related part:

- Carburetor and internal parts
- Spark plug
- Magneto or electronic ignition system
- Fuel filter
- Air cleaner element

# Foreword

This manual is designed primarily for use by trained mechanics in a properly equipped shop. However, it contains enough detail and information to make it useful to the owner who desires to perform his own basic maintenance and repair work. A basic knowledge of mechanics, the proper use of tools, and workshop procedures must be understood in order to carry out maintenance and repair satisfactorily. Whenever the owner has insufficient experience or has doubts as to his ability to do the work, all adjustments, maintenance, and repair should be carried out only by qualified mechanics.

In order to perform the work efficiently and to avoid costly mistakes, read the text, thoroughly familiarize yourself with the procedures before starting work, and then do the work carefully in a clean area. Whenever special tools or equipment are specified, do not use makeshift tools or equipment. Precision measurements can only be made if the proper instruments are used, and the use of substitute tools may adversely affect safe operation.

To get the longest life out of your equipment.

- Follow the Periodic Maintenance Chart in the Service Manual.
- Be alert for problems and non-scheduled maintenance.
- Use proper tools and genuine Kawasaki engine parts. Genuine parts provided as spare parts are listed in the Parts Catalog.
- Follow the procedures in this manual carefully. Don't take shortcuts.
- Remember to keep complete records of maintenance and repair with dates and any new parts installed.

---

## How to Use this Manual

---

Whenever you see these WARNING and CAUTION symbols, heed their instructions! Always follow safe operating and maintenance practices.

### WARNING

**This warning symbol identifies special instructions or procedures which, if not correctly followed, could result in personal injury, or loss of life.**

### CAUTION

**This caution symbol identifies special instructions or procedures which, if not strictly observed, could result in damage to or destruction of equipment.**

This manual contains four more symbols (in addition to WARNING and CAUTION) which will help you distinguish different types of information.

### NOTE

○ *This note symbol indicates points of particular interest for more efficient and convenient operation.*

- Indicates a procedural step or work to be done.
- Indicates a procedural sub-step or how to do the work of the procedural step it follows. It also precedes the text of a WARNING, CAUTION, or NOTE.
- ★ Indicates a conditional step or what action to take based on the results of the test or inspection in the procedural step or sub-step it follows.

In most chapters an exploded view illustration of the system components follows the Table of Contents. In these illustrations you will find the instructions indicating which parts require specified tightening torque, oil, grease or a locking agent during assembly.

# General Information

## Table of Contents

Before Servicing .....	1-2
Model Identification.....	1-4
General Specifications.....	1-5

## 1-2 GENERAL INFORMATION

---

### Before Servicing

---

Before starting to service the engine, carefully read the applicable section to eliminate unnecessary work. Photographs, diagrams, notes, cautions, warnings, and detailed descriptions have been included wherever necessary. Nevertheless, even a detailed account has limitations, a certain amount of basic knowledge is required for successful work.

#### Especially note the following:

(1) Dirt

Before removal and disassembly, clean the engine. Any dirt entering the engine, carburetor, or other parts, will work as an abrasive and shorten the life of engine. For the same reason, before installing a new part, clean off any dust or metal filings.

(2) Tightening Sequence

Generally, when installing a part with several bolts, nuts, or screws, start them all in their holes and tighten them to a snug fit. Then tighten them evenly, in a staggered sequence. This is to avoid distortion of the part and/or causing gas or oil leakage. Conversely when loosening the bolts, nuts, or screws, first loosen all of them by about a quarter of a turn and then remove them. Where there is a tightening sequence indication in this Service Manual, the bolts, nuts, or screws must be tightened in the order and method indicated.

(3) Torque

When torque values are given in this Service Manual, use them. Either too little or too much torque may lead to serious damage. Use a good quality, reliable torque wrench.

(4) Force

Common sense should dictate how much force is necessary in assembly and disassembly. If a part seems especially difficult to remove or install, stop and examine what may be causing the problem. Whenever tapping is necessary, tap lightly using a wooden or plastic-faced mallet. Use an impact driver for screws (particularly for the removal of screws held by a locking agent) in order to avoid damaging the heads.

(5) Edges

Watch for sharp edges, especially during major engine disassembly and assembly. Protect your hands with gloves or a piece of thick cloth when lifting the engine or turning it over.

(6) High-Flash Point Solvent

A high-flash point solvent is recommended to reduce fire danger. A commercial solvent commonly available in North America is Standard solvent (generic name). Always follow manufacturer and container directions regarding the use of any solvent.

(7) Gasket, O-Ring

Do not reuse a gasket or O-ring once it has been in service. The mating surfaces around the gasket should be free of foreign matter and perfectly smooth to avoid oil or compression leaks.

(8) Liquid Gasket, Non-Permanent Locking Agent

Follow manufacturer's directions for cleaning and preparing surfaces where these compounds will be used. Apply sparingly. Excessive amounts may block engine oil passages and cause serious damage. An example of a non-permanent locking agent commonly available in North America is Loctite Lock'n Seal (Blue).

(9) Press

A part installed using a press or driver, such as a journal, should first be coated with oil on its outer or inner circumference so that it will go into place smoothly.

(10) Ball Bearing, Needle Bearing

Do not remove a ball bearing or a needle bearing unless it is absolutely necessary. Replace any ball or needle bearings that were removed with new ones. Install bearings with the manufacturer and size marks facing out, applying pressure evenly with a suitable driver to the end of the race that contacts the press fit portion, and press it evenly over the base component.

(11) Oil Seal and Grease Seal

Replace any oil or grease seals that were removed with new ones, as removal generally damages seals.

When pressing in a seal which has manufacturer's marks, press it in with the marks facing out. Seals should be pressed into place using a suitable driver, which contacts evenly with the side of seal, until the face of the seal is even with the end of the hole.



**Before Servicing**

(12) Seal Guide

A seal guide is required for certain oil or grease seals during installation to avoid damage to the seal lips. Before a shaft passes through a seal, apply a little oil, preferably high temperature grease on the lips to reduce rubber to metal friction.

(13) Circlip, Retaining Ring and Cotter Pin

When installing circlips and retaining rings, take care to compress or expand them only enough to install them and no more. Install the circlip with its chamfered side facing load side as well.

Replace any circlips, retaining rings, and cotter pins that were removed with new ones, as removal weakens and deforms them. If old ones are reused, they could become detached while running, leading to a problem.



(14) Lubrication

Engine wear is generally at its maximum while the engine is warming up and before all the rubbing surfaces have an adequate lubricative film. During assembly, oil or grease (whichever is more suitable) should be applied to any rubbing surface which has lost its lubricative film. Old grease and dirty oil should be cleaned off. Deteriorated grease has lost its lubricative quality and may contain abrasive foreign particles.

Don't use just any oil or grease. Some oils and greases in particular should be used only in certain applications and may be harmful if used in an application for which they are not intended. This manual makes reference to molybdenum disulfide grease (MoS2) in the assembly of certain engine parts. Always check manufacturer recommendations before using such special lubricants.

(15) Electrical Wires

All the electrical wires are either single-color or two-color and, with only a few exceptions, must be connected to wires of the same color. On any of the two-color wires there is a greater amount of one color and a lesser amount of a second color, so a two-color wire is identified by first the primary color and then the secondary color. For example, a yellow wire with thin red stripes is referred to as a "yellow/red" wire; it would be a "red/yellow" wire if the colors were reversed to make red the main color.

Wire (cross-section)	Color Indicated on the Wire	Color Indicated on the Wiring Diagram
	Yellow/Red	

GB020601W1 C

(16) Replacement Parts

When there is a replacement instruction, replace these parts with new ones every time they are removed. There replacement parts will be damaged or lose their original function once removed.

(17) Inspection

When parts have been disassembled, visually inspect these parts for the following conditions or other damage. If there is any doubt as to the condition of them, replace them with new ones.

Abrasion	Crack	Hardening	Warp
Bent	Dent	Scratch	Wear
Color change	Deterioration	Seizure	

(18) Service Data

Service Data terms are defined as follows:

"Standards" show dimensions or performances which brand-new parts or systems have.

"Service Limits" indicate the usable limits. If the measurement shows excessive wear or deteriorated performance, replace the damaged parts.

## 1-4 GENERAL INFORMATION

### Model Identification



**General Specifications**

<b>Item</b>	<b>TJ27D</b>
Type of Engine	Forced air cooled, 2-stroke, horizontal shaft, gasoline engine
Bore × Stroke	34 mm × 29 mm (1.34 in. × 1.14 in.)
Piston Displacement	26.3 mL (1.60 cu. in.)
Direction of Rotation	Counterclockwise facing the PTO shaft
Ignition System	Flywheel magneto transistor type
Starting System	Kar Recoil starter (Coil damper type)
Spark Plug	NGK BPMR6A
Clutch Type	Automatic centrifugal type
Clutch Drum Bore	Φ54
Carburetor	Diaphragm with starter button type (TZ11K-2A by TK)
Air Cleaner	Dry type
Dimensions (L × W × H )	167 mm × 217 mm × 231 mm (6.57 in. × 8.54 in. × 9.09 in.)
Dry Weight	2.3 kg (5.1 lbs)
Mixing Ratio	Regular unleaded gasoline 50 : 1 2 stroke engine oil (JASO-FC class)
Tank Capacity	0.6 L (0.63 US qt)

Specifications subject to change without notice.

# Periodic Maintenance

## Table of Contents

Periodic Maintenance Chart .....	2-2
Tightening Torque .....	2-3
Specifications .....	2-4
Special Tools and Sealant .....	2-5
Periodic Maintenance Procedures.....	2-6
Fuel System.....	2-6
Idling Speed Adjustment.....	2-6
Fuel Tube Replacement.....	2-6
Fuel Filter Cleaning.....	2-6
Fuel Tank Cap Inspection .....	2-7
Fuel Leakage Inspection.....	2-7
Air Cleaner Element Inspection and Cleaning .....	2-7
Engine Top.....	2-8
Cylinder Fins Cleaning .....	2-8
Cylinder Cleaning.....	2-8
Piston Cleaning.....	2-8
Muffler Cleaning.....	2-9
Crankshaft .....	2-9
Crankshaft, Connecting Rod Inspection .....	2-9
Electrical System .....	2-10
Spark Plug Cleaning and Inspection.....	2-10
Spark Plug Gap Inspection and Adjustment .....	2-10

## 2-2 PERIODIC MAINTENANCE

### Periodic Maintenance Chart

#### WARNING

Accidental engine starting can cause injury.

Always remove the spark plug cap from the spark plug before servicing the engine to prevent accidental starting.

Maintenance	Interval				
	Daily	First 20 hours	Every 20 hours	Every 50 hours	Every 100 hours
Check and replenish fuel	•				
Check for fuel leakage	•				
Check bolts, nuts and screws for looseness and loss	•				
Clean fuel filter			•		
Clean fuel tank cap			•		
★ Clean air filter element			•		
Tighten bolts, nuts and screws		•		•	
Clean spark plug and adjust electrode gap				•	
★ Remove dust and dirt from cylinder fins				•	
K Remove carbon deposits on piston head and inside cylinder				•	
K Remove carbon deposits in the exhaust pipe of muffler				•	
Clean net of spark arrester				•	
K Check the sliding portion of crankshaft, connecting rod etc.					•
Fuel tube	It is recommended to replace every 3 years.				

#### NOTE

○ The service intervals indicated are to be used as a guide.

K: These items must be performed with proper tools. See your authorized Kawasaki dealer for service.

★: These items must be performed more frequently as necessary by operating condition.

**Tightening Torque**

The following tables list the tightening torque for the major fasteners and the parts requiring use of a non-permanent locking agent or liquid gasket.

Letters used in the following "Tightening Torque" table mean.

L: Apply a non-permanent locking agent to the threads.

LG: Apply a liquid gasket to the sealing surface.

**Tightening Torque**

Fasteners	Size	Torque			Remarks
		N·m	kgf·m	ft·lb	
Ignition Coil	M4	2.2	0.22	1.6 in·lb	
Recoil Starter	M4	1.8	0.18	1.3 in·lb	L
Crankcase	M5	3.7	0.38	2.7 in·lb	LG
Engine Shroud	M5	2.7	0.28	2.0 in·lb	L
Fan Housing	M5	3.7	0.38	2.7 in·lb	
Carburetor (Tighten with Air Cleaner Case)	M5	3.7	0.38	2.7 in·lb	
Insulator	M5	3.7	0.38	2.7 in·lb	L
Fuel Tank	M5	1.6	0.16	1.2 in·lb	L
Muffler	M5	3.7	0.38	2.7 in·lb	L
Cylinder	M5	3.7	0.38	2.7 in·lb	L
Clutch	M6	8.8	0.90	6.5 in·lb	L
Flywheel Nut	M8	15	1.50	11	
Starting Pulley	M6	15	1.50	11	
Spark Plug	M14	14	1.50	11	

The table below, relating tightening torque to thread diameter, lists the basic torque for the bolts and nuts. Use this table for only the bolts and nuts which do not require a specific torque value. All of the values are for use with dry solvent-cleaned threads.

**Basic Torque for General Fasteners**

Threads dia (mm)	Torque		
	N·m	kgf·m	ft·lb
4	2.0	0.20	17 in·lb
5	3.4	0.35	30 in·lb
6	5.9	0.60	52 in·lb
8	15	1.5	11


## 2-4 PERIODIC MAINTENANCE

### Specifications


Item	Standard
<b>Fuel System</b> Maximum Speed Idling Speed Air Cleaner Type Carburetor Main Jet	Different depend on matching machine 3 000 ±200 r/min (rpm)  Dry type  #40
<b>Electrical System</b> Spark Plug Gap Ignition Coil Air-gap	0.6 ~ 0.7 mm (0.024 ~ 0.028 in.) 0.3 ~ 0.5 mm (0.012 ~ 0.020 in.)

**Special Tools and Sealant**


**Hand Tester:  
57001-1394**



**Flywheel Puller:  
57001-6002**



**Kawasaki Bond (Silicone Sealant):  
56019-120**





**BUY NOW**

**Then Instant Download  
the Complete Manual  
Thank you very much!**