

Table of Contents

XTX Series Tractors Service/Diagnostic Manual SM 8-15002

1 GENERAL

Safety Rules, General Information and Torque Specifications1001 SM

2 ENGINE

NOTE: For Service and Overhaul procedures refer to your Engine Service Manual. SM
Error Codes: Tier 2 Tier 3

3 FUEL

NOTE: For Service and Overhaul procedures refer to your Engine Service Manual.

4 ELECTRICAL

Electrical Troubleshooting and Schematics.....4001 SM

Instrument Cluster Programming.....4002 SM

Battery Servicing and Testing.....4004 SM

5 STEERING

Steering Column and Steering Hand Pump Removal5001 SM

Rexroth Steering Hand Pump.....5002 SM

6 TRANSMISSION

Transmission How it Works6

Guidelines for Separating the Speed and Range Transmissions6003 SM

8 Speed Powershift Transmission Servicing6006 SM

Range Transmission Servicing6007 SM

Differential and Differential Lock Servicing6012 SM

MFD Clutch Servicing6017 SM

Rear Axle Removal6018 SM

PTO Servicing - shiftable/reversible6019 SM

MFD Front Axle (20.29 Rigid Axle)6021 SM

MFD Front Axle (20.43 Rigid Axle)6021-A SM

MFD Front Axle (20.29 Suspended Axle)6022 SM

MFD Front Axle (20.43 Suspended Axle)6022-A SM

7 BRAKES

Brakes How it Works..... 7

Service Brakes 7002 SM

8 HYDRAULICS

Hydraulics How it Works 8

Hydraulic Troubleshooting and Schematic 8001 SM

Charge/Lubrication Pump 8003 SM

Remote Valves..... 8008 SM

9 CHASSIS

Pedal, Lever and Switch Adjustments 9001 SM

10CONTROLLER SYSTEMS

Electrical Controllers How it Works..... 10

Auxiliary/Remote Valve Controller - Error Codes,
Troubleshooting and Schematics 10001 SM

Hitch/PTO Controller - Error Codes,
Troubleshooting and Schematics 10002 SM

Independent Front Suspension Axle Controller - Calibration,
Error Codes, Troubleshooting and Schematics..... 10003 SM

Transmission and Cab Controller - Calibration, Error Codes,
Troubleshooting and Schematics 10006 SM

Instrument Cluster Controller - Error Codes,
Troubleshooting and Schematics 10009 SM

Controller Reprogramming
(Using The McCormick Diagnostic Centre) 10010 SM

Cab Suspension Controller - Calibration, Error Codes,
Troubleshooting and Schematics 10011 SM

Automatic Temperature Control - Error Codes,
Troubleshooting and Schematics 10012 SM

NOTE: *Information contained in this manual may cover features that are not available in all markets worldwide.*

NOTE: *References throughout this manual may be made to sections currently not available. These Sections will be made available at a later date.*

Section 1001

1001

SAFETY, GENERAL INFORMATION AND STANDARD TORQUE SPECIFICATIONS

TABLE OF CONTENTS

| | |
|---|---|
| SAFETY | 3 |
| GENERAL INFORMATION | |
| Cleaning | 5 |
| Inspection | 5 |
| Bearings | 5 |
| Needle Bearings | 5 |
| Gears | 5 |
| Oil Seals, O-Rings And Gaskets | 5 |
| Shafts | 5 |
| Service Parts | 5 |
| Lubrication | 5 |
| STANDARD TORQUE DATA FOR NUTS AND BOLTS | |
| Chart 1 (Plain Nuts/Bolts) | 6 |
| Chart 2 (Phosphate Coated Nuts/Bolts) | 6 |
| Chart 3 (Zinc or Cadmium Plated Nuts/Bolts) | 7 |


SAFETY



This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.

To prevent injury always follow the Warning, Caution and Danger notes in this section and throughout the manual.

Put a warning tag as shown below on the key for the key switch when carrying out servicing or repairs to the tractor. Warning tags (publication number 2-1000) are available from your McCormick dealer.



WARNING: Read the operators manual to familiarize yourself with the correct control functions.



WARNING: Operate the machine and equipment controls from the seat position only. Any other method could result in serious injury.



WARNING: This is one a man machine, no riders allowed.



WARNING: Before starting engine, study Operator's Manual safety messages. Read all safety signs on machine. Clear the area of other persons. Learn and practice safe use of controls before operating.

It is your responsibility to understand and follow manufacturers instructions on machine operation, service, and to observe pertinent laws and regulations. Operator's and Service Manuals may be obtained from you McCormick dealer.



WARNING: If you wear clothing that is too loose or do not use the correct safety equipment for your job, you can be injured. Always wear clothing that will not catch on objects. Extra safety equipment that can be required includes hard hat, safety shoes, ear protection, eye or face protection, heavy gloves and reflector clothing.



WARNING: When working in the area of the fan belt with the engine running, avoid loose clothing if possible, and use extreme caution.



WARNING: When doing checks and tests on the equipment hydraulics, follow the procedures as they are written. DO NOT change the procedure.



WARNING: When putting the hydraulic cylinders on this machine through the necessary cycles to check operation or to remove air from a circuit, make sure all people are out of the way.



WARNING: Use insulated gloves or mittens when working with hot parts.



CAUTION: Lower all attachments to the ground or use stands to safely support the attachments before you do any maintenance or service.



CAUTION: Pin sized and smaller streams of hydraulic oil under pressure can penetrate the skin and result in serious infection. If hydraulic oil under pressure does penetrate the skin, seek medical treatment immediately. Maintain all hoses and tubes in good condition. Make sure all connections are tight. Make a replacement of any tube or hose that is damaged or thought to be damaged. **DO NOT** use your hand to check for leaks, use a piece of cardboard or wood.



CAUTION: When removing hardened pins such as a pivot pin, or a hardened shaft, use a soft head (brass or bronze) hammer or use a driver made from brass or bronze and a steel head hammer.



CAUTION: When using a hammer to remove and install pivot pins or separate parts using compressed air or using a grinder, wear eye protection that completely encloses the eyes (approved goggles or other approved eye protectors).



CAUTION: Use suitable floor (service) jacks or chain hoist to raise wheels or tracks off the floor. Always block machine in place with suitable safety stands.



CAUTION: When servicing or repairing the machine. Keep the shop floor and operator's compartment and steps free of oil, water, grease, tools, etc. Use oil absorbing material and or shop cloths as required. Use safe practices at all times.



CAUTION: Some components of this machine are very heavy. Use suitable lifting equipment or additional help as instructed in this Service Manual.



DANGER: Engine exhaust fumes can cause death. If it is necessary to start the engine in a closed place, remove the exhaust fumes from the area with an exhaust pipe extension. Open the doors and get outside air into the area.



DANGER: When the battery electrolyte is frozen, the battery can explode if (1), you try to charge the battery, or (2), you try to jump start and run the engine. To prevent that battery electrolyte from freezing, try to keep the battery at full charge. If you do not follow these instructions, you or others in the area can be injured.



DANGER: Batteries contain acid and explosive gas. Explosions can result from sparks, flames or wrong cable connections. To connect the jumper cables correctly to the battery of this machine see the Operator's Manual. Failure to follow these instructions can cause serious injury or death.

GENERAL INFORMATION

Cleaning

Clean all metal parts except bearings, in mineral spirits or by steam cleaning. Do not use caustic soda for steam cleaning. After cleaning dry and put oil on all parts. Clean oil passages with compressed air. Clean bearings in kerosene, dry the bearings completely and put oil on the bearings.

Inspection

Check all parts when the parts are disassembled. Replace all parts that have wear or damage. Small scoring or grooves can be removed with a hone or crocus cloth. Complete visual inspection for indications of wear, pitting and the replacement of parts necessary will prevent early failures.

Bearings

Check bearings for easy action. If bearings have a loose fit or rough action replace the bearing. Wash bearings with a good solvent or kerosene and permit to air dry. **DO NOT DRY BEARINGS WITH COMPRESSED AIR.**

Needle Bearings

Before you press needle bearings in a bore always remove any metal protrusions in the bore or edge of the bore. Before you press bearings into position put petroleum jelly on the inside and outside diameter of the bearings.

Gears

Check all gears for wear and damage. Replace gears that have wear or damage.

Oil Seals, O-Rings And Gaskets

Always install new oil seals, o-rings and gaskets. Put petroleum jelly on seals and o-rings.

Shafts

Check all shafts that have wear or damage. Check the bearing and oil seal surfaces of the shafts for damage.

Service Parts

Always install genuine McCormick service parts, when ordering refer to the Parts Catalog for the correct part number of the genuine McCormick replacement items. Failures due to the use of other than genuine McCormick replacement parts are not covered by warranty.

Lubrication

Only use the oils and lubricants specified in the Operators or Service Manual. Failures due to the use of non specified oils and lubricants are not covered by warranty.

STANDARD TORQUE DATA FOR NUTS AND BOLTS

NOTE: A "click type" torque wrench is recommended for the bolt torques listed below.

Chart 1 (Plain Nuts/Bolts)

| BOLT SIZE (mm) | TYPE 8.8 | | | | TYPE 10.9 | | | |
|----------------------|----------|--------|--------|--------|-----------|--------|--------|--------|
| | MIN | | MAX | | MIN | | MAX | |
| | lb ft | Nm | lb ft | Nm | lb ft | Nm | lb ft | Nm |
| M4 | 3.0 | 4.0 | 3.4 | 4.5 | 4.3 | 5.8 | 4.8 | 6.5 |
| M5 | 4.8 | 6.5 | 5.5 | 7.5 | 7.0 | 9.5 | 7.8 | 10.5 |
| M6 | 8.2 | 11.0 | 9.2 | 12.5 | 11.8 | 16.0 | 13.3 | 18.0 |
| M8 | 20.0 | 27.0 | 22.5 | 31.0 | 28.7 | 39.0 | 32.3 | 44.0 |
| M10 | 40.0 | 54.0 | 45.0 | 61.0 | 56.0 | 77.0 | 64.0 | 87.0 |
| M12 | 69.0 | 94.0 | 78.0 | 106.0 | 100.0 | 134.0 | 110.0 | 151.0 |
| M14 | 110.0 | 150.0 | 125.0 | 170.0 | 160.0 | 215.0 | 180.0 | 240.0 |
| M16 | 175.0 | 235.0 | 190.0 | 260.0 | 245.0 | 335.0 | 275.0 | 375.0 |
| M20 | 345.0 | 470.0 | 390.0 | 530.0 | 480.0 | 650.0 | 540.0 | 730.0 |
| M22 | 475.0 | 640.0 | 530.0 | 720.0 | 655.0 | 890.0 | 735.0 | 1000.0 |
| M24 | 600.0 | 810.0 | 675.0 | 915.0 | 830.0 | 1125.0 | 930.0 | 1265.0 |
| M30 | 1190.0 | 1615.0 | 1340.0 | 1815.0 | 1645.0 | 2235.0 | 1855.0 | 2515.0 |
| M36 | 2080.0 | 2825.0 | 2340.0 | 3175.0 | 2875.0 | 3900.0 | 3235.0 | 4390.0 |

Chart 2 (Phosphate Coated Nuts/Bolts)

| BOLT SIZE (mm) | TYPE 8.8 | | | | TYPE 10.9 | | | |
|----------------------|----------|--------|--------|--------|-----------|--------|--------|--------|
| | MIN | | MAX | | MIN | | MAX | |
| | lb ft | Nm | lb ft | Nm | lb ft | Nm | lb ft | Nm |
| M4 | 2.3 | 3.0 | 2.6 | 3.4 | 3.2 | 4.4 | 3.6 | 4.9 |
| M5 | 3.6 | 4.9 | 4.1 | 5.6 | 5.2 | 7.1 | 5.9 | 8.0 |
| M6 | 6.2 | 8.3 | 6.9 | 9.4 | 8.9 | 12.0 | 10.0 | 13.5 |
| M8 | 15.0 | 20.3 | 16.9 | 23.3 | 21.5 | 29.2 | 24.2 | 32.8 |
| M10 | 30.0 | 41.0 | 34.0 | 46.0 | 42.0 | 58.0 | 48.0 | 65.0 |
| M12 | 52.0 | 71.0 | 59.0 | 80.0 | 75.0 | 101.0 | 83.0 | 113.0 |
| M14 | 83.0 | 113.0 | 94.0 | 126.0 | 120.0 | 161.0 | 135.0 | 180.0 |
| M16 | 131.0 | 176.0 | 143.0 | 195.0 | 185.0 | 251.0 | 205.0 | 280.0 |
| M20 | 259.0 | 353.0 | 293.0 | 400.0 | 360.0 | 490.0 | 405.0 | 550.0 |
| M22 | 355.0 | 480.0 | 400.0 | 540.0 | 490.0 | 665.0 | 550.0 | 750.0 |
| M24 | 450.0 | 608.0 | 506.0 | 686.0 | 625.0 | 845.0 | 700.0 | 950.0 |
| M30 | 893.0 | 1211.0 | 1005.0 | 1361.0 | 1235.0 | 1675.0 | 1390.0 | 1885.0 |
| M36 | 1560.0 | 2119.0 | 1755.0 | 2381.0 | 2156.0 | 2925.0 | 2425.0 | 3295.0 |

Chart 3 (Zinc or Cadmium Plated Nuts/Bolts)

| BOLT SIZE (mm) | TYPE 8.8 | | | | TYPE 10.9 | | | |
|----------------------|----------|--------|--------|--------|-----------|--------|--------|--------|
| | MIN | | MAX | | MIN | | MAX | |
| | lb ft | Nm | lb ft | Nm | lb ft | Nm | lb ft | Nm |
| M4 | 2.6 | 3.5 | 2.9 | 3.9 | 3.7 | 5.0 | 4.1 | 5.6 |
| M5 | 4.1 | 5.6 | 4.6 | 6.3 | 5.9 | 8.0 | 6.6 | 9.0 |
| M6 | 7.0 | 9.5 | 7.8 | 10.6 | 10.0 | 13.6 | 11.3 | 15.3 |
| M8 | 17.0 | 23.1 | 19.1 | 25.9 | 24.4 | 33.1 | 27.4 | 37.2 |
| M10 | 34.0 | 46.0 | 38.3 | 52.0 | 48.0 | 65.0 | 54.0 | 74.0 |
| M12 | 59.0 | 80.0 | 66.0 | 90.0 | 85.0 | 114.0 | 94.0 | 128.0 |
| M14 | 94.0 | 128.0 | 106.0 | 145.0 | 136.0 | 183.0 | 153.0 | 205.0 |
| M16 | 149.0 | 200.0 | 161.0 | 220.0 | 208.0 | 285.0 | 235.0 | 320.0 |
| M20 | 293.0 | 400.0 | 330.0 | 450.0 | 408.0 | 555.0 | 460.0 | 620.0 |
| M22 | 400.0 | 545.0 | 450.0 | 615.0 | 555.0 | 755.0 | 625.0 | 850.0 |
| M24 | 510.0 | 690.0 | 575.0 | 780.0 | 705.0 | 955.0 | 790.0 | 1075.0 |
| M30 | 1010.0 | 1375.0 | 1140.0 | 1545.0 | 1400.0 | 1900.0 | 1580.0 | 2140.0 |
| M36 | 1770.0 | 2400.0 | 1990.0 | 2700.0 | 2445.0 | 3315.0 | 2750.0 | 3730.0 |



Service Manual

**Electronic Common Rail
6 Cylinder (Tier 2) Engines**

This publication provides the features, data and correct method of repair operations that can be performed on every single component of the engine.

Following the instructions given and using the special tools will ensure correct repairing, within the scheduled times, while also protecting operators against possible accidents.

Before starting any repair work, make sure that all accident-prevention equipment is close at hand and in efficient conditions.

Therefore, check and wear the items specified by the rules of safety: goggles, helmet, gloves, shoes.

Before use, check all the working, hoisting and handling equipment.

The possibility exists that the information given in this manual may not be up to date as a result of modifications adopted by the Manufacturer at any time for reasons of a technical or commercial nature or to adjust to the laws in force in the different Countries.

The reproduction, even only in part, of the text and illustrations is forbidden.

CONTENT OF SECTIONS

| | |
|---|-----------------|
| General information | 1 |
| Fuel | 2 |
| Duty - Industrial applications Common Rail Engines | 3 |
| Overhaul and technical specifications | 4 |
| Tools | 5 |
| Safety prescriptions | Appendix |

PREFACE TO USER'S GUIDELINE MANUAL

Section 1 describes the engine illustrating its features and working in general.

Section 2 describes the type of fuel feed.

Section 3 relates to the specific duty and is divided in four separate parts:

1. Mechanical part, related to the engine overhaul, limited to those components with different characteristics based on the relating specific duty.
2. Electrical part, concerning wiring harness, electrical and electronic equipment with different characteristics based on the relating specific duty.
3. Maintenance planning and specific overhaul.
4. Troubleshooting part dedicated to the operators who, being entitled to provide technical assistance, shall have simple and direct instructions to identify the cause of the major inconveniences.


Sections 4 and 5 illustrate the overhaul operations of the engine overhaul on stand and the necessary equipment to execute such operations.

The appendix reports general safety prescriptions to be followed by all operators whether being in-charge of installation or maintenance, in order to avoid serious injury.

SPECIAL REMARKS

















Where possible, the same sequence of procedures has been followed for easy reference.
Diagrams and symbols have been widely used to give a clearer and more immediate illustration of the subject being dealt with, (see next page) instead of giving descriptions of some operations or procedures.

Example



Tighten to torque
Tighten to torque + angular value


Graph and symbols


| | | | |
|---|---|---|---|
|  | Removal Disconnection |  | Intake |
|  | Refitting Connection |  | Exhaust |
|  | Removal Disassembly |  | Operation |
|  | Fitting in place Assembly | \varnothing | Compression ratio |
|  | Tighten to torque |  | Tolerance Weight difference |
|  | Tighten to torque + angle value |  | Rolling torque |
|  | Press or caulk |  | Replacement Original spare parts |
|  | Regulation Adjustment |  | Rotation |
|  | Warning Note |  | Angle Angular value |
|  | Visual inspection Fitting position check |  | Preload |
|  | Measurement Value to find Check |  | Number of revolutions |
|  | Equipment |  | Temperature |
|  | Surface for machining Machine finish |  | Pressure |
|  | Interference Strained assembly | > | Oversized Higher than.... Maximum, peak |
|  | Thickness Clearance | < | Undersized Less than.... Minimum |
|  | Lubrication Damp Grease |  | Selection Classes Oversizing |
|  | Sealant Adhesive |  | Temperature < 0°C Cold Winter |
|  | Air bleeding |  | Temperature > 0°C Hot Summer |

SECTION 1**General Specifications**

| | Page |
|--|------|
| ENGINE ID. CODE | 3 |
| LUBRICATING CIRCUIT, 4 AND 6 CYLINDERS | 5 |
| OIL VAPOUR RECIRCULATING SYSTEM | 7 |
| COOLING CIRCUIT SYSTEM 4 AND 6 CYLINDERS | 8 |
| AIR INDUCTION BOOST DIAGRAM | 12 |

ENGINE IDENTIFICATION CODE



SPECIFIC ENGINE CODE**EXAMPLES**

N4CENT.C

N = Engine

40 = 4 liters

E = Electronic

N = Type of Engine block

T = Supercharger with aftercooler

C = Euro3


LUBRICATION (4 CYLINDERS)

Lubrication by forced circulation is achieved through oil rotary expansion pump (1), placed in the front part of the basement, driven by the straight-tooth gear splined to the shaft's bar hold.

From the pan, the lubrication oil flows to the driving shaft, to the camshaft and to the valve drive.

Lubrication involves the heat exchanger as well, the turbo-blower and the eventual compressor for any eventual compressed air system. All these components may often vary according to the specific duty and will therefore be examined in the specific section.

Figure 1




LUBRICATION SYSTEM LAYOUT

LUBRICATION(6 CYLINDERS)

Even for the 6 cylinders version lubrication is obtained by forced circulation and achieved through an oil rotary expansion pump similar to the 4 cylinders' one.




Also in this case, the components such as the oil exchanger, the turbo-blower and the eventual compressor are specifically studied and made out to suit the equipment or the duty for which the engine has been developed.

Figure 2



Oil recover from the turbo-blower


To the exchanger and to the turbo-blower

-  Routing of oil under pressure
-  Routing of oil return by gravity to sump
-  Introduction of oil

LUBRICATION SYSTEM LAYOUT

OIL VAPOUR RECYCLING

Figure 3



1. Pre-separator - 2 Exhaust to the outside (temporary) - 3 Filter - 4 Return to engine

The tappet cover houses the pre-separator (1), whose shape and position determines an increase in oil vapour outlet speed and condenses a part of vapours at the same time.

Condensate oil returns to the oil sump whereas the residual vapours are ducted, collected and filtered in the blow-by (3).

In the blow-by (3), part of the vapours condense and return to the oil sump whereas the remaining part is put into cycle again through pipe (2).

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**