CONTENTS

SECTION 1 GENERAL

Group 1 Safety Hints ····· 1-1
Group 2 Specifications ····· 1-9

SECTION 2 STRUCTURE AND FUNCTION

Group 1 Pump Device ····· 2-1
Group 2 Main Control Valve ····· 2-21
Group 3 Swing Device ····· 2-46
Group 4 Travel Device ····· 2-58
Group 5 RCV Lever ····· 2-69
Group 6 RCV Pedal ····· 2-76

SECTION 3 HYDRAULIC SYSTEM

Group 1 Hydraulic Circuit ····· 3-1
Group 2 Main Circuit ····· 3-2
Group 3 Pilot Circuit ····· 3-5
Group 4 Single Operation ····· 3-13
Group 5 Combined Operation ····· 3-23

SECTION 4 ELECTRICAL SYSTEM

Group 1 Component Location ····· 4-1
Group 2 Electrical Circuit ····· 4-3
Group 3 Electrical Component Specification ····· 4-23
Group 4 Connectors ····· 4-33

SECTION 5 MECHATRONICS SYSTEM

Group 1 Outline ····· 5-1
Group 2 Mode selection System ····· 5-3
Group 3 Automatic Deceleration System ····· 5-6
Group 4 Power Boost System ····· 5-7
Group 5 Travel Speed Control System ····· 5-8
Group 6 Automatic Warming Up Function ····· 5-9
Group 7 Engine Overheat Prevention Function ····· 5-10
Group 8 Anti-Restart system ····· 5-11
Group 9 Self-Diagnostic System ····· 5-12

Group 10 Engine Control System ····· 5-15
Group 11 EPPR(Electro Proportional Pressure Reducing) Valve ····· 5-22
Group 12 Monitoring System ····· 5-25

SECTION 6 TROUBLESHOOTING

Group 1 Before trobleshooting ····· 6-1
Group 2 Hydraulic and Mechanical System ····· 6-4
Group 3 Electrical System ····· 6-24
Group 4 Mechatronics System ····· 6-41

SECTION 7 MAINTENANCE STANDARD

Group 1 Operational Performance Test ····· 7-1
Group 2 Major Components ····· 7-21
Group 3 Track and Work Equipment ····· 7-31

SECTION 8 DISASSEMBLY AND ASSEMBLY

Group 1 Precaution ····· 8-1
Group 2 Tightening Torque ····· 8-4
Group 3 Pump Device ····· 8-7
Group 4 Main Control Valve ····· 8-36
Group 5 Swing Device ····· 8-49
Group 6 Travel Device ····· 8-74
Group 7 RCV Lever ····· 8-114
Group 8 Turning Joint ····· 8-129
Group 9 Boom, Arm and Bucket Cylinder ····· 8-134
Group 10 Undercarriage ····· 8-151
Group 11 Work Equipment ····· 8-163

SECTION 9 COMPONENT MOUNTING TORQUE

Group 1 Introduction guide ····· 9-1
Group 2 Engine system ····· 9-2
Group 3 Electric system ····· 9-4
Group 4 Hydraulic system ····· 9-6
Group 5 Undercarriage ····· 9-10
Group 6 Structure ····· 9-11
Group 7 Work equipment ····· 9-14

BUY NOW

Then Instant Download the Complete Manual

Thank you very much!