



PARTS MANUAL

GPC2000 SL SERIES





TABLE OF CONTENT

Table of Content

INTRODUCTION	PAGE	SERIAL NR. CUT	REV.
General	3		
COVERS	PAGE	SERIAL NR. CUT	REV.
Covers	6, 8, 10		
Castor Wheel	12		
Load Wheel	14		
HYDRAULIC	PAGE	SERIAL NR. CUT	REV.
Tube-/Hose Layout	18, 20		
Pump Motor and Pump	22		
DRIVE UNIT	PAGE	SERIAL NR. CUT	REV.
Drive Unite	26		
Gearbox	28, 30		
Drive Motor	32		
Knuckel	34, 36		
ELECTRIC	PAGE	SERIAL NR. CUT	REV.
Contacteur Panel	40		
Steering Controller GPC2040S	42		
Drive Board	44		
Contacteur/Traction	46		
Contacteur/Pump	48		
Quick Pic GPC2040S	50		
Accelerator Switch GPC2040S	52		
Lift/Lower and Horn GPC2040S	54		
Control Handle	56		
Handle	58, 60		
Foot Brake	62		
Platform	64		
Switch	66		
Battery Connector/Emergency Disconnecter	68		
Dash Board	70		
Steer Indicator GPC2040S	72		
BRAKE SYSTEM	PAGE	SERIAL NR. CUT	REV.
Brake	76		
STEERING	PAGE	SERIAL NR. CUT	REV.
Steering GPC2040S	80		
Steer Motor GPC2040S	82		
Steering GPC2040S	84, 86		
Steering Column	88		
MAST-/LIFT STRUCTURE	PAGE	SERIAL NR. CUT	REV.
Lift Structure	92		
Guard Rail	94		
Yoke	96		
CYLINDER	PAGE	SERIAL NR. CUT	REV.
Lift Cylinder	100		
Free Lift Cylinder	102		


CABIN/PLATFORM	PAGE	SERIAL NR. CUT	REV.
Platform	106, 108, 110		
MISCELLANEOUS SERVICE INF.	PAGE	SERIAL NR. CUT	REV.
Labels and Decals	114		



INTRODUCTION

COVERS

COVERS 1 - 2



M0105

INDEX	PART NUMBER	PART NAME	NUMBER REQUIRED
1	813411-002-01	Cover	1
	055055-003	Protection	1
	804307	Lock	1
	803695	Key	1
2	813411-001-01	Cover	1
	055055-003	Protection	1
	804307	Lock	1
	803695	Key	1
3	804862	Buffer	6
4	804338	Battery Lock	2
5	050007-035	Screw	2
6	050008-034	Nut	2
7	804952	Holder	1
8	050068-003	Nut	2
	050025-009	Screw	2
9	804652	Mushroom	1
10	051057-006	Spring	1
11	050009-025	Washer	1
12	050008-030	Nut	1
13	804277	Pin Drift	2
	050011-004	Washer	AR
	050000-009	Pin	2
14	804207	Roller	6
15	804681	Bearing Ball	12
16	804208	Roller Axle	6
17	804432	Battery Connector Assembly (Anderson + 18 & 19)	1
	803673	Battery Connector (Anderson)	1
	803649	Battery Connector Assembly (Schaltbau + 18 & 19)	1
	803546-001	Battery Connector (Schaltbau)	
18	052050-023	Power Cable (B+/Anderson)	1
	052050-081	Power Cable (B+/Schaltbau)	1
	801988-004	Hose Guard (Schaltbau)	1
19	052050-022	Power Cable (B-/Anderson)	1
	052050-080	Power Cable (B-/Schaltbau)	1
	801988-004	Hose Guard (Schaltbau)	1
20	804303	Cover	1
	806506	Clamp	7
	050008-024	Nut	7
21	804863	Nut	2
22	050071-036	Screw	2
23	804423-001-01	Support	1
	050068-003	Nut	2

* To select appropriate part number, refer to truck data number.
The truck data number represents truck features.
Refer to Introduction.



BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**