



SC3200 SERIES PARTS MANUAL



Order Number: 812691-006
Revision: B • Printed in Germany



TABLE OF CONTENTS

TABLE OF CONTENTS

INTRODUCTION	PAGE	SERIAL NO. CUT	REV.
Important customer information	3		
Subsequent Attachments and Modifications made to the Truck	3		
Ordering Spare Parts	3		
Using the Manual	3		
Product Identification Number	4		
COVERS	PAGE	SERIAL NO. CUT	REV.
Covers Part 1 - 5	8	01	Rev. 11/06
Covers Part 2 - 5	10		
Covers Part 3 - 5	12	01	Rev. 11/06
Covers Part 4 - 5	14		
Covers Part 5 - 5	16	01	Rev. 11/06
Seat Part 1 - 2	18	01	Rev. 11/06
Seat Part 2 - 2	20	01	Rev. 11/06
Rear Mirror	22	01	Rev. 11/06
HYDRAULIC SYSTEM	PAGE	SERIAL NO. CUT	REV.
Tube/Hose Layout Part 1 - 4	26		
Tube/Hose Layout Part 2 - 4	28	01	Rev. 11/06
Tube/Hose Layout Part 3 - 4	30		
Tube/Hose Layout	32		
Control Valve Linkage	34		
Control Valve Linkage	36		
Control Lever	38		
Hydraulic Tank	40		
Hydraulic Mast TL Part 1 - 2	42		
Hydraulic Mast TL Part 2 - 2	44		
Hydraulic Mast TL Part 1 - 2	46		
Hydraulic Mast TL Part 2 - 2	48		
Hydraulic Mast TT	50		
Valve Bloc	52		
Lowering Flow Control Manifold	54	01	Rev. 11/06
Counter Balance Valve	56		
Tilt Flow Regulator Valve	58		
Accessory Manifold	60		
Pump	62		
Pump Motor and Pump	64		
Pump Motor	66		
DRIVE UNIT	PAGE	SERIAL NO. CUT	REV.
Gearbox	70		
Gearbox	72		
Drive Motor	74		
Drive Tyres	76	01	Rev. 11/06
ELECTRICAL SYSTEM	PAGE	SERIAL NO. CUT	REV.
Contactor Panel Part 1 - 5	80		
Contactor Panel Part 2 - 5	82		
Contactor Panel Part 3 - 5	84	01	Rev. 11/06

TABLE OF CONTENTS



Contactora Panel Part 4 - 5	86	01 Rev. 11/06
Contactora Panel Part 4 - 5	88	
Contactora Panel Part 5 - 5	90	01 Rev. 11/06
Forward/Reverse Contactora	92	
Line Contactora	94	
Regen Braking Contactora	96	
Mast Wiring Mast TL	98	
Mast Wiring Mast TT	100	
Directional Control	102	
Accelerator	104	01 Rev. 11/06
Emergency Disconnect/Battery Connector	106	01 Rev. 11/06
Instruments	108	
Reverse Alarm	110	
Working Light	112	
Light Rear	114	
Cooling System	116	01 Rev. 11/06
Cooling System Option	118	
BRAKE SYSTEM	PAGE	SERIAL NO. CUT REV.
Brake Pedal	122	01 Rev. 11/06
Brake	124	
Parking Brake	126	
STEERING	PAGE	SERIAL NO. CUT REV.
Steer Wheel	130	01 Rev. 11/06
Steer Axle Up to ser. no. 9A134728	132	9A134728 01 Rev. 11/06
Steer Axle From ser. no. 9A134730	134	9A134730
Steer Axle/Potentiometer	136	
Steering Column Part 1 - 3	138	01 Rev. 11/06
Steering Column Part 2 - 3	140	
Steering Column Part 3 - 3	142	
LIFTING MECHANISM	PAGE	SERIAL NO. CUT REV.
TL Mast	146	
TL Mast Part 1 - 3	148	
TL Mast Part 2 - 3	150	
TL Mast Part 3 - 3	152	
TL Mast - Chain	154	
TT Mast	156	01 Rev. 11/06
TT Mast	158	01 Rev. 11/06
TT Mast	160	
TT Mast	162	01 Rev. 11/06
Fork Carriage TL Mast	164	
Fork Carriage TL Mast	166	01 Rev. 11/06
Fork Carriage TT Mast	168	
Sideshift	170	
Fork Carriage TL Mast	172	
Fork Carriage TL Mast	174	
Fork Carriage TT Mast	176	
Fork Carriage TT Mast	178	01 Rev. 11/06
Fork Carriage TT Mast	180	01 Rev. 11/06
Integrat Sideshift TT Mast	182	01 Rev. 11/06
Fork	184	01 Rev. 11/06





TABLE OF CONTENTS

Load Backrest	186
Yoke TT Mast	188

CYLINDERS	PAGE	SERIAL NO. CUT	REV.
Lift Cylinder Mast TL	192		
Lift Cylinder Mast TL	194		
Lift Cylinder Mast TT	196		
Free Lift Cylinder Mast TT	198		
Tilt Cylinder	200		
Sideshift Cylinder	202		

MISCELLANEOUS	PAGE	SERIAL NO. CUT	REV.
Labels and Decals	206	01 Rev. 11/06



INTRODUCTION

Important customer information

To ensure the safety of the truck, you, the customer, must only carry out maintenance and repairs as stipulated in the operator manual.

Any additional work must be performed by Crown authorised service technicians. Authorised service technicians have the required expertise and up-to-date service information.

If you wish to have your own technicians trained, please contact Crown for relevant training courses.

Subsequent Attachments and Modifications made to the Truck



DANGER

Any proposed modification which would alter the original condition of the truck when delivered, must first be assessed and approved in writing by Crown Gabelstapler GmbH.

- *The net weight and position of attachments may considerably affect the capacity and other truck characteristics.*
- *Changing the electrical system or adding electrically operated components may result in operating faults.*

Modifications which have not been assessed may result in fatal accidents!

Ordering Spare Parts

The maintenance manual does not cover spare parts. These are listed in a separate parts manual.

Spare parts can be ordered by quoting:

- The truck specification number
- The truck model number

The truck serial number This information can be found on the truck's data plate. Only if this information is provided can the order be processed quickly, correctly and reliably.

Please refer to the Technical Specifications Sheet for the utilisable loads, technical data and dimensions for

this series. Brochures can be obtained from your CROWN dealer or from the following address:

CROWN Gabelstapler GmbH & Co.KG
 Moosacher Str. 52
 80809 Munich
 GERMANY

Tel.: +49 (0)89 / 93 002 -0
 Fax: +49 (0)89 / 93 002 -175 or133

Using the Manual

The manual is divided into chapters. The following table shows how the manual is structured.

Manual Structure	
Chapter	Content
ITD	Introduction
1	Covers
2	Hydraulic System
3	Drive Unit
4	Electrical System
5	Brake System
6	Steering
7	Lifting Mechanism
8	Cylinders
9	Platform
10	Miscellaneous

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**