



Service Manual

Our energy working for you.™




Generator Set with PowerCommand® 1301 Controller

C110 D5B/C125 D5/C150 D5
C110 D6/C140 D6
C70 D5/C80 D5/C90 D5/C100 D5
C60 D6/C70 D6/C80 D6/C90 D6

Table of Contents

SECTION	TITLE	PAGE
	IMPORTANT SAFETY INSTRUCTIONS	iii
1	INTRODUCTION	
	About this Manual	1-1
	Generator Set	1-1
	System Overview	1-1
	Test Equipment	1-1
	How to Obtain Service	1-1
2	CONTROL OPERATION	
	General	2-1
	Control Panel Power On/Off Modes	2-1
	Control Panel	2-2
	System Messages	2-5
	Selecting Auto, Manual Run and OFF Modes	2-7
	Operator Menus	2-10
	Service Menus	2-14
	History/About Menu	2-16
	Screen Adjust Menu	2-18
	Fault History Menu	2-20
3	CIRCUIT BOARD	
	General	3-1
	Base Board	3-3
4	TROUBLESHOOTING	
	General	4-1
	InPower Service Tool	4-1
	Network Applications and Customer Inputs	4-1
	Safety Consideration	4-2
	Reading Fault Codes	4-2
	Troubleshooting Procedure	4-3



SECTION	TITLE	PAGE
5	CONTROL ADJUSTMENT AND SERVICE	
	General	5-1
	Circuit Board Removal/Replacement	5-2
	Setup Menu	5-3
	Genset Service Menus	5-4
	Genset Service Submenus	5-6
	Automatic Voltage Regulator Submenus	5-12
	Electronic Governor Submenus	5-14
	Customer I/O Submenus	5-16
	Metering Submenus	5-18
	Genset Setup Submenus	5-27
	Genset Submenus	5-30
	Voltage Protection Submenus	5-36
	Current Protection Submenus	5-38
	Engine Protection Submenus	5-40
	TB1 Base Board Customer Connections	5-46
	Engine Sensors	5-47
	Magnetic Speed Pickup Unit (MPU) Installation	5-48
	Current Transformer (CT) Installation	5-49
6	SERVICING THE GENERATOR	
	Testing the Generator	6-1
	Generator/Base Board Isolation Procedure	6-2
	Generator Disassembly	6-10
	Generator Reassembly	6-12
	Servicing the PMG	6-12
7	WIRING DIAGRAMS	
	General	7-1
A	MENU SEQUENCE DIAGRAMS	
	General	A-1

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**