



Service Manual

Our energy working for you.™



**Power
Generation**

Drill Rig Power Module with PowerCommand® Controller

DQGAC (Spec A)

Table of Contents

1. IMPORTANT SAFETY INSTRUCTIONS	1
1.1 Warning, Caution and Note Styles Used In This Manual	1
1.2 General Information	1
1.3 Safety Code for Drill Rig Power Modules	2
1.4 Electrical Shock Can Cause Severe Personal Injury Or Death.....	3
1.5 Drill Rig Grounding System	4
1.6 Fuel And Fumes Are Flammable	4
2. INTRODUCTION.....	7
2.1 About This Manual.....	7
2.2 Test Equipment.....	7
2.3 Schedule of Abbreviations	7
2.4 Related Literature	9
2.5 After Sales Services	9
3. POWERCOMMAND CONTROL SYSTEM	11
3.1 Control System Description	11
3.2 Operator Panel	14
4. FUEL SYSTEM	17
4.1 Fuel System Operation	17
4.2 Electronic Injectors.....	18
4.3 High Pressure Fuel Pump.....	18
4.4 Fuel Filter Head, Fuel Filters, and Engine Control Modules.....	19
4.5 Electronic Engine Control	21
5. ROLLING PRE-LUBE.....	23
6. CONTROL CALIBRATION AND ADJUSTMENT	25
6.1 General	25
6.2 Adjusting Display Options.....	25
6.3 Speed Control System.....	26
7. TROUBLESHOOTING	27
7.1 Control Unit.....	27
7.2 Safety Considerations.....	27
7.3 Fault Finding	28

7.4 Status Indicators - PowerCommand Control	29
7.5 Fault/Status Codes	29
8. LASER ALIGNMENT.....	53
8.1 Checking Engine/Alternator Alignment	53
9. MANUFACTURING FACILITIES.....	63
APPENDIX A. WIRING DIAGRAMS	65

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**