

# **PARTS MANUAL**

---

## **CHALLENGER**

**H13.00-16.00XM H10.00-  
12.000XM-12EC  
(F019)**

**CUSTOMER EDITION**

---

# ***HYSTER***

**SECTIONS**

<b>1</b>	<b>FRAME</b>
<b>2</b>	<b>ENGINES</b>
<b>3</b>	<b>FUEL SYSTEM</b>
<b>4</b>	<b>ELECTRICAL SYSTEM</b>
<b>5</b>	<b>TRANSMISSION</b>
<b>6</b>	<b>DRIVE AXLE</b>
<b>7</b>	<b>STEERING SYSTEM</b>
<b>8</b>	<b>BRAKE SYSTEM</b>
<b>9</b>	<b>HYDRAULIC SYSTEM</b>
<b>10</b>	<b>MAST-TWO STAGE LIMITED FREE-LIFT</b>
<b>11</b>	<b>MAST-THREE STAGE FULL FREE-LIFT</b>
<b>12</b>	<b>EMPTY CONTAINER HANDLER</b>
<b>13</b>	<b>ATTACHMENTS</b>
<b>14</b>	<b>OPTIONS</b>
<b>15</b>	<b>NUMERICAL INDEX</b>

This Parts Manual is divided into 15 major sections which are listed above. Quick reference to these sections can be made by placing the right thumb on the tab of the desired section, bending the book back and thumbing the pages to the corresponding tab.


**1**

**FRAME**

**SECTION 1  
FRAME**

<b>DESCRIPTION</b>	<b>PAGE</b>
AIR CONDITIONING SYSTEM	
CUMMINS.....	1-32
PERKINS .....	1-30
AIR DUCT AND ACCESSORIES	
CAB.....	1-66
ARMREST	
PIVOT-UP .....	1-58
CAB AND ATTACHING PARTS .....	1-12
CAB AND TILT CYLINDER MOUNTING.....	1-20
CAB HARDWARE AND CONTROL COVER.....	1-60
CONDENSER.....	1-44
COUNTERWEIGHT .....	1-8
DASH DISPLAY .....	1-68
ELECTRIC PUMP .....	1-28
FLOOR PLATES AND COVERS .....	1-10
GENERAL TRUCK .....	1-2
HAND PUMP	
CAB TILT.....	1-26
HEATER AND AIR CONDITIONER ASSEMBLY.....	1-42
HEATER AND AIR CONDITIONER ATTACHMENT .....	1-38
HEATER ARRANGEMENT .....	1-34
HEATER ASSEMBLY .....	1-40
HEATER HOSE ARRANGEMENT	
CUMMINS.....	1-36
HOOD.....	1-4
HYDRAULIC CONTROL AND TWISTLOCK	
EMPTY CONTAINER HANDLER.....	1-62
INCHING PEDAL AND ACCESSORIES	
CAB.....	1-64
LABELS.....	1-70
SEAT ASSEMBLY	
AIR.....	1-46
MECHANICAL .....	1-48
STEEL DOOR	
LEFT HAND.....	1-18
RIGHT HAND.....	1-16
TILT CYLINDER	
CAB.....	1-24
TRAINING SEAT .....	1-54
WINDOW WASHER AND ARMREST ASSEMBLY .....	1-56

## GENERAL TRUCK (Figure 1-1)




HP990129

**GENERAL TRUCK**

ITEM	PART NO.	DESCRIPTION	QTY
1	.....	Frame (☞ Figure 1-2) .....	1
2	.....	Engine Assembly (☞ Figure 2-1) .....	1
3	.....	Fuel System (☞ Figure 3-1) .....	1
4	.....	Electrical System (☞ Figure 4-1) .....	1
5	.....	Transmission (☞ Figure 5-1) .....	1
6	.....	Drive Axle (☞ Figure 6-1) .....	1
7	.....	Steering System (☞ Figure 7-1) .....	1
8	.....	Brake System (☞ Figure 8-1) .....	1
9	.....	Hydraulic System (☞ Figure 9-1) .....	1
10	.....	Mast-Two Stage Limited Free-Lift (☞ Figure 10-1) .....	1
11	.....	Empty Container Attachments (☞ Figure 12-2) .....	1
12	.....	Attachments (☞ Figure 13-1) .....	1
13	.....	Options (☞ Figure 14-1) .....	1
14	.....	Numerical Index.....	1

## HOOD (Figure 1-2)



BP120122

**HOOD**

ITEM	PART NO.	DESCRIPTION	QTY
1	362030	Handle .....	2
2	1477508	Bracket.....	1
3	292501	Capscrew.....	4
4	320156	Washer .....	4
5	292680	Lockwasher.....	4
6	136687	Nut .....	4
7	292528	Capscrew.....	4
8	1479870	Screw (Stop).....	4
9	136692	Nut .....	4
10	320157	Washer .....	2
11	292681	Lockwasher.....	4
12	1489092	Screw (Stop).....	2
13	216877	Nut .....	10
14	239503	Nut .....	4
15	376397	Nut .....	2
16	18498	Capscrew.....	2
17	1479871	Washer .....	2
18	292535	Capscrew.....	AR
19	300088	Seal (Door) .....	8
20	320162	Washer .....	8
21	292683	Lockwasher.....	10
22	1554208	Channel .....	1
23	1476910	Hood (RH) .....	1
24	1385584	Gas Spring.....	2
25	1476911	Hood (LH).....	1
26	1478959	Rod .....	2
27	1489401	Support.....	1
28	1477512	Bracket.....	1
29	1494868	Plug (Without Air Conditioner) .....	4
30	1494869	Plug (Without Air Conditioner) .....	3
31	1382332	Latch .....	2
32	1494480	Bracket.....	2
33	320155	Washer .....	4
34	296155	Capscrew.....	4
35	292679	Lockwasher.....	4
36	292668	Nut .....	4
37	320160	Washer .....	4
38	292682	Lockwasher.....	4
39	136692	Nut .....	4
40	a 1382766	Wrench (Hood Latch) .....	1
41	309666	Plug .....	2
42	1494642	Shim .....	AR
42	1494643	Shim .....	AR
42	1494645	Shim .....	AR
43	320158	Washer .....	AR
44	1587730	Sound Liner (LH) (EEC) .....	1
45	1587731	Sound Liner (RH) (EEC).....	1
46	1587727	Sound Liner (LH) (EEC) .....	1
47	1587726	Sound Liner (RH) (EEC).....	1
48	1587734	Sound Liner (LH) (EEC) .....	1
49	1587735	Sound Liner (RH) (EEC).....	1




## HOOD

ITEM	PART NO.	DESCRIPTION	QTY
50	1498373	Plate (EEC).....	28
51	136985	Capscrew (EEC).....	28
52	1593327	Spacer (EEC) .....	28

**FOOTNOTES:**

a Not Illustrated

## COUNTERWEIGHT (Figure 1-3)




HP120578

**COUNTERWEIGHT****KEY:****A: H13.00XM-14.00XM/H10.00-EC****B: H16.00XM/12.00-EC****C: H12.00-EC**

ITEM	PART NO.	DESCRIPTION	QTY		
			A	B	C
1	2038857	Fender (LH) .....	1	1	1
2	2038858	Fender (RH) .....	1	1	1
3	292597	Capscrew .....	4	4	4
4	1475872	Washer .....	4	4	4
5	316829	Nut .....	4	4	4
6	1301086	Washer .....	4	4	4
7	1467696	Tow Pin .....	1	1	1
8	1495368	Grip .....	1	1	1
9	302440	Pin .....	1	1	1
10	816231	Stop .....	..	..	4
11	1475214	Shim .....	AR	AR	AR
12	221786	Washer .....	1	1	1
13	15170	Lockwasher .....	1	1	1
14	15189	Washer .....	1	1	1
15	280472	Sealant .....	AR	AR	AR
16	1475211	Shim .....	AR	AR	AR
17	1475212	Shim .....	AR	AR	AR
18	1475213	Shim .....	AR	AR	AR
19	1467625	Counterweight .....	1	..	..
19	1467626	Counterweight .....	..	1	1
20	1453469	Capscrew .....	1	..	..
20	1453470	Capscrew .....	..	1	1
21	2045338	Counterweight (RH) .....	1	1	1
21	2045336	Counterweight (LH) .....	1	1	1
22	1485676	Plate .....	2	2	2
23	292689	Lockwasher .....	2	2	2
24	292612	Capscrew (127 mm) .....	2	2	2
25	216877	Nut .....	..	..	4
26	296130	Nut .....	..	..	4
27	816136	Counterweight (RH) .....	..	..	1
28	816137	Counterweight (LH) .....	..	..	1
29	293696	Capscrew .....	..	..	4
30	816138	Washer .....	..	..	4
31	1331575	Washer .....	..	..	4
32	316828	Nut .....	..	..	4
33	1373270	Isolator .....	..	..	4
34	1532632	Liner (LH) .....	1	1	1
35	1532633	Liner (RH) .....	1	1	1

## FLOOR PLATES AND COVERS (Figure 1-4)



HP120674


**FLOOR PLATES AND COVERS**

ITEM	PART NO.	DESCRIPTION	QTY
1	320162	Washer .....	18
2	296173	Capscrew.....	6
3	287837	Capscrew.....	6
4	216735	Grommet.....	6
5	320160	Washer .....	6
6	1491360	Seal .....	AR
7	320158	Washer .....	42
8	296167	Capscrew.....	14
9	1480237	Clip Nut.....	14
10	325983	Trim .....	AR
11	292681	Lockwasher.....	2
12	296012	Capscrew.....	8
13	302402	Nut .....	6
14	136749	Capscrew.....	4
15	1532341	Gas Spring.....	1
16	302400	Locknut .....	10
17	2071326	Cover .....	1
18	91946	Grommet.....	8
19	1529665	Capscrew.....	2
20	1529664	Running Board (LH).....	1
21	1529663	Running Board (RH) .....	1
22	1532449	Extension (LH) .....	1
23	1532447	Extension (RH) .....	1
24	1485265	Cover .....	1
25	1485263	Panel (LH).....	1
26	1485264	Panel (RH) .....	1
27	1529751	Cover (Battery Box) .....	1
28	1532202	Battery Box .....	1
29	<b>a</b> 136692	Nut .....	8
30	<b>a</b> 292682	Lockwasher.....	8
31	<b>a</b> 320160	Washer .....	8
32	<b>a</b> 1515432	Cover (Rear) .....	1
33	<b>a</b> 1562201	Cover (Bottom) .....	1
34	<b>a</b> 1562209	Liner.....	1
35	<b>a</b> 1562210	Liner.....	1
36	<b>a</b> 1562212	Liner.....	1
37	<b>a</b> 1562205	Liner.....	1
38	329069	Nut .....	2
39	288762	Tape.....	AR

**FOOTNOTES:**

**a** H13.00XM-6, H14.00XM-6, H16.00XM-6

## CAB AND ATTACHING PARTS (Figure 1-5)



HP120624

**CAB AND ATTACHING PARTS**


ITEM	PART NO.	DESCRIPTION	QTY
1	1558020	Bar (LH) (Hold-Open) (Lower) .....	1
1	1558021	Bar (RH) (Hold-Open) (Lower).....	1
2	1492239	Bolt .....	8
3	320158	Washer .....	10
4	1476584	Cap .....	6
5	1493313	Bumper .....	2
6	1558023	Bar (RH) (Hold-Open) (Upper) .....	1
6	1558022	Bar (LH) (Hold-Open) (Upper) .....	1
7	1493316	Bumper .....	2
8	316835	Nut .....	2
9	1476584	Cap .....	6
10	.....	Window Assembly (Curved Window_ .....	1
10	1493320	Windshield (Tempered) .....	1
10	1498750	Seal Kit.....	1
10	2046118	Windshield (Laminated).....	1
10	1498750	Seal Kit.....	1
10	2046119	Flat Glass Kit (Service Option) .....	1
10	1498750	Seal Kit.....	1
11	1493323	Window Assembly (Rear) .....	1
11	1493324	Window (Rear) (Curved) .....	1
11	1498750	Seal Kit.....	1
12	1558024	Window (Skylight) (Laminated).....	1
13	1515337	Seal .....	AR
13	1393463	Seal (Optional).....	AR
14	1498339	Sealant .....	AR
15	1498341	Seal .....	1
16	1498342	Washer .....	5
17	1493328	Clip .....	1
18	1493329	Cover .....	3
19	1493397	Cover .....	8
20	316834	Nut .....	8
21	1498343	Clip .....	3
22	320156	Washer .....	3
23	1493344	Wiper Motor .....	1
24	1498347	Wiper Arm.....	1
25	1498348	Wiper Blade .....	1
26	1493336	Connector .....	6
27	1493337	Hose .....	9
28	1507003	Nozzle (Top) .....	1
29	1493332	Wiper Motor .....	1
30	1493333	Linkage .....	1
31	1493334	Wiper Arm.....	1
32	1493335	Wiper Blade .....	1
33	1507005	Nozzle (Front).....	1
34	1493339	Wiper Motor .....	1
35	1493340	Wiper Blade .....	1
36	1493341	Wiper Arm.....	1
37	2043546	Wire Harness (Rear Wiper) .....	1
38	1498344	Washer (Nozzle) .....	1
39	1393473	Hinge (LH) .....	2
39	.....	Pin (Hinge) .....	2

**CAB AND ATTACHING PARTS**

<b>ITEM</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>	<b>QTY</b>
40	1393474	Hinge (RH).....	2
40	. . . . .	Pin (Hinge) .....	2
41	1493308	Bolt .....	12
42	1468312	Washer .....	4
43	1553405	Door Assembly (LH) .....	1
43	1553404	Door Assembly (RH).....	1
44	1493272	Air Filter Cover.....	1
44	1493274	Cover .....	1
45	1558028	Air Filter .....	1
46	293613	Capscrew .....	3
47	320156	Washer .....	3
48	1493318	Bolt Assembly (Striker) .....	2
48	1504953	Block.....	1
48	1504954	Guard (Striker Bolt) .....	1
48	1504955	Bolt (Striker) .....	1
49	1493307	Frame (Cab) .....	1



## STEEL DOOR (Figure 1-6) RIGHT HAND




BP120062

**STEEL DOOR  
RIGHT HAND**

ITEM	PART NO.	DESCRIPTION	QTY
	1553404	Door Assembly (RH).....	1
1	1558292	Frame .....	1
2	1515337	Seal .....	5
3	1558293	Window (Main) .....	1
4	1558294	Seal .....	1
5	1558295	Window (Lower) .....	1
6	1558296	Frame (Window) (Lower).....	1
7	1558297	Window (Upper) .....	1
8	1558298	Frame (Window) (Upper).....	1
9	1558299	Seal .....	4
10	1495371	Handle (Push Button).....	1
11	1495372	Seal .....	1
12	1495431	Seal .....	1
13	287816	Capscrew .....	1
14	1468321	Washer .....	1
15	1558300	Cap.....	1
16	1558301	Latch Assembly .....	1
17	296229	Capscrew .....	2
18	1558302	Plate (Door Handle).....	1
19	1558303	Washer .....	1
20	1558304	Screw .....	1
21	1495435	Cover.....	1
22	1558305	Remote Control (Door Handle).....	1
23	1558306	Rod (Connector).....	1
24	1497241	Hold-Open .....	1
25	1495454	Seal .....	1
26	1558307	Screw .....	3
27	1506738	Washer .....	3
28	316834	Nut.....	3
29	1493397	Cover.....	3

## STEEL DOOR (Figure 1-7) LEFT HAND




BP120063

**STEEL DOOR  
LEFT HAND**

ITEM	PART NO.	DESCRIPTION	QTY
	1553405	Door Assembly (LH) .....	1
1	1558440	Frame .....	1
2	1515337	Seal .....	5
3	1558441	Window (Main) .....	1
4	1558294	Seal .....	AR
5	1558442	Window (Door) (Lower) .....	1
6	1558443	Frame (Window) (Lower) .....	1
7	1558444	Window (Door) (Upper) .....	1
8	1558445	Frame (Window) (Upper) .....	1
9	1558299	Seal .....	4
10	1495371	Handle (Push Button) .....	1
10	1507006	Key .....	1
11	1495372	Seal .....	1
12	1495431	Seal .....	1
13	287816	Capscrew .....	1
14	1468321	Washer .....	1
15	1558300	Cap .....	1
16	1558446	Latch Assembly .....	1
17	296229	Capscrew .....	2
18	1558302	Plate .....	1
19	1558303	Washer .....	1
20	1558304	Screw .....	1
21	1495438	Cover .....	1
22	1558305	Remote Control .....	1
23	1558447	Rod (Connector) .....	1
24	1495453	Hold-Open .....	1
25	1495454	Seal .....	1
26	1558307	Screw .....	3
27	1506738	Washer .....	3
28	316834	Nut .....	3
29	1493397	Cover .....	3

## CAB AND TILT CYLINDER MOUNTING (Figure 1-8)



BP120080


**CAB AND TILT CYLINDER MOUNTING****KEY:****A: Manual Tilt****B: Power Tilt**

ITEM	PART NO.	DESCRIPTION	QTY	
			A	B
1	2043194	Tilt Cylinder (Cab) (☞ Figure 1-9) .....	1	..
2	1486535	Hand Pump (☞ Figure 1-10) .....	1	..
3	1487204	Handle (Used With Item #2) .....	1	..
4	136692	Nut .....	1	1
5	370776	Switch (Momentary).....	..	1
6	1474921	Shaft .....	1	..
7	1496296	Swivel .....	1	1
8	1480186	Pump Assembly.....	..	1
8	1475732	Pump (Tilt) (☞ Figure 1-11) .....	..	1
8	.....	Hose.....	..	1
8	1480187	Connector.....	..	1
8	1480188	Secondary Lock.....	..	1
8	1484709	Terminal (Pin) .....	..	2
9	1485271	Bracket.....	..	1
10	1486540	Mount.....	4	4
11	2049849	Wire Harness (Tilt Cab) (☞ Figure 4-17) .....	..	1
12	1486630	Pin .....	1	1
13	320169	Washer .....	1	1
14	15235	Cotter Pin.....	2	2
15	292681	Lockwasher.....	8	2
16	287851	Capscrew.....	2	2
17	292682	Lockwasher.....	3	3
18	292514	Capscrew.....	2	2
19	300939	Washer .....	4	4
20	296382	Washer .....	4	4
21	292535	Capscrew.....	4	4
22	1486539	Latch .....	2	2
23	195566	Anchor .....	1	1
24	1520841	Shim .....	2	2
25	1486067	Hose .....	1	1
26	1486068	Hose .....	1	1
27	1486069	Hose .....	1	1
28	1486070	Hose .....	1	1
29	320157	Washer .....	8	8
30	176640	Capscrew.....	7	7
31	136749	Capscrew.....	1	1
32	239503	Nut .....	7	7
33	1496296	Swivel .....	1	1
34	1488675	Fitting.....	1	1
35	1488676	Fitting.....	2	2
36	292517	Capscrew.....	1	1
37	1486825	Platform .....	1	..
37	1493322	Adhesive (Not Illustrated) .....	AR	AR
38	1493379	Frame .....	1	1
39	1493380	Bearing.....	2	2
40	1493381	Rod (Release).....	1	1

## CAB AND TILT CYLINDER MOUNTING

ITEM	PART NO.	DESCRIPTION	QTY	
			A	B
41	1493382	Catch (Tilt).....	1	1
42	1493383	Knob.....	1	1
43	1493384	Retaining Ring.....	1	1
44	1493385	Spring (Compression) .....	1	1
45	1493386	Washer .....	2	2
46	1493387	Cotter Pin .....	1	1
47	2004005	Strap Clamp.....	..	1
48	1496459	Fitting.....	..	1
49	1496368	Hose .....	..	1
50	137852	Strap Clamp.....	..	1
51	397676	Strap Clamp.....	AR	AR
52	1393802	Clamp .....	1	1
52	. . . . .	Capscrew.....	1	1
53	18515	Washer .....	1	1
54	15155	Lockwasher.....	1	1
55	15055	Nut .....	1	1

## ELECTRIC PUMP (Figure 1-11)




HP120584



**ELECTRIC PUMP**

ITEM	PART NO.	DESCRIPTION	QTY
	1475732	Pump .....	1
1	.....	Coupler.....	1
2	1488736	Hose .....	1
3	1488735	Filter.....	1
4	.....	Screen .....	1
5	.....	Ball.....	1
6	1488730	Spring.....	1
7	.....	Coupler .....	1
8	.....	Coupler .....	1
9	1488727	O-Ring .....	1
10	1488726	Motor .....	1
	1488728	Service Kit (Includes Items 3-8).....	1
	1488725	Motor Kit (Includes Items 9-10) .....	1

## AIR CONDITIONING SYSTEM (Figure 1-12) PERKINS




BP120034

**AIR CONDITIONING SYSTEM  
PERKINS**

ITEM	PART NO.	DESCRIPTION	QTY
1	1538218	Condensor (☞ Figure 1-19) .....	1
2	320157	Washer .....	1
3	292681	Lockwasher.....	1
4	176640	Capscrew.....	4
5	1485958	Hose .....	1
6	1487118	O-Ring .....	4
7	1486637	Pressure Switch.....	1
8	303493	Grommet.....	3
9	125303	Hose .....	1
10	255578	Clamp .....	1
11	153069	Clamp .....	1
12	239503	Nut .....	1
13	1487122	O-Ring .....	2
14	2033612	Strap Clamp.....	6
15	1485956	Hose .....	1
16	1485955	Hose .....	1
17	1487125	O-Ring .....	2
18	320159	Washer .....	10
19	292682	Lockwasher.....	7
20	287854	Capscrew.....	5
21	1390281	Capscrew.....	1
22	292515	Capscrew.....	1
23	1480318	Compressor .....	1
24	1510210	Bracket.....	1
25	136692	Nut .....	3
26	1532139	Heat Shield .....	1
27	114310	Hose .....	1
28	199337	Hose .....	1
29	320158	Washer .....	2
30	1480245	Hose .....	1
31	1485953	Hose .....	1
32	132861	Capscrew.....	1
33	1384698	Clamp .....	2
34	385107	Clamp (Insulated) .....	1
35	1538217	Dryer.....	1

## AIR CONDITIONING SYSTEM (Figure 1-13) CUMMINS




HP020615

**AIR CONDITIONING SYSTEM  
CUMMINS**

ITEM	PART NO.	DESCRIPTION	QTY
1	1538218	Condensor .....	1
2	385107	Clamp (Insulated) .....	1
3	129563	Strap Clamp .....	6
4	166857	Clamp .....	2
5	1480318	Compressor .....	1
6	1538217	Dryer .....	1
7	1384698	Clamp .....	2
8	1485958	Hose .....	1
9	1487118	O-Ring .....	4
10	1487122	O-Ring .....	2
11	1487125	O-Ring .....	2
12	320157	Washer .....	6
13	292681	Lockwasher.....	7
14	239503	Nut .....	3
15	176640	Capscrew.....	5
16	320158	Washer .....	2
17	303493	Grommet.....	3
18	1485953	Hose .....	1
19	1514338	Hose .....	1
20	114310	Hose .....	1
21	199337	Hose .....	1
22	2004005	Strap Clamp.....	AR
23	166857	Clamp .....	2
24	1514341	Hose .....	1
25	2046918	V-Belt.....	1
26	1500869	Sheave (Belt) .....	1
27	1500871	Bracket.....	1
28	1500870	Bracket.....	2
29	1373791	Spacer .....	2
30	1359458	Capscrew.....	2
31	287860	Capscrew.....	4
32	136692	Nut .....	6
33	320159	Washer .....	7
34	292682	Lockwasher.....	6
35	16816	Capscrew.....	3
36	15134	Washer .....	3
37	15156	Lockwasher.....	3

## HEATER ARRANGEMENT (Figure 1-14)




HP120585

**HEATER ARRANGEMENT**

ITEM	PART NO.	DESCRIPTION	QTY
1	1316496	Clamp .....	1
2	132861	Capscrew.....	1
3	320158	Washer .....	2
4	292681	Lockwasher.....	1
5	239503	Nut .....	1
6	16156	Fitting.....	2
7	130845	Clamp .....	4
8	125303	Hose .....	1
9	1480245	Hose .....	1
10	1309524	Bracket.....	1
11	136749	Capscrew.....	1
12	292681	Lockwasher.....	3
13	320157	Washer .....	2
14	239503	Nut .....	3
15	198678	Clamp .....	2
16	136681	Capscrew.....	2

## HEATER HOSE ARRANGEMENT (Figure 1-15) CUMMINS




HP120616



**HEATER HOSE ARRANGEMENT  
CUMMINS**

ITEM	PART NO.	DESCRIPTION	QTY
1	130845	Clamp .....	4
2	1316496	Clamp .....	1
3	132861	Capscrew.....	1
4	320158	Washer .....	4
5	292681	Lockwasher.....	1
6	239503	Nut .....	1
7	17742	Fitting.....	2
8	16156	Fitting.....	1
9	127852	Fitting.....	1
10	224060	Hose .....	1
11	258488	Hose .....	1

## HEATER AND AIR CONDITIONER ATTACHMENT (Figure 1-16)




BP120064

**HEATER AND AIR CONDITIONER ATTACHMENT**

ITEM	PART NO.	DESCRIPTION	QTY
1	1558032	Heater Assembly (☞ Figure 1-17) .....	1
1	1558045	Heater And Air Conditioning Assembly (☞ Figure 1-18) .....	1
2	1558033	Control Panel (Heater) (☞ Figure 4-3) .....	1
2	1558046	Control Panel (Air Conditioning) (☞ Figure 4-4) .....	1

## HEATER ASSEMBLY (Figure 1-17)




HP120741

**HEATER ASSEMBLY**

ITEM	PART NO.	DESCRIPTION	QTY
	1558032	Heater Assembly .....	1
1	1560537	Blower .....	1
2	1453031	Resistor .....	1
3	1560623	Core (Heater) .....	1
4	1560624	Hose (Water Valve) .....	1
5	1560625	Water Valve .....	1
6	1560626	Cable (Push Pull) .....	1
7	1560547	Adapter (Hose) .....	1
8	1560548	Rivet .....	1
9	1560627	Wire Harness .....	1
10	. . . . .	Connector .....	1
11	1560552	Bearing .....	1
12	1560553	Clip .....	1
13	1560554	Cable (Push Pull) .....	1
14	1560555	Rotary Control .....	1
15	1560556	Clip .....	1

## HEATER AND AIR CONDITIONER ASSEMBLY (Figure 1-18)



HP120742

**HEATER AND AIR CONDITIONER ASSEMBLY**

ITEM	PART NO.	DESCRIPTION	QTY
	1558045	Heater And Air Conditioning Assembly.....	1
1	1560537	Blower .....	1
2	1453031	Resistor .....	1
3	1560538	Thermostat .....	1
4	1560539	Heater Core.....	1
5	1560540	Evaporator Core .....	1
6	1560541	Motor (Water Valve).....	1
7	1560542	Coupling .....	1
8	1560543	Water Valve .....	1
9	1560544	Hose .....	1
10	1560545	Hose .....	1
11	1560546	Controller (Water Valve) .....	1
12	1560547	Adapter .....	1
13	1560548	Rivet .....	1
14	1560549	Wire Harness .....	1
15	1560550	Wire Harness .....	1
16	. . . . .	Connector.....	1
17	1560552	Bearing.....	1
18	1560553	Clip .....	1
19	1560554	Cable .....	1
20	1560555	Rotary Control .....	1
21	1560556	Clip .....	1

**BUY NOW**

**Then Instant Download  
the Complete Manual  
Thank you very much!**