

283 COTTON STRIPPER




JOHN DEERE

TECHNICAL MANUAL 283 COTTON STRIPPER

TM1126 (01MAY79) English

DES MOINES WORKS
TM1126 (01MAY79)

LITHO IN THE U.S.A.
ENGLISH



283 COTTON STRIPPER
Technical Manual
TM-1126 (May-79)

CONTENTS

INTRODUCTION	2
SAFETY AND YOU	3
GENERAL INFORMATION	4-5
Description	4
Lubrication	5
DIAGNOSING AND TESTING	6-7
Organizing the Diagnosis	6
Diagnosing	6-7
ROW UNIT STRIP ROLLS AND BEARING	8-10
General Information	8
Front Bearing Removal	8
Rear Bearing Removal	9
Strip Roll Removal	9
Adjustments	9-10
ROW UNIT AUGERS AND BEARINGS	10-12
General Information	10
Front Bearing Removal	10
Rear Bearing Removal	11
Auger Removal	12
Cross Auger Belt Adjustment	12
CROSS AUGER	13-14
General Information	13
Removal	13
Installation	14
MAIN DRIVE COMPONENTS	14-17
General Information	14
Four-Sheave Cluster	14-16
Countershaft	16-17
FAN	17-19
General Information	17
Fan Removal	17-18
Fan Installation	18
TELESCOPING DRIVE SHAFTS	19
HEIGHT CONTROL SYSTEM	20
General Information	20
Preliminary Testing	20-21
Hydraulic Cylinders	21
Control Valve	23
BOLL BOX ATTACHMENT	27
General Information	27
Removal	27
BASKET AND BOLL BOX HYDRAULIC CYLINDERS	28
SPECIFICATIONS	30

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

**Copyright © 1979
Deere & Company
Moline, Illinois
All rights Reserved**

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**