

3805 AND 3807 KNUCKLEBOOM LOADERS




JOHN DEERE

TECHNICAL MANUAL 3805 AND 3807 KNUCKLEBOOM LOADERS

TM1028 (01APR70) English

TM1028 (01APR70)

LITHO IN THE U.S.A.
ENGLISH



3805-3807
Knuckleboom Loaders
Technical Manual
TM-1028 (Apr-70)

CONTENTS

Section 10 - GENERAL

- Group 5 - Specifications
- Group 10 - Lubrication

Section 20 - HYDRAULIC SYSTEM

- Group 5 - General Information, Testing and Diagnosis
- Group 10 - Hydraulic Pump
- Group 15 - Reservoirs and Filters
- Group 20 - Hydraulic Cylinders
- Group 25 - Boom Swing Cylinder
- Group 30 - Grapple Swing Cylinder
- Group 35 - Upper Control Valve
- Group 40 - Lower Control Valve
- Group 45 - Swivel Assembly, Relief Valve, and Flow Divider

Section 30 - MISCELLANEOUS

- Group 5 - Mast and Main Frame
- Group 10 - Operator's Platform and Grapple Assembly

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**