

4300 Beet Harvester



JOHN DEERE

TECHNICAL MANUAL 4300 Beet Harvester

TM1120 (01OCT75) English

TM1120 (01OCT75)

LITHO IN U.S.A. (N) REVISED
ENGLISH



4300 BEET HARVESTER

TECHNICAL MANUAL
TM-1120 (Oct-75)

CONTENTS

INTRODUCTION

SAFETY

SECTION 10 - GENERAL

- Group 5 - Description
- Group 10 - Specifications
- Group 15 - Lubrication
- Group 20 - Diagnosing Malfunctions

SECTION 20 - DRIVE TRAIN

- Group 5 - General Information
- Group 10 - Powershaft
- Group 15 - Main Gear Case
- Group 20 - L.H. Drive Components
- Group 25 - R.H. Drive Components
- Group 30 - Vertical Auger, Gear Case, and Slip Clutch
- Group 35 - Flail Gear Case
- Group 40 - Specifications and Torque Values

SECTION 30 - HYDRAULIC SYSTEM

- Group 5 - General Information and Flow Diagrams
- Group 10 - Hydraulic Motor and Truck Conveyor Drive
- Group 15 - Hydraulic Row Finder
- Group 20 - Specifications and Torque Values

SECTION 40 - MISCELLANEOUS

- Group 5 - Star Wheel Cleaning Bed
- Group 10 - Grab Rolls
- Group 15 - Electromagnetic Clutch
- Group 20 - Pedestal and Lifter Wheels
- Group 25 - Rear Wheels
- Group 30 - Vertical Auger
- Group 35 - Specifications and Torque Values

SECTION 50 - ALPHABETICAL INDEX

The specifications and design information contained in this manual were correct at the time this machine was manufactured. It is John Deere's policy to continually improve and update our machines. Therefore, the specifications and design information are subject to change without notice. Wherever applicable, specifications and design information are in accordance with SAE and IEMC standards.

FOR YOUR CONVENIENCE

Vertical lines appear in the margins of many of the pages. These lines identify new material and revised information that affects specifications, procedures, and other important instructions.

Copyright © 1975
DEERE & COMPANY
Moline, Illinois
All rights reserved

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**