



40 Rotary Tiller



JOHN DEERE

TECHNICAL MANUAL

40
Rotary Tiller

TM1232 (01NOV79) English

John Deere Horicon Works
TM1232 (01NOV79)

LITHO IN U.S.A.
ENGLISH



TABLE OF CONTENTS

	Page		Page
INTRODUCTION	2	REPLACING TINES AND DRIVE COMPONENTS	9
DESCRIPTION	2	Replacing Tines	9
SPECIFICATIONS	3	Replacing Shear Bolts	9
Tiller Specifications	3	Replacing Drive Chains	9
Tractor Requirements	3	Replacing Drive Shaft Bearings	11
SERIAL NUMBERS	3	Replacing Tine Shaft Rotor Bearings	12
Tiller Serial Number	3	Replacing Tine Shaft Rotor	12
Gear Case Serial Number	3	SERVICING GEAR CASE	13
TORQUE CHARTS	4	Removing Gear Case	13
Bolt Torque Chart	4	Disassembling Gear Case	15
Set Screw Seating Torque Chart	4	Inspecting Gear Case Parts	17
LUBRICATION	5	Assembling Gear Case	18
Gear Case	5	Installing Gear Case	20
Grease Fittings	5	Lubricating Gear Case and Powershaft	22
Chain Case	5	SERVICING POWERSHAFT	23
Hinge or Pivot Points	5	Removing Powershaft from Tiller	23
ADJUSTMENTS	6	Disassembling Powershaft	23
Leveling Tiller Side-to-Side	6	Inspecting Powershaft Parts	26
Leveling Tiller Front-to-Rear	6	Assembling Powershaft	27
Adjusting Sway Chains	7	Installing Powershaft	29
Adjusting Drive Chain Tensioners	7	Lubricating Powershaft	29
DIAGNOSING MALFUNCTIONS	8		

OOA

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**