

40 Series Corn Head Gear Case



JOHN DEERE

TECHNICAL MANUAL

40 Series Corn Head
Gear Case

TM1027 (01JUL72) English

TM1027 (01JUL72)

LITHO IN U.S.A. (REVISED)
ENGLISH



40 SERIES CORN HEAD GEAR CASE

Technical Manual
TM-1027 (Jul-72)

CONTENTS

	Page
GENERAL	2-3
Introduction	2
Description	2
Lubrication	2
Diagnosing Malfunctions	3
REMOVAL	4
SERVICING GEAR CASE	5-13
Disassembly	5-6
Inspection	6
Replacing Bearings and Bushings	6-9
Assembly	10-13
SERVICING BARREL ASSEMBLY AND STALK ROLL SHAFTS	14-17
Disassembly	14
Inspection and Repair	14-15
Attaching Barrel Assembly to Gear Case	16-17
INSTALLATION	17
SPECIFICATIONS	18
Special Tools	18
MAKING SPECIAL TOOLS	19

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**