



Service Manual



Our energy working for you.™

Generator Set with PowerCommand® Control PCC2100

GGPA (Spec A)
GGPB (Spec A)
GGPC (Spec A)

Table of Contents

1. IMPORTANT SAFETY INSTRUCTIONS	1
1.1 Warning, Caution and Note Styles Used In This Manual	1
1.2 General Information	1
1.3 Generator Set Safety Code	2
1.4 Electrical Shock Can Cause Severe Personal Injury Or Death.....	3
1.5 Fuel And Fumes Are Flammable	4
1.6 Exhaust Gases Are Deadly.....	5
2. INTRODUCTION.....	7
2.1 About This Manual	7
2.2 Test Equipment.....	7
2.3 Schedule of Abbreviations	7
2.4 Related Literature	9
2.5 After Sales Services.....	9
3. CONTROL SYSTEM - PCC 2100	11
3.1 Control System Description	11
3.2 Control Panel Power On/Off Modes	12
3.3 Front Panel	13
3.4 Control Menus.....	17
4. CIRCUIT BOARDS.....	37
4.1 General	37
4.2 Base Board	40
4.3 Connector J1.....	40
4.4 Connector J2.....	41
4.5 Connector J3.....	42
4.6 Connector J4.....	43
4.7 Connector J7.....	44
4.8 Connector J8.....	45
4.9 TB1 Customer Connections.....	46
5. TROUBLESHOOTING	47
5.1 General	47
5.2 Safety Considerations.....	47
5.3 InPower Service Tool.....	47

5.4 Network Applications and customer inputs.....	48
5.5 Troubleshooting Procedure.....	48
5.6 Relay K1	51
5.7 Relay K4	51
5.8 Relay K6	51
5.9 Engine Lacks Power or Is Unstable (No Fault Message).....	51
5.10 Fault Code 121 - Speed Signal Lost.....	52
5.11 Fault Code 135 - Oil Pressure Sensor High	53
5.12 Fault Code 143 - Pre-Low Oil Pressure Sensor	54
5.13 Fault Code 141 - Oil Pressure Sensor Low	55
5.14 Fault Code 144 - Coolant Temperature Sensor High	55
5.15 Fault Code 145 - Coolant Temperature Sensor Low.....	56
5.16 Fault Code 146 - Pre-High Cool Temp	57
5.17 Fault Code 151 - High Coolant Temp.....	57
5.18 Fault Code 197 - Low Coolant Level	58
5.19 Fault Code 234 - Overspeed	59
5.20 Fault Code 235 - Low Coolant Level	59
5.21 Fault Code 359 - Fail to Start	60
5.22 Fault Code 415 - Low Oil Pressure	63
5.23 Fault Code 441 - Low Battery Voltage.....	64
5.24 Fault Code 442 - High Battery Voltage.....	65
5.25 Fault Code 1123 - Shutdown After Battle Short	66
5.26 Fault Code 1124 - Delayed Shutdown.....	66
5.27 Fault Code 1131 - Battle Short Active	66
5.28 Fault Code 1311, 1312, 1317 - Customer Input #1#3	66
5.29 Fault Code 1318 - Service Engine Fault.....	67
5.30 Fault Code 1334 - Crit Scaler OR.....	69
5.31 Fault Code 1335 - Non-Crit Scaler OR.....	69
5.32 Fault Code 1416 - Fail to Shutdown	69
5.33 Fault Code 1417 - Power Down Error	70
5.34 Fault Code 1433 - Emergency Stop	70
5.35 Fault Code 1434 - Remote Emergency Stop.....	70
5.36 Fault Code 1435 - Low Coolant Temperature	70
5.37 Fault Code 1438 - Fail to Crank	71
5.38 Fault Code 1442 - Weak Battery	72
5.39 Fault Code 1443 - Battery Failed.....	73

5.40 Fault Code 1444 - kW Overload	73
5.41 Fault Code 1445 - Short Circuit	73
5.42 Fault Code 1446 - High AC Voltage	74
5.43 Fault Code 1447 - Low AC Voltage	74
5.44 Fault Code 1448 - Under Frequency	75
5.45 Fault Code 1449 - Over Frequency	75
5.46 Fault Code 1461 - Loss of Field	76
5.47 Fault Code 1466 - Modem Failure	76
5.48 Fault Code 1468 - Network Error.....	76
5.49 Fault Code 1469 - Speed/Hz Match	76
5.50 Fault Code 1471 - Over Current	76
5.51 Fault Code 1472 - Over Current	77
5.52 Fault Code 2323–2326 - Network Fault 5 through 8	77
5.53 Fault Code 2335 - Excitation Fault	77
5.54 Fault Code 2336 - Memory Error.....	77
5.55 Fault Code 2341 - High Control Temperature	77
5.56 Fault Code 2342 - Too Long in Idle	77
5.57 Fault Code 2967 - Governor Fault.....	77
5.58 Fault Code 2968 - AVR Fault	78
5.59 Fault Code 2969 - LON Failure.....	78
5.60 Fault Code 2972 - Field Overload.....	78
 6. CONTROL ADJUSTMENT AND SERVICE	79
6.1 General	79
6.2 Circuit Board Removal/Replacement.....	79
6.3 Modifying Setup Submenus	80
6.4 Password Submenu.....	81
6.5 Crank/Idle Setup Menu	83
6.6 Governor/Regulator Setup Menu	85
6.7 Governor/Regulator Setup Menu (Continued...)	88
6.8 PCC Control Panel Box Components (Standard/Optional)	89
6.9 Engine Sensors.....	92
6.10 Distributor.....	94
6.11 Magnetic Speed Pickup Unit (MPU) Installation	94
6.12 Current Transformer (CT) Installation	95
6.13 CT Installation Requirements.....	95
 7. SERVICING THE GENERATOR.....	97

7.1 Testing the Generator	97
7.2 Generator/Base Board Isolation Procedure	98
7.3 Generator Dissambly	107
7.4 Generator Reassembly	110
7.5 Servicing the PMG	110
8. FUEL SYSTEM ADJUSTMENTS	113
8.1 Fuel System Components.....	113
8.2 Actuator/Fuel System Adjustments.....	113
8.3 Fuel Mixture Adjustments	119
8.4 Demand Regulator	120
9. EXHAUST SYSTEM.....	121
9.1 Overview	121
9.2 Oxygen Sensor	121
10. GLOBAL ADDRESSES	123
APPENDIX A. WIRING DIAGRAMS	125

BUY NOW

**Then Instant Download
the Complete Manual**

Thank you very much!