



Service Manual

Cummins **Onan**

Performance you rely on.™



Hybrid Quiet Diesel Power System HQDSA

Power Unit HQDPC (Beginning Spec C)

Power Unit HQDPA (Prior to Spec C)

Inverter Charger HQDVA

Transfer Switch HQDTA

Table of Contents

SECTION	PAGE
SAFETY PRECAUTIONS	vi
1. INTRODUCTION	1-1
About this Manual	1-1
Hybrid Power System Component Nameplates	1-1
Engine Emissions Compliance	1-3
Features	1-4
Modes of Operation	1-5
2. OPERATING THE HYBRID POWER SYSTEM	2-1
Pre-Start Checks	2-1
EveryDay Operation	2-1
Enabling AUTO	2-2
Inverter Mode—Manual Control	2-4
Generator Mode—Manual Control	2-5
Shore Power Mode	2-6
3. POWER UNIT OPERATION AND MAINTENANCE	3-1
General	3-1
Power Unit Control Panel	3-2
Remote Control Switch	3-2
Recommended Fuel	3-4
Recommended Coolant	3-4
Recommended Engine Oil	3-5
Operating at High Altitude	3-5
Operating in Cold Weather	3-5
Operating in Hot Weather	3-5
Operating in Dusty Environments	3-5
New engine Break-In	3-6
Exercising the Hybrid Power System	3-6
Storage	3-6
Periodic Maintenance Schedule	3-7
General Inspections	3-8

SECTION	PAGE
Checking Engine Oil Level	3-9
Changing Engine Oil and Oil Filter	3-10
Replacing the Air Filter Element	3-11
Cleaning the Spark Arrestor	3-12
Replacing the Fuel Filter	3-13
Maintaining Engine and Inverter/Charger Cooling System	3-14
4. POWER UNIT SERVICE	4-1
General	4-1
Engine Service	4-2
Engine Combustion Air Intake	4-5
Engine Exhaust Muffler	4-6
Engine Cooling System	4-8
Inverter/Charger Heat Exchanger	4-11
Engine Fuel System	4-12
Engine Starter	4-14
ECM (Engine Control Module)	4-15
Engine Governor	4-16
PMA	4-20
Removing Power Unit From Vehicle	4-24
Test Stand	4-24
Housing Panels	4-25
5. INVERTER/CHARGER	5-1
General	5-1
Maintenance	5-1
Service	5-3
6. TRANSFER SWITCH	6-1
General	6-1
Maintenance	6-1
Service	6-3
7. COACH BATTERIES	7-1
Charging the Coach Batteries	7-1
Maintaining the Coach Batteries	7-1
Equalizing the Coach Batteries	7-2
Storing the Coach Batteries	7-2

SECTION	PAGE
Replacing the Coach Batteries	7-3
Connecting the Coach Battery Cables	7-4
Replacing a Coach Battery Fuse	7-6
8. COMMUNICATIONS AND INPUT CABLES	8-1
General	8-1
Power Unit Connections	8-2
Load Demand Input	8-3
Auto Safety Input	8-3
Battery Saver Signal	8-4
Shunt Input	8-5
Battery Temperature Sensor	8-6
9. INSTALLATION REVIEW AND STARTUP	9-1
Installation Review	9-1
Startup	9-3
APPENDIX A. OPERATOR PANEL	A-1
About the Operator Panel	A-1
Home Screen	A-2
AUTO Button	A-3
Clock Button	A-6
Manual Button	A-7
Status Menu	A-8
Batt Status	A-9
Auto Status	A-10
Gen Status	A-11
Inv Status	A-12
Shore Status	A-13
Fault Information	A-14
Setup Menu	A-15
Auto Setup	A-16
Shore Breaker	A-17
Screen Setup	A-18
Service Menu	A-19
Input Setup	A-20
Battery Setup	A-21

SECTION	PAGE
Equalize	A-22
About	A-24
Warning and Prompt Screens	A-25
APPENDIX B. TROUBLESHOOTING SYMPTOMS	B-1
Fault Code Blinking	B-1
Restoring Fault Code Blinking	B-1
APPENDIX C. TROUBLESHOOTING FAULT CODES	C-1
APPENDIX D. BATTERY INTERCONNECTIONS	D-1
APPENDIX E. HOT AIR RECIRCULATION TEST	E-1
APPENDIX F. SPECIFICATIONS	F-1
APPENDIX G. MAINTENANCE RECORD	G-1
APPENDIX H. THREAD TORQUES	H-1
APPENDIX I. INPOWER ONAN SERVICE TOOL	I-1
Hybrid Quiet Diesel and the InPower ONAN Service Tool	I-1
Downloading software	I-1
Replacement components and system configuration	I-1
Clear Fault History	I-2
Initial Update calibration	I-2
APPENDIX J. OUTLINE AND SYSTEM DRAWINGS	J-5
System Diagram (Sheet 1 of 8)	J-6
Power Unit (Sheet 2 of 8)	J-7
Inverter/Charger (Sheet 3 of 8)	J-8
Transfer Switch (Sheet 4 of 8)	J-9
Operator Panel (Sheet 5 of 8)	J-10
12 Volt DC System Diagram (Sheet 6 of 8)	J-11
AC System Diagram (Sheet 7 of 8)	J-12
Communication Cable System Diagram (Sheet 8 of 8)	J-13
Diagram—Typical Hybrid Power System Installation	J-14
Communications Cables	J-15
Power Unit Wiring Schematic	J-16
Power Unit Wiring Harness	J-17

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**