



Service Manual

Our energy working for you.™



**Power
Generation**

Controller

PowerCommand® 3201

Á
Á
Á
Á
Á
Á

Table of Contents

SECTION	TITLE	PAGE
1. Introduction		1-1
	ABOUT THIS MANUAL	1-1
	TEST EQUIPMENT	1-1
	HOW TO OBTAIN SERVICE	1-1
2. Control Operation		2-1
	GENERAL	2-1
	SEQUENCE OF OPERATION	2-1
	CONTROL PANEL POWER ON/OFF MODES	2-1
	CONTROL PANEL ASSEMBLY	2-4
	READING FAULT CODES	2-6
	MENU DISPLAY AND SWITCHES	2-7
	LANGUAGE/UNITS SELECTION MENU	2-8
	MAIN MENU	2-9
	ENGINE SUBMENUS	2-11
	ALTERNATOR SUBMENUS	2-12
	CONTROL SUBMENU	2-13
	HISTORY/ABOUT SUBMENUS	2-14
	HISTORY/ABOUT SUBMENUS (CONT.)	2-15
	PARALLEL DATA SUBMENU	2-16
	POWER TRANSFER MAIN/SUBMENUS	2-17
	UTILITY (PWR TRAN) SUBMENUS	2-19
	STATUS (PWR TRAN) SUBMENUS	2-20
	TRANSFER CONTROL (PWR TRAN) SUBMENU	2-21
	GENSET (PWR TRAN) SUBMENUS	2-22
3. Control Calibration and Adjustment		3-1
	GENERAL	3-1
	PARALLELING and NON-PARALLELING	3-1
	SOFTWARE CALIBRATIONS	3-1
	MODIFYING SETUP/ADJUST SUBMENUS	3-1
	SETUP MENUS	3-3
	GOVERNING/VOLT REG SUBMENU	3-4
	CUSTOMER FAULTS SUBMENUS	3-6
	CALIBRATION SUBMENUS	3-8
	ISOLATED BUS SUBMENUS	3-11
	UTILITY SUBMENUS	3-17
	POWER TRANSFER CONTROL MAIN MENUS	3-19
	UTILITY SENSORS SUBMENUS	3-20
	GENSET SENSORS SUBMENUS	3-22
	TIMERS SUBMENU	3-24
	TEST/EXERCISE SUBMENU	3-26
	ADJUST SUBMENU	3-28
	CALIBRATION PROCEDURE	3-29

SECTION	TITLE	PAGE
	CONTROL BOX WIRING	3-31
	RUN RELAYS (K11, K12, K13)	3-33
	ALARM RELAY (K16)	3-34
	MAGNETIC SPEED PICKUP UNIT (MPU) INSTALLATION	3-35

~~~~~

# IMPORTANT SAFETY INSTRUCTIONS

---

**SAVE THESE INSTRUCTIONS** – This manual contains important instructions that should be followed during installation and maintenance of the generator set and batteries.

**Before operating the generator set (genset)**, read the Operator's Manual and become familiar with it and the equipment. **Safe and efficient operation can be achieved only if the equipment is properly operated and maintained.** Many accidents are caused by failure to follow fundamental rules and precautions.

The following symbols, found throughout this manual, alert you to potentially dangerous conditions to the operator, service personnel, or the equipment.

**⚠ DANGER** *This symbol warns of immediate hazards which will result in severe personal injury or death.*

**⚠ WARNING** *This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.*

**⚠ CAUTION** *This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.*

## FUEL AND FUMES ARE FLAMMABLE

Fire, explosion, and personal injury or death can result from improper practices.

- DO NOT fill fuel tanks while engine is running, unless tanks are outside the engine compartment. Fuel contact with hot engine or exhaust is a potential fire hazard.
- DO NOT permit any flame, cigarette, pilot light, spark, arcing equipment, or other ignition source near the generator set or fuel tank.
- Fuel lines must be adequately secured and free of leaks. Fuel connection at the engine should be made with an approved flexible line. Do not use zinc coated or copper fuel lines with diesel fuel.
- Be sure all fuel supplies have a positive shutoff valve.
- Be sure battery area has been well-ventilated prior to servicing near it. Lead-acid batteries emit a highly explosive hydrogen gas that can be ignited by arcing, sparking, smoking, etc.

## EXHAUST GASES ARE DEADLY

- Provide an adequate exhaust system to properly expel discharged gases away from enclosed or sheltered areas and areas where individuals are likely to congregate. Visually and audibly inspect the exhaust daily for leaks per the maintenance schedule. Make sure that exhaust manifolds are secured and not warped. Do not use exhaust gases to heat a compartment.
- Be sure the unit is well ventilated.
- Engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects, and other reproductive harm.

## MOVING PARTS CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Keep your hands, clothing, and jewelry away from moving parts.
- Before starting work on the generator set, disconnect battery charger from its AC source, then disconnect starting batteries, negative (–) cable first. This will prevent accidental starting.
- Make sure that fasteners on the generator set are secure. Tighten supports and clamps, keep guards in position over fans, drive belts, etc.
- Do not wear loose clothing or jewelry in the vicinity of moving parts, or while working on electrical equipment. Loose clothing and jewelry can become caught in moving parts.
- If adjustment must be made while the unit is running, use extreme caution around hot manifolds, moving parts, etc.

## DO NOT OPERATE IN FLAMMABLE AND EXPLOSIVE ENVIRONMENTS

Flammable vapor can cause an engine to overspeed and become difficult to stop, resulting in possible fire, explosion, severe personal injury and death. Do not operate a genset where a flammable vapor environment can be created by fuel spill, leak, etc., unless the genset is equipped with an automatic safety device to block the air intake and stop the engine. The owners and operators of the genset are solely responsible for operating the genset safely. Contact your authorized Cummins Power Generation distributor for more information.

## **ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH**

- Remove electric power before removing protective shields or touching electrical equipment. Use rubber insulative mats placed on dry wood platforms over floors that are metal or concrete when around electrical equipment. Do not wear damp clothing (particularly wet shoes) or allow skin surface to be damp when handling electrical equipment. Do not wear jewelry. Jewelry can short out electrical contacts and cause shock or burning.
- Use extreme caution when working on electrical components. High voltages can cause injury or death. DO NOT tamper with interlocks.
- Follow all applicable state and local electrical codes. Have all electrical installations performed by a qualified licensed electrician. Tag and lock open switches to avoid accidental closure.
- DO NOT CONNECT GENERATOR SET DIRECTLY TO ANY BUILDING ELECTRICAL SYSTEM. Hazardous voltages can flow from the generator set into the utility line. This creates a potential for electrocution or property damage. Connect only through an approved isolation switch or an approved paralleling device.

## **GENERAL SAFETY PRECAUTIONS**

- Coolants under pressure have a higher boiling point than water. DO NOT open a radiator or heat exchanger pressure cap while the engine is running. To prevent severe scalding, let engine cool down before removing coolant pressure cap. Turn cap slowly, and do not open it fully until the pressure has been relieved.
- Used engine oils have been identified by some state or federal agencies as causing cancer or reproductive toxicity. When checking or changing engine oil, take care not to ingest, breathe the fumes, or contact used oil.
- Keep multi-class ABC fire extinguishers handy. Class A fires involve ordinary combustible materials such as wood and cloth; Class B fires, combustible and flammable liquid fuels and gaseous fuels; Class C fires, live electrical equipment. (ref. NFPA No. 10).
- Make sure that rags or combustible material are not left on or near the generator set.
- Make sure generator set is mounted in a manner to prevent combustible materials from accumulating under or near the unit.
- Remove all unnecessary grease and oil from the unit. Accumulated grease and oil can cause overheating and engine damage which present a potential fire hazard.
- Keep the generator set and the surrounding area clean and free from obstructions. Remove any debris from the set and keep the floor clean and dry.
- Do not work on this equipment when mentally or physically fatigued, or after consuming any alcohol or drug that makes the operation of equipment unsafe.
- Substances in exhaust gases have been identified by some state or federal agencies as causing cancer or reproductive toxicity. Take care not to breathe or ingest or come into contact with exhaust gases.
- Do not store any flammable liquids, such as fuel, cleaners, oil, etc., near the generator set. A fire or explosion could result.
- Wear hearing protection when near an operating generator set.
- To prevent serious burns, avoid contact with hot metal parts such as radiator system, turbo charger system and exhaust system.

**KEEP THIS MANUAL NEAR THE GENSET FOR EASY REFERENCE**

# 1. Introduction

---

## ABOUT THIS MANUAL

This manual provides PowerCommand® Control 3201 (PCC) calibration and adjustment procedures, control operation, alternator test and repair procedures.

Operating and maintenance instructions are in the applicable Operator's Manual.

Read **Important Safety Instructions** and carefully observe all instructions and precautions in this manual.


## TEST EQUIPMENT

To perform the test procedures in this manual, the following test equipment must be available

- True RMS meter for accurate measurement of small AC and DC voltages.
- Battery Hydrometer
- Jumper Leads
- Tachometer or Frequency Meter
- Wheatstone Bridge or Digital Ohmmeter
- Variac
- Load Test Panel
- Megger or Insulation Resistance Meter
- InPower™ Service Tool (PC based genset service tool)

## HOW TO OBTAIN SERVICE

Always give the complete Model, Specification and Serial number of the generator set as shown on the nameplate when seeking additional service information or replacement parts. The nameplate is located on the side of the generator output box.

** *WARNING* Incorrect service or replacement of parts can result in severe personal injury or death, and/or equipment damage. Service personnel must be trained and experienced to perform electrical and mechanical service. Read and follow Important Safety Instructions, on pages iii and iv.**

**BUY NOW**

**Then Instant Download  
the Complete Manual  
Thank you very much!**