

2950 Tractor



TECHNICAL MANUAL

2950 Tractor

TM4407 (01AUG86) English

John Deere Werke Mannheim TM4407 (01AUG86)

LITHO IN U.S.A. ENGLISH



2950 TRACTOR TECHNICAL MANUAL TM-4407 (Apr-86)

CONTENTS

The engine information has been removed from this manual. For engine information, refer to engine component technical manual, CTM-4, 3179, 4239, and 6359 Engines.

SECTION 10 - GENERAL

Group 00 - Specifications and Special Tools

Group 05 - Predelivery, Delivery, and After-Sales Inspections

Group 10 - Lubrication and Service

Group 15 - Tune-Up

Group 20 - Tractor Separation

SECTION 20 - ENGINE

Group 00 - Specifications

Group 05 - Radiator

SECTION 30 - FUEL AND AIR INTAKE SYSTEM

Group 00 - Specifications and Special Tools

Group 05 - General Information, and Diagnosing Malfunctions

Group 10 - Fuel Tank and Water Trap

Group 15 - Cold Weather Starting Aids

Group 20 - Speed Control Linkage

Group 25 - Air Cleaner

SECTION 40 - ELECTRICAL SYSTEM

Group 00 - Specifications and Special Tools

Group 05 - Description, Diagnosing Malfunctions and Tests

Group 06 - Connector Repair

Group 10 - Wiring Harnesses

Group 15 - Controls and Instruments

Group 20 - Lighting System

Group 25 - Wiring Diagrams

Group 30 - Starting Motor

Group 35 - Alternator

SECTION 50 - POWER TRAIN

Group 00 - Specifications and Special Tools

Group 05 - Description, Operation and Lubrication System

Group 10 - Clutch Operating Linkages

Group 15 - Engine Clutch

Group 20 - Hi-Lo Shift Unit

Group 25 - Creeper Transmission

Group 30 - Transmission Shift Linkages

Group 35 - Synchronized Transmission and Transmission Oil Pump

Group 40 - Differential

Group 45 - Final Drives

Group 50 - Independent PTO

Group 55 - Mechanical Front Wheel Drive

SECTION 60 - STEERING SYSTEM AND BRAKES

Group 00 - Specifications and Special Tools

Group 05 - Steering System

Group 10 - Brakes

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without rotice.

COPYRIGHT® 1985 DEERE & COMPANY Moline, Illinois All rights reserved Previous Edition Copyright® 1982, 1984 Deere & Company

CONTENTS—Continued

SECTION 70 - HYDRAULIC SYSTEM

Group 00 - Specifications and Special Tools

Group 05 - Description, Diagnosing Malfunctions and Tests

Group 10 - Oil Reservoir, Filter, Valves and Oil Cooler

Group 15 - Hydraulic Pump

Group 20 - Rockshaft

Group 25 - Selective Control Valve (Poppet Valve Type) and Breakaway Coupler

Group 26 - Selective Control Valve (Spool Type) and Quick Coupler

Group 30 - Remote Cylinder

SECTION 80 - ENGINE

Group 00 - Specifications

Group 05 - Front Axle

Group 10 - Front and Rear Wheels

SECTION 90 - OPERATOR'S STATION

Group 00 - Specifications and Special Tools

Group 05 - Air Conditioning System

Group 10 - Cab Ventilation and Heating

Group 15 - Seats

Group 20 - SOUND-GARD Body

Group 25 - ROLL-GARD Protective Structure

Section 10 GENERAL

CONTENTS OF THIS SECTION

Page	Page
GROUP 00 - SPECIFICATIONS AND SPECIAL TOOLS	GROUP 05 - PREDELIVERY, DELIVERY AND AFTER-SALES INSPECTIONS
Specifications	Tractor Storage 10-05-1
Serial Numbers 10-00-3	Predelivery Inspection 10-05-2
Model Numbers 10-00-3	Delivery Inspection
Engine 10-00-3	After-Sales Inspection 10-05-10
Engine Clutch	·
Cooling System 10-00-4	GROUP 10 - LUBRICATION AND SERVICE
Fuel System 10-00-4	Lubrication and Service 10-10-1
Electrical System 10-00-4	
Synchronized Transmission 10-00-4	GROUP 15 - TUNE-UP
Hi-Lo Shift Unit 10-00-4	Preliminary Engine Testing 10-15-1
Creeper Transmission 10-00-5	Dynamometer Test 10-15-1
Differential and Final Drives 10-00-5	Testing Compression Pressure 10-15-2
Differential Lock 10-00-5	Engine Tune-Up
PTO 10-00-5	Checking Tractor Operation 10-15-7
Mechanical Front Wheel Drive 10-00-5	Standard Torques 10-15-8
Hydrostatic Steering 10-00-6	
Foot Brakes 10-00-6	GROUP 20 - TRACTOR SEPARATION
Handbrake 10-00-6	Separating between Engine and
Hydraulic System 10-00-6	Tractor Front End 10-20-1
Capacities 10-00-6	Removal and Installation of Engine 10-20-5
Travel Speeds 10-00-6	Removal and Installation of
Front and Rear Wheels 10-00-6	Clutch Housing 10-20-8
Dimensions and Weights 10-00-6	Removal and Installation of
Predelivery, Delivery and	Final Drives 10-20-10
After-Sales Inspections 10-00-7	Removal and Installation of
Lubrications and Service 10-00-8	Rockshaft 10-20-15
Tune-up 10-00-9	Removal and Installation of
Tractor Separation 10-00-10	SOUND-GARD® Body 10-20-17
Standard Torques 10-00-11	
Special Tools 10.00.12	

Group 00 SPECIFICATIONS AND SPECIAL TOOLS SPECIFICATIONS

Serial Numbers

The engine serial number is stamped into the plate located on the lower front right-hand side of the cylinder block.

NOTE: When ordering engine parts, quote all digits of serial number stamped on the plate

The plate showing the tractor serial number is located on the right-hand side of the front axle carrier.

NOTE: When ordering tractor service parts (excluding engine parts), quote all digits and letters of serial number stamped on the plate.

A plate showing the tractor type, transmission serial number, cone point measurement etched into pinion face of differential drive shaft (as well as reduction of differential) is located on the right-hand side of the transmission case.

Model Numbers

The fuel injection pump, fuel injection nozzles, alternator, starting motor, hydrostatic steering valve and hydraulic pump have model numbers to facilitate identification of different makes of a given unit.

Engine

Number of cylinders
Cylinder liner bore
Stroke
Displacement
Compression ratio up to engine serial no. 547636CD
Maximum torque at 1400 rpm
Firing order
Valve clearance (engine hot or cold) Intake valve 0.35 mm (0.014 in.) Exhaust Valve 0.45 mm (0.018 in.)
Fast idle speed
Slow idle speed
Rated engine speed
Working speed range

^{*} With the engine run in (above 100 hours of operation) and having reached operating temperature (engine and transmission); measured by means of a dynamometer. Permissible variation \pm 5 percent.

Creeper Transmission		
Type		Synchronized reduction unit
Travel speed decreases in low (I) and revers	se ranges by	Approx. 79%
Shifting both ranges		Mechanical and not under load
Differential and Final Drives		
Type of differential		Spiral bevel gears
Type of final drive		Planetary reduction drive
Differential Lock		
Operation		Hand or foot operated
Disengage	Will disengage autor	natically as soon as traction has equalized
PTO		
Type Indepe	ndent of transmission, ca	an be engaged and disengaged under load
PTO speeds (with engine speed of 2400 rpm	n)	540/1000 rpm
PTO clutch		. Hydraulically operated "wet" disk clutch
PTO brake		Hydraulically operated "wet" disk brake
ENGI	NE/PTO SPEED RELATIONSH	IIPS
Engine speed	540 rpm shaft	1000 rpm shaft
800 2400 2500 2660	180 540 565 600	335 1000 1040 1110
Mechanical Front Wheel Drive		
Type	Engaged hydraulid	cally, under full load with "wet" disk clutch
Control		Electrical/hydraulic solenoid switch
Engagement		Preloaded cup springs
Disengagement		Hydraulic

Hydrostatic Steering Without mecha	unical linkage bet	tween steering va	lve and the front wheels
Foot Brakes	. Self-adjusting	, hydraulically ope	erated "wet" disk brakes
Handbrake Mechanically	operated band-ty	pe locking brake	acting on the differential
Hydraulic System			
Туре		Closed center, c	onstant pressure system
Standby pressure	15800 to 16200	0 kPa (158 to 162	2 bar) (2300 to 2350 psi)
Operating pressure	14000 kPa	(140 ba	r) (2050 psi)
Hydraulic pump		8-piston pump wi	th variable displacement
Capacities			
Fuel tank		122 liters	(32.0 U.S. gals.)
Cooling system			
Without SOUND-GARD Body	• • • • • • • • • • • • • • • • • • • •	17.0 L	(4.5 U.S. gals.)
With SOUND-GARD Body		19.0 L	(5.0 U.S. gals.)
Engine crankcase			
Without filter change		11.0 L	(2.9 U.S. gals.)
With filter change		11.5 L	(3.0 U.S. gals.)
Hydraulic clutch reservoir		500 cm3	17.5 fl. oz.
Transmission - Hydraulic system			
Initial filling	• • • • • • • • • • • • • • • • • • • •	68.0 L	(18.0 U.S. gals.)
Oil change		60.0 L	(15.9 U.S. gals.)
Mechanical front wheel drive			
Front axle housing		7.0 L	(7.85 U.S. gals.)
Wheel hub housing, each		0.75 L	(0.2 U.S. gals.)
Travel Speeds			See Operator's Manual
Front and Rear Wheels			
Tires, tread widths, tire pressure and ballast weights		• • • • • • • • • • • • • • • • • • • •	See Operator's Manual
Dimensions and Weights			See Operator's Manual

PREDELIVERY, DELIVERY AND AFTER-SALES INSPECTIONS

 Slow idle
 700 to 800 rpm

 Fast idle
 2610 to 2660 rpm

Engine Speeds

Rated speed	n
Fan Belt	
The fan belt should have 19 mm (3/4 in.) flex with 90 N (20 lb) pull midway between crankshaft and alternate or water pump (use a spring scale).	or
Batteries	
Specific gravity at an electrolyte temperature of 20°C (68°F) Normal and arctic conditions	
Clutch Operating Linkage	
Tractors Without SOUND-GARD Body	
Clutch pedal free travel	.)
Tractors With SOUND-GARD Body	
Travel of slave cylinder operating rod 8.5 to 12.0 mm (5/16 to 15/32 in	.)
Front Wheel Toe-In	
Tractors without MFWD	.)
Tractors with MFWD	.)
Torques for Hardware	
Start safety switch in rockshaft housing, max	s)
Tractors without MFWD	2)
Tractors with MFWD	•
Axle knees to axle center, cap screws	
Tie rod clamps	,
Cap screw (M10)	3)
Cap screw (M12)	•
Tie rod tube, cap screw	3)
Rear wheels	
Rear wheels to axle	•
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	٠١

Wheel disk to hub (rack-and-pinion axle) 400 N·m

Supports to crossbar, cap screws 200 N·m

Supports to final drives, cap screws and nuts 400 N·m

(300 ft-lbs)

(145 ft-lbs) (300 ft-lbs)

2-post ROLL-GARD protective structure

LUBRICATION AND SERVICE

Capacities

Engine crankcase		
Without filter change	11.0 L	(2.9 U.S. gal.)
With filter change	11.5 L	(3.0 U.S. gal.)
Cooling system		
Without SOUND-GARD Body	17.0 L	(4.5 U.S. gals.)
With SOUND-GARD Body	19.0 L	(5.0 U.S. gals.)
Transmission - Hydraulic system		
Initial filling	68.0 L	(18.0 U.S. gal.)
Oil change	60.0 L	(15.9 U.S. gal.)
Mechanical front wheel drive		
Front axle housing	7.0 L	(1.85 U.S. gal.)
Wheel hub housing, each	0.75 L	(0.2 U.S. gal.)
Service Intervals		
Checking crankcase oil level Changing engine oil Changing engine oil filter Checking transmission/hydraulic system oil level Changing transmission/hydraulic system oil filter Changing transmission/hydraulic oil Changing hydrostatic steering filter Cleaning hydrostatic steering filter Cleaning hydraulic pump strainer Checking MFWD oil level MFWD oil change Cleaning and packing front wheel bearings Lubricating grease fittings Clutch throw-out bearing grease fitting (when equipped) Mechanical front wheel drive universal-jointed shaft In wet and muddy conditions Front axle and front axle bearings Rear axle bearings In wet and muddy conditions Three-point hitch		every 100 hours every 200 hours every 50 hours every 500 hours every 1000 hours every 100 hours every 50 hours every 50 hours every 50 hours every 500 hours every 500 hours every 100 hours

10-00-9

TUNE-UP

PTO horsepower* at 2500 rpm rated engine speed		63 kW	85 hp
Slow idle	•	•••••	700 to 800 rpm
Fast idle		26	310 to 2660 rpm
Rated engine speed			2500 rpm
Air intake system vacuum	3.5 to 6.0 kPa	35 to 60 mbar	(14 to 25 in. water head)
Air cleaner restriction warning switch closes at a vacuum of	5.5 to 6.5 kPa	55 to 65 mbar	(22 to 26 in. water head)
Radiator cap high pressure valve opens at	40 to 50 kPa	0.4 to 0.5 bar	(6 to 7 psi)
Radiator cap low pressure valve opens at	. 0 to 4 kPa	0 to 0.04 bar	(0 to 0.6 psi)

Fan Belt

Fan belt should have 19 mm (3/4 in.) flex with 90 N (20 lb) pull midway between crankshaft and alternator or water pump (use a spring scale).

Compressor Belt

Compressor belt should have 19 mm (3/4 in.) flex with 60 N (13 lb) pull midway between pulleys.

^{*} With the engine run in (more than 100 hours of operation) and having reached operating temperature (engine and transmission); measured by means of a dynamometer. Permissible variation \pm 5%.

TRACTOR SEPARATION

Torques for Hardware

Front axle carrier to engine block, cap screws	230 1	N·m	(170 ff	t-lbs)
Front axle carrier to oil pan, cap screws	400 N	V·m	(300 ft	t-lbs)
Engine block to front axle carrier, cap screws	230 1	V·m	(170 ft	t-lbs)
Hydraulic pump drive shaft, cap screws	1 02	N∙m	(35 ft	t-lbs)
Jointed shaft flange to front axle drive hub (tractors with MFWD), cap screws	75 l	N·m	(55 ft	t-lbs)
Clutch housing to engine block Cap screws Hex. nuts			(170 ft (170 ft	
Oil pan to clutch housing, cap screws	230 1	V·m	(170 ft	t-lbs)
Clutch housing to transmission case, cap screws	160 N	V·m	(120 ft	t-lbs)
Oil drain plug of transmission case	135 N	٧·m	(100 ft	:-lbs)
Hydraulic lines retainer to clutch housing, cap screw	45 N	V·m	(32 ft	:-lbs)
Final drive housings to transmission case, cap screws	230 N	√m	(170 ft	:-lbs)
Rockshaft housing to transmission case, cap screws	120 N	V·m	(85 ft	:-lbs)
Rear wheels to rear axle	400 N	٧·m	(300 ft	:-lbs)
Wheel disk to hub (rack and pinion axle)	400 N	٧·m	(300 ft	:-lbs)
Rear fenders to final drive housings, hex. nuts	200 N	٧·m	(145 ft	:-lbs)
2-post ROLL-GARD protective structure to final drive housings			(300 ft (145 ft	•
Basic weight to front axle carrier, cap screws	400 N	小 m	(300 ft	-lbs)
Drawbar to transmission case Front cap screws Rear cap screws	230 N 120 N		(170 ft (85 ft	
SOUND - GARD Body to rubber bearing block, cap screws and hex. nuts	200 N	√m	(145 ft	-lbs)

STANDARD TORQUES

RECOMMENDED TORQUES IN N:m, AND FT-LBS FOR UNC AND UNF CAP SCREWS					
Head Marking (identifying strength)		or 10.9*		or 12.9**	
Thread-O.D. (in.)	N:m	ft-lbs	N:m	ft-lbs	
1/4	15	10 20	20 40	15 30	
5/16 3/8	30 50	35	70	50	
7/16	80	55	110	80	
1/2	120	85	170	120	
9/16	180	130	240	175	
5/8	230	170	320	240	
3/4	400	300	580	425	
7/8	600	445	930	685	
1	910	670	1400	1030	
1-1/8	1240	910	1980	1460	
1-1/4	1700	1250	2800	2060	

RW7097

NOTE: A variation of \pm 10% is permissible for all torques indicated in this chart.

Torque figures indicated above and in the Specification sections of this manual are valid for non-greased or non-oiled threads and heads unless otherwise specified. Therefore, do not grease or oil bolts or cap screws unless otherwise specified in this manual.

- * Tempered steel high-strength bolts and cap screws
- ** Tempered steel extra high-strength bolts and cap screws

BUY NOW

Then Instant Download the Complete Manual Thank you very much!