




Parts Manual



WF3000 Series




Printed in Germany



Table of Content

ITD – INTRODUCTION	PAGE	SERIAL NR. CUT	REV.
General	7		
SECTION 1 – COVERS	PAGE	SERIAL NR. CUT	REV.
Covers	_		
Caster Wheel	14		
Load Wheel	16		
SECTION 2 – HYDRAULIC PART	PAGE	SERIAL NR. CUT	REV.
Tube-/Hose Layout	_		
Hydraulic TF Mast			
SECTION 3 – DRIVE UNIT	PAGE	SERIAL NR. CUT	REV.
Gearbox	_	SERIAL NR. COT	KLV.
Drive Motor 0,7kW/1.0t	-		
Drive Motor 1,4kW/1.2t			
Knuckel			
SECTION 4 – ELECTRICAL	PAGE	SERIAL NR. CUT	REV.
Electrical Parts	_	SERIAL INK. CUI	REV.
Contactor	,		
Control Handle			
Switch	,		
Charger	-		
Battery			
Instrument			
SECTIONS - BRAKE SYSTEM	PAGE	SERIAL NR CLIT	RFV
SECTION5 – BRAKE SYSTEM Brake	PAGE	SERIAL NR. CUT	REV.
Brake	56		
SECTION6 - STEERING	56 PAGE	SERIAL NR. CUT	REV.
Brake	56 PAGE		
SECTION6 - STEERING	56 PAGE		
SECTION6 – STEERING Steering Mechanism SECTION 7 – MAST-/LIFT STRUCTURE Mono Mast	56 PAGE 60 PAGE 64	SERIAL NR. CUT	REV.
SECTION6 – STEERING Steering Mechanism SECTION 7 – MAST-/LIFT STRUCTURE Mono Mast TL Mast	56 PAGE 60 PAGE 64 66	SERIAL NR. CUT	REV.
SECTION6 – STEERING Steering Mechanism SECTION 7 – MAST-/LIFT STRUCTURE Mono Mast TL Mast TF Mast	56 PAGE 60 PAGE 64 66 68	SERIAL NR. CUT	REV.
Brake SECTION6 – STEERING Steering Mechanism	56 PAGE 60 PAGE 64 66 68 70	SERIAL NR. CUT	REV.
Brake	56 PAGE 60 PAGE 64 66 68 70 72	SERIAL NR. CUT	REV.
Brake SECTION6 – STEERING Steering Mechanism SECTION 7 – MAST-/LIFT STRUCTURE Mono Mast TL Mast TF Mast Fork Carriage Mono Mast Fork Carriage TL/TF Mast 1.0t Fork Carriage TL/TF Mast 1.2t	56 PAGE 60 PAGE 64 66 68 70 72 74	SERIAL NR. CUT	REV.
Brake SECTION6 – STEERING Steering Mechanism SECTION 7 – MAST-/LIFT STRUCTURE Mono Mast TL Mast TF Mast Fork Carriage Mono Mast Fork Carriage TL/TF Mast 1.0t Fork Carriage TL/TF Mast 1.2t Mast Safty Screen	56 PAGE 60 PAGE 64 66 68 70 72 74 76	SERIAL NR. CUT	REV.
Brake	56 PAGE 60 PAGE 64 66 68 70 72 74 76 78	SERIAL NR. CUT	REV.
Brake	56 PAGE 60 PAGE 64 66 68 70 72 74 76 78	SERIAL NR. CUT	REV.
Brake	56 PAGE 60 PAGE 64 66 68 70 72 74 76 78 80 PAGE	SERIAL NR. CUT	REV.
Brake	56 PAGE 60 PAGE 64 66 68 70 72 74 76 78 80 PAGE	SERIAL NR. CUT SERIAL NR. CUT	REV.
Brake SECTION6 – STEERING Steering Mechanism SECTION 7 – MAST-/LIFT STRUCTURE Mono Mast TL Mast TF Mast Fork Carriage Mono Mast Fork Carriage TL/TF Mast 1.0t Fork Carriage TL/TF Mast 1.2t Mast Safty Screen Load Backrest Yoke SECTION 8 – CYLINDER Lift Cylinder - Mast TL Free Lift Cylinder - Mast Mono/Mast TF	56 PAGE 60 PAGE 64 66 68 70 72 74 76 78 80 PAGE 84	SERIAL NR. CUT SERIAL NR. CUT	REV.
Brake SECTION6 – STEERING Steering Mechanism SECTION 7 – MAST-/LIFT STRUCTURE Mono Mast TL Mast TF Mast Fork Carriage Mono Mast Fork Carriage TL/TF Mast 1.0t Fork Carriage TL/TF Mast 1.2t Mast Safty Screen Load Backrest Yoke SECTION 8 – CYLINDER Lift Cylinder - Mast TL Free Lift Cylinder - Mast Mono/Mast TF Lift Cylinder - Mast TF	56 PAGE 60 PAGE 64 66 68 70 72 74 76 78 80 PAGE	SERIAL NR. CUT SERIAL NR. CUT	REV.
Brake SECTION6 – STEERING Steering Mechanism SECTION 7 – MAST-/LIFT STRUCTURE Mono Mast TL Mast TF Mast Fork Carriage Mono Mast Fork Carriage TL/TF Mast 1.0t Fork Carriage TL/TF Mast 1.2t Mast Safty Screen Load Backrest Yoke SECTION 8 – CYLINDER Lift Cylinder - Mast TL Free Lift Cylinder - Mast Mono/Mast TF	56 PAGE 60 PAGE 64 66 68 70 72 74 76 78 80 PAGE	SERIAL NR. CUT SERIAL NR. CUT	REV.
Brake SECTION6 – STEERING Steering Mechanism SECTION 7 – MAST-/LIFT STRUCTURE Mono Mast TL Mast TF Mast Fork Carriage Mono Mast Fork Carriage TL/TF Mast 1.0t Fork Carriage TL/TF Mast 1.2t Mast Safty Screen Load Backrest Yoke SECTION 8 – CYLINDER Lift Cylinder - Mast TL Free Lift Cylinder - Mast Mono/Mast TF Lift Cylinder - Mast TF	56 PAGE 60 PAGE 64 66 68 70 72 74 76 78 80 PAGE	SERIAL NR. CUT SERIAL NR. CUT	REV.



Printed in Germany



Important customer information

To ensure the safety of the truck, you, the customer, must only carry out maintenance and repairs as stipulated in the operator manual.

Any additional work must be performed by Crown authorised service technicians. Authorised service technicians have the required expertise and up-to-date service information.

If you wish to have your own technicians trained, please contact Crown for relevant training courses.

Subsequent Attachments and Modifications made to the Truck

DANGER!



Any proposed modification which would alter the original condition of the truck when delivered, must first be assessed and approved in writing by Crown Gabelstapler GmbH.

- The net weight and position of attachments may considerably affect the capacity and other truck characteristics.
- Changing the electrical system or adding electrically operated components may result in operating faults.

Modifications which have not been assessed may result in fatal accidents!

Ordering Spare Parts

Spare parts can be ordered by quoting:

- The truck specification number
- The truck model number
- The truck serial number

This information can be found on the truck's data plate. Only if this information is provided can the order be processed quickly, correctly and reliably.

Please refer to the Technical Specifications Sheet for the utilisable loads, technical data and dimensions for this series. Brochures can be obtained from your CROWN dealer or from the following address:

CROWN Gabelstapler GmbH & CoKG Moosacher Str. 52 80809 Munich GERMANY

Tel.: +49 (0)89 / 93 002 -0 Fax: +49 (0)89 / 93 002 -175 oder 133

BUY NOW

Then Instant Download the Complete Manual Thank you very much!