

# CROWN

## Parts Manual



### WP2000S Series

---

**CROWN**

***TABLE OF CONTENT***

---

## Table of Content

<b>ITD – INTRODUCTION</b>	<b>PAGE</b>	<b>SERIAL NR. CUT</b>	<b>REV.</b>
General.....	7		
<b>SECTION 1 – COVERS</b>	<b>PAGE</b>	<b>SERIAL NR. CUT</b>	<b>REV.</b>
Covers .....	12		Rev.2 02/03
Covers (Batterierollers) .....	14		Rev.1 02/03
Caster Wheel .....	16		
<b>SECTION 2 – HYDRAULIC PART</b>	<b>PAGE</b>	<b>SERIAL NR. CUT</b>	<b>REV.</b>
Tube/Hose Layout .....	20		Rev.3 02/03
Pump Motor and Pump .....	22		Rev.2 02/03
<b>SECTION 3 – DRIVE UNIT</b>	<b>PAGE</b>	<b>SERIAL NR. CUT</b>	<b>REV.</b>
Drive Unit.....	26		Rev.3 02/03
Gearbox.....	28		Rev.1 03/02
Drive Motor .....	30		
Knuckle.....	32		Rev.2 02/03
<b>SECTION 4 – ELECTRICAL</b>	<b>PAGE</b>	<b>SERIAL NR. CUT</b>	<b>REV.</b>
Elektrical Parts .....	36,38,40		Rev.3 02/03
Contactore .....	42		
Control Handle .....	44,46		Rev.1 03/02
Emergency Disconnect/Battery Connector .....	48		Rev.2 02/03
Instrument .....	50		
Horn .....	52		Rev.2 02/03
<b>SECTION5 – BRAKE SYSTEM</b>	<b>PAGE</b>	<b>SERIAL NR. CUT</b>	<b>REV.</b>
Brake .....	56		Rev.1 03/02
<b>SECTION 7 – MAST-/LIFT STRUCTURE</b>	<b>PAGE</b>	<b>SERIAL NR. CUT</b>	<b>REV.</b>
Fork Carriage (single Loadwheel) .....	60,62		Rev.2 02/03
Fork Carriage (tandem Loadwheel) .....	64,66		Rev.2 02/03
Lift Stucture .....	68		Rev.3 02/03
<b>SECTION 8 – CYLINDER</b>	<b>PAGE</b>	<b>SERIAL NR. CUT</b>	<b>REV.</b>
Lift Cylinder .....	72		
<b>SECTION 9 – CABIN/PLATFORM</b>	<b>PAGE</b>	<b>SERIAL NR. CUT</b>	<b>REV.</b>
Platform .....	76,78		Rev.1 03/02
Platform (fixed Platform) .....	80		
<b>SECTION10 – MISCELLANEOUS SERVICE INF.</b>	<b>PAGE</b>	<b>SERIAL NR. CUT</b>	<b>REV.</b>
Labels and Decals .....	84		

---

**CROWN**

***INTRODUCTION***

---

## Important customer information

To ensure the safety of the truck, you, the customer, must only carry out maintenance and repairs as stipulated in the operator manual.

Any additional work must be performed by Crown authorised service technicians. Authorised service technicians have the required expertise and up-to-date service information.

If you wish to have your own technicians trained, please contact Crown for relevant training courses.

## Subsequent Attachments and Modifications made to the Truck

### **DANGER!**



***Any proposed modification which would alter the original condition of the truck when delivered, must first be assessed and approved in writing by Crown Gabelstapler GmbH.***

- *The net weight and position of attachments may considerably affect the capacity and other truck characteristics.*
- *Changing the electrical system or adding electrically operated components may result in operating faults.*

***Modifications which have not been assessed may result in fatal accidents!***

## Ordering Spare Parts

Spare parts can be ordered by quoting:

- The truck specification number
- The truck model number
- The truck serial number

This information can be found on the truck's data plate. Only if this information is provided can the order be processed quickly, correctly and reliably.

Please refer to the Technical Specifications Sheet for the utilisable loads, technical data and dimensions for this series. Brochures can be obtained from your CROWN dealer or from the following address:

**CROWN Gabelstapler GmbH & CoKG**  
**Moosacher Str. 52**  
**80809 Munich**  
**GERMANY**  
**Tel.: +49 (0)89 / 93 002 -0**  
**Fax: +49 (0)89 / 93 002 -175 oder 133**

**BUY NOW**

**Then Instant Download  
the Complete Manual  
Thank you very much!**