

Onan

**Service
Manual**

20 kW

ES

**Generator and
Controls**

900-0335

7/82
Printed in U.S.A.

Safety Precautions

The following symbols in this manual highlight conditions potentially dangerous to service personnel, or equipment. Read this manual carefully. Know when these conditions can exist. Then take necessary steps to protect personnel as well as equipment.

▲ DANGER *This symbol warns of immediate hazards which will result in severe personal injury or death.*

▲ WARNING *This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.*

▲ CAUTION *This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.*

PROTECT AGAINST MOVING PARTS

Avoid moving parts of the unit. Avoid use of loose jackets, shirts or sleeves due to danger of becoming caught in moving parts.

Make sure all nuts and bolts are secure. Keep power shields and guards in position.

If you must make adjustments while the unit is running, use extreme caution around hot manifolds,

moving parts, etc.

Do not work on this equipment when mentally or physically fatigued.

GUARD AGAINST ELECTRIC SHOCK

Disconnect electric power before removing protective shields or touching electrical equipment. Use rubber insulative mats placed on dry wood platforms over floors that are metal or concrete when around electrical equipment. Do not wear damp clothing (particularly wet shoes) or allow skin surfaces to be damp when handling electrical equipment.

Disconnect batteries to prevent accidental engine start. Jewelry is a good conductor of electricity and should be removed before working on electrical equipment.

Use extreme caution when working on electrical components. High voltages cause injury or death.

Follow all state and local codes. To avoid possible personal injury or equipment damage, a qualified electrician or an authorized service representative must perform installation and all service.

▲ WARNING

EXHAUST GAS IS DEADLY!

Exhaust gases contain carbon monoxide, an odorless and colorless gas. Carbon monoxide is poisonous and can cause unconsciousness and death. Symptoms of carbon monoxide poisoning can include:

- Dizziness
- Nausea
- Headache
- Weakness and Sleepiness
- Throbbing in Temples
- Muscular Twitching
- Vomiting
- Inability to Think Coherently

IF YOU OR ANYONE ELSE EXPERIENCE ANY OF THESE SYMPTOMS, GET OUT INTO THE FRESH AIR IMMEDIATELY. If symptoms persist, seek medical attention. Shut down the unit and do not operate until it has been inspected and repaired.

Protection against carbon monoxide inhalation includes proper installation and regular, frequent visual and audible inspections of the complete exhaust system.

Contents

TITLE	PAGE
SAFETY PRECAUTIONS	Inside Front Cover
INTRODUCTION	2
Service Manual	2
Test Equipment	2
Generator Description	3
Generator Operation	3
Voltage Reconnection with Optional Instruments	4
GENERATOR TROUBLESHOOTING	4
Preparation	4
Troubleshooting Procedures	4
Flow Chart A. No Build Up of AC Output Voltage	5
Flow Chart B. AC Output Voltage Builds Up, But is Unstable	6
Flow Chart C. AC Output Voltage Builds Up, But High or Low	6
Flow Chart D. AC Output Voltage Builds Up, But Field Breaker Trips	7
Flow Chart E. Unbalanced Generator Output Voltage	8
ADJUSTMENTS AND TESTS	9
DC CONTROL	19
General	19
Control Panel	19
Control Panel Interior	19
Engine Sensors	22
ENGINE CONTROL SYSTEM OPERATION	24
ENGINE CONTROL TROUBLESHOOTING	26
CONTROL COMPONENT CHECKOUT	30
GOVERNOR ADJUSTMENTS	31
General	31
Governor Adjustment, Engine Speed	31
WIRING DIAGRAMS	32

▲WARNING

INCORRECT SERVICE OR REPLACEMENT OF PARTS MIGHT RESULT IN SEVERE PERSONAL INJURY AND/OR EQUIPMENT DAMAGE. SERVICE PERSONNEL MUST BE QUALIFIED TO PERFORM ELECTRICAL AND/OR MECHANICAL SERVICE.

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**