



Service Manual

Our energy working for you.™



Transfer Switch 30–260 Amperes (Spec J)

LT III

Table of Contents

SECTION	TITLE	PAGE
	SAFETY PRECAUTIONS	iii
1	INTRODUCTION	1-1
	About This Manual	1-1
	Transfer Switch Application	1-1
	Automatic Transfer Switches	1-1
	Transfer Switch Protection	1-2
	Removing and Replacing Electronic Control Components	1-2
	Model Identification	1-2
	Feature Description / Feature Option	1-3
2.	DESCRIPTION AND OPERATION	2-1
	General	2-1
	Component Descriptions	2-1
	Transfer Switch Assembly	2-2
	Electronic Control	2-4
	Optional Modules	2-5
	Operation	2-6
	Generator Set Exercise	2-6
	Planned Maintenance	2-8
3.	ADJUSTMENTS AND SETTINGS	3-1
	Introduction	3-1
	Calibrating and Adjusting the Electronic Control	3-1
	Time Delay	3-3
	3-Wire Start Module	3-4
	Program Transition	3-4
	Exerciser Clock (Control Package B Only)	3-5
	Float Battery Charger	3-7
	10 Amp Charger Alarm Settings	3-9
	Converting Transfer Switch Phase Setting (Control Package B Only)	3-10
4.	TROUBLESHOOTING	4-1
	Introduction	4-1
	Control System Operation	4-1
	Control Circuit Board Indicator Lamps	4-2
	Troubleshooting	4-5

Table of Contents (Continued)

SECTION	TITLE	PAGE
5.	TRANSFER SWITCH SERVICE	5-1
	Introduction	5-1
	Disconnect AC Power	5-1
	Reconnecting AC Power	5-1
	30- to 60-Ampere Contactor Assembly Service	5-1
	100- to 260-Ampere Contactor Assembly Service	5-5
	Electronic Control Circuit Board	5-6
	Program Transition Module	5-7
	Manual Override Switch S3	5-8
	Membrane Touch Panel (Control Package B Only)	5-9
6	SCHEMATICS AND WIRING DIAGRAMS	6-1
	Electronic Control 300-4754 (Control Package A)	6-2
	Electronic Control 300-4750 (Control Package B)	6-3
	626-2252 Sheet 1 of 8 (Typical 30- to 60-Ampere Switch)	6-4
	626-2252 Sheet 2 of 8 (Typical 30- to 60-Ampere Switch)	6-5
	626-2252 Sheet 3 of 8 (Typical 30- to 60-Ampere Switch)	6-6
	626-2252 Sheet 4 of 8 (Typical 30- to 60-Ampere Switch)	6-7
	626-2252 Sheet 5 of 8 (Typical 30- to 60-Ampere Switch)	6-8
	626-2252 Sheet 6 of 8 (Typical 30- to 60-Ampere Switch)	6-9
	626-2252 Sheet 7 of 8 (Typical 30- to 60-Ampere Switch)	6-10
	626-2252 Sheet 8 of 8 (Typical 30- to 60-Ampere Switch)	6-11
	626-2242 Sheet 1 of 5 (Typical 100- to 260-Ampere Switch)	6-12
	626-2242 Sheet 2 of 5 (Typical 100- to 260-Ampere Switch)	6-13
	626-2242 Sheet 3 of 5 (Typical 100- to 260-Ampere Switch)	6-14
	626-2242 Sheet 4 of 5 (Typical 100- to 260-Ampere Switch)	6-15
	626-2242 Sheet 5 of 5 (Typical 100- to 260-Ampere Switch)	6-16
	626-2264 Sheet 1 of 5 (Typical 30- to 60-Ampere Switch)	6-17
	626-2264 Sheet 2 of 5 (Typical 30- to 60-Ampere Switch)	6-18
	626-2264 Sheet 3 of 5 (Typical 30- to 60-Ampere Switch)	6-19
	626-2264 Sheet 4 of 5 (Typical 30- to 60-Ampere Switch)	6-20
	626-2264 Sheet 5 of 5 (Typical 30- to 60-Ampere Switch)	6-21
	626-2255 Sheet 1 of 3 (Typical 30- to 60-Ampere Switch)	6-22
	626-2255 Sheet 2 of 3 (Typical 30- to 60-Ampere Switch)	6-23
	626-2255 Sheet 3 of 3 (Typical 30- to 60-Ampere Switch)	6-24

⚠WARNING

INCORRECT SERVICE OR REPLACEMENT OF PARTS CAN RESULT IN DEATH, SEVERE PERSONAL INJURY, AND/OR EQUIPMENT DAMAGE. SERVICE PERSONNEL MUST BE QUALIFIED TO PERFORM ELECTRICAL AND/OR MECHANICAL SERVICE.

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**