

Service Manual

Our energy working for you.™



X1.7 –2.5 Engine Series

CONTENTS

Group Page No. Description Page Nos are deliberately numbered in this fashion as this document references the page nos in for the domestic X series Workshop Manual 01 **BASE ENGINE** 23 1.1 Cylinder Head 24 1.2 Pistons And Connecting Rod 28 1.3 Cylinder Block And Liners 31 1.4 Crankshaft And Main Bearings 32 1.5 Timing Case And Drive 38 **Fuel Timing** 1.6 43 1.7 **Lubricating System** 45 1.8 Cooling System 50 1.9 Fuel System And Air Cleaner 52 Flywheel And Flywheel Housing 1.10 54 1.11 Service Tools 55 Threads / Recommended Torque 58 1.12 Manufacturing Data and Dimensions 60 1.13 03 SUB-ASSEMBLY 125 3.1 Fuel Injection Pump & Injector 126 3.2 **Starting Motor** 131 3.3 **Battery Charging Alternator** 132 04 **GENSET ASSEMBLY** 139 Assembly of Fuel Tank, Engine Support, Radiator, 130 Air Cleaner, Safety Switches, Fuel Solenoid, Wiring Harness, C P Box, etc. 05 **MISCELLANEOUS** 151 5.1 **Genset Installation Guidelines** 152 5.2 Trouble Shooting Guidelines 162 5.3 Genset Testing Procedure 165

FOREWORD

This manual is designed to be of assistance to all personnel concerned with the maintenance and overhaul of the DXP Series Genset. It presents a complete and detailed description of the Genset, together with precise instruction on servicing and overhaul procedure and dimensions which should be closely followed when overhauling any part of the Genset to the Manufacturers standards.

Effective maintenance can only be carried out if the personnel concerned are fully

conversant with the various components of the Genset. Before maintenance operations are commenced, this manual should be carefully studied, and it should at all times be kept where it will be needed in the workshop.

BUY NOW

Then Instant Download the Complete Manual Thank you very much!